


DISTRIBUTED SNIFFER SYSTEM™

Expert Analyzer Operations Manual



NETWORK GENERAL CORPORATION



Expert Analyzer Operations Manual



NETWORK GENERAL CORPORATION

DISCLAIMER OF WARRANTIES

The information in this document has been reviewed and is believed to be reliable; nevertheless, Network General Corporation makes no warranties, either expressed or implied, with respect to this manual or with respect to the software and hardware described in this manual, its quality, performance, merchantability, or fitness for any particular purpose. The entire risk as to its quality and performance is with the buyer. The software herein is transferred "AS IS."

Network General Corporation reserves the right to make changes to any products described herein to improve their function or design.

In no event will Network General Corporation be liable for direct, indirect, incidental or consequential damages at law or in equity resulting from any defect in the software, even if Network General Corporation has been advised of the possibility of such damages. Some states do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This document is copyrighted and all rights are reserved. This document may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior consent, in writing, from Network General Corporation.

Sniffer is a registered trademark of Network General Corporation

Sniffer Network Analyzer is a trademark of Network General Corporation.

All other registered and unregistered trademarks in this document are the sole property of their respective owners.

©Copyright 1993 by Network General Corporation. All rights reserved.

Present copyright law protects not only the actual text, but also the "look and feel" of the product screens, as upheld in the Atari and Broderbund cases.

Document prepared by Sid Heaton with contributions from Jim Mar, Terri FitzMaurice, and Arlene Brenner.

March 1993

P/N:20103-001

Table of Contents

Preface	xiii
About This Manual	xiii
Manuals for the Distributed Sniffer System	xiii
Audience of This Manual	xiv
Organization of This Manual	xiv
Navigational Aids Used in this Manual	xv
Conventions Used in This Manual	xv
Special Notations	xv
Terminology	xvi
Screen Displays and Keyboard Input	xvi
Other Sources of Information	xvi
On-Line Help	xvi
Technical Support	xvii
Training	xvii
 Chapter 1. Overview—What a Sniffer Analysis Server Does	1-1
Overview	1-3
The Distributed Sniffer System	1-3
About the Distributed Sniffer System	1-3
Major Components of the Sniffer Analysis Server	1-5
The Role of the Analyzer	1-5
The Analyzer as (Mostly) Passive Observer	1-6
A Map of the Analyzer's Functions	1-7
The Analyzer's Menus and Controls	1-9
The Server's Selection Menu	1-9
Tree-Structure of the Analyzer's Menus	1-10
Features of the Expert Sniffer Analyzer	1-13
 Chapter 2. Getting Familiar with the Expert Analyzer	2-1
Overview	2-3
Expert Analyzer Terminology	2-3
About Network Objects	2-3
About Symptoms	2-4
About Diagnoses	2-4
About Alarms	2-4
Starting the Sniffer Analyzer in Expert Mode	2-5
Getting More Information About a Diagnosis	2-9
Getting Context-Sensitive Explain Messages	2-10

Getting More Information About Symptoms and Network Objects	2-12
Protocols Available for Expert Analysis	2-15
Chapter 3. Expert Analyzer Options	3-1
Overview	3-3
Expert Layers and the OSI Model	3-4
Configuring the Expert Analyzer	3-7
Setting Subnet Masks	3-7
Setting Trustee Names	3-11
Setting Thresholds for Symptoms and Diagnoses	3-13
Symptom and Diagnosis Thresholds at Each Expert Layer	3-15
Application Thresholds	3-17
Connection Thresholds	3-21
Network Station Thresholds	3-22
DLC Station Thresholds	3-24
Token Ring-Specific (MAC level) Thresholds	3-26
WAN/Synchronous (Sniffer Internetwork Analyzer) Thresholds	3-28
Effects of Changing Expert Thresholds	3-30
Console Alarms	3-33
Application Layer Alarms	3-34
Connection Layer Alarms	3-35
Network Layer Alarms	3-35
DLC Station Layer Alarms	3-36
Token Ring-Specific (MAC level) Alarms	3-36
Alarm Levels	3-38
Alarm Throttle	3-38
Expert Triggers	3-39
Effects of an Expert Trigger	3-40
Available Expert Triggers	3-41
The Order in Which the Analyzer Processes Triggers	3-42
Customizing a Capture Session	3-43
Highest Layer Option	3-44
Freeze/Reuse Allocation Option	3-45
Print Network Objects Option	3-47
Name Width Display Option	3-51
How the Expert Analyzer Learns Symbolic Names	3-52
Chapter 4. Expert Analyzer Capture and Display	4-1
Overview	4-3
Displaying Analysis Results In the Expert Window	4-3
Navigating the Expert Window	4-6
The Expert Overview Display	4-8

Navigating through the Expert Overview	4-9
Other Counters in the Expert Overview	4-9
Diagnosis-Related Displays	4-10
Diagnosis Summary Window	4-10
Diagnosis Detail Displays	4-13
Symptom and Network Object-Related Displays	4-36
About Symptom and Network Object-Related Displays	4-36
Symptom and Network Object Summary Windows	4-36
Displaying the Summary Window	4-37
Information in the Summary Windows	4-38
Changing the Format of the Summary Window	4-40
Application and Connection Layer Summary Window	4-41
Network Station Summary Window	4-43
DLC Station Summary Window	4-44
Subnet Pairs Summary Window	4-44
Global Symptom Summary Window	4-46
Symptom and Network Object Detail Windows	4-47
Displaying the Detail Window	4-47
Information in the Detail Windows	4-49
Subnet Pairs Detail Window	4-51
Global Symptom Detail Window	4-53
Symptom and Network Object Statistics Windows	4-54
Displaying a Statistics Window	4-55
Application Statistics Window	4-56
Connection Statistics Window	4-58
Network Station Statistics Window	4-59
DLC Station Statistics Window	4-60
The Global Statistics Window	4-64
Composition of the Global Statistics Window	4-64
Effects of Capture Filters on Global Statistics	4-68
Effects of Frame Size Option on Global Statistics	4-68
Expert Display Filters	4-68
Network Object Filter	4-68
Symptom Frames Filter	4-76
Advanced Navigation Techniques	4-77
Using the Higher Layer/Lower Layer Function Keys	4-77
Using the Next Symptom/Previous Symptom Keys	4-79
Function Keys in the Expert Window	4-80
Appendix A. Symptom and Diagnosis Messages	A-1
Overview	A-3
Symptoms	A-3

Application Layer	A-3
Connection Layer	A-4
Network Station Layer	A-6
DLC Station Layer	A-9
MAC Layer (Token Ring)	A-9
WAN/Synchronous	A-11
Diagnoses	A-14
Application Layer	A-14
Connection Layer	A-14
Network Station Layer	A-15
DLC Station Layer	A-15
MAC Layer (Token Ring)	A-16
WAN/Synchronous	A-17

Index

List of Figures

Chapter 1. Overview—What a Sniffer Analysis Server Does

Figure 1-1. Basic Distributed Sniffer System components.	1-4
Figure 1-2. Major software components of a Sniffer analysis Server.	1-5
Figure 1-3. Overview of Sniffer analyzer functions.....	1-8
Figure 1-4. Server selection menu.	1-10
Figure 1-5. Main menu of the Sniffer analyzer (in this case, for Ethernet).....	1-11
Figure 1-6. Scrolling over the tree-structured menu.	1-12
Figure 1-7. New features of the Expert Sniffer analyzer.....	1-13

Chapter 2. Getting Familiar with the Expert Analyzer

Figure 2-1. Role of the Expert analyzer in solving network problems.	2-5
Figure 2-2. Main Selection Menu of a Sniffer Server.....	2-6
Figure 2-3. Initialization screen of the Sniffer Network Analyzer.....	2-7
Figure 2-4. Main Menu of the Sniffer analyzer (in this case, for Ethernet).	2-7
Figure 2-5. Expert Overview window of the Expert analyzer.	2-8
Figure 2-6. Application Diagnosis Summary window. This view shows all diagnoses at the Application layer.	2-9
Figure 2-7. Application Diagnosis Detail screen.	2-10
Figure 2-8. Explain screen for the diagnosis, <i>Slow server</i>	2-11
Figure 2-9. Expert Overview with Objects/Symptoms column highlighted at Connections layer.	2-12
Figure 2-10. Connection Summary window.....	2-13
Figure 2-11. Connection Detail window. This window provides detailed information about a specific connection.....	2-13
Figure 2-12. Connection Statistics screen.	2-14
Figure 2-13. Protocols currently available for Expert analysis.....	2-15
Figure 2-14. The protocols on which the analyzer can perform Expert analysis.	2-16

Chapter 3. Expert Analyzer Options

Figure 3-1. How the OSI model of network layers relates to the Expert's model.....	3-5
Figure 3-2. The Diagnosis Overview window. The four Expert layers are displayed at left, along with Subnet Pairs and Global Symptoms.....	3-6
Figure 3-3. Configuration menu of the Expert Sniffer analyzer.	3-7
Figure 3-4. Two different Class A IP broadcast addresses.....	3-8
Figure 3-5. Set Subnet Masks box.....	3-9
Figure 3-6. Entering the IP network address.	3-9

Figure 3-7. Entering the associated subnet mask.	3-10
Figure 3-8. List of defined IP network addresses and subnet masks.	3-10
Figure 3-9. Modifying or deleting the IP address.	3-10
Figure 3-10. Set Trustee Names box	3-12
Figure 3-11. Entering a new Trustee Name.	3-12
Figure 3-12. The Expert settings\Thresholds\Connection layer menu.	3-14
Figure 3-13. Expert thresholds available at each Expert layer.	3-16
Figure 3-14. How the analyzer calculates the value of Duplicate address percentage.	3-23
Figure 3-15. The relationship between the thresholds <i>LAN overload</i> and <i>LAN overload%</i>	3-25
Figure 3-16. Results of Expert analysis can vary depending on when performed.	3-31
Figure 3-17. A single frame exhibiting two symptoms. Only the first is detected by the analyzer.	3-32
Figure 3-18. Alarm Priorities available for each Expert layer.	3-33
Figure 3-19. The Trigger\Expert trigger\Application layer menu.	3-40
Figure 3-20. Expert triggers available at each Expert layer.	3-41
Figure 3-21. The order in which the analyzer processes triggers.	3-43
Figure 3-22. Expert settings\Highest layer menu. Notice that the radio control is set to <i>Application</i> , the default.	3-45
Figure 3-23. Capture\Expert mode menu.	3-47
Figure 3-24. Menu items associated with printing network objects.	3-48
Figure 3-25. Printed report on a network object.	3-50

Chapter 4. Expert Analyzer Capture and Display

Figure 4-1. Schematic of the various Expert windows.	4-4
Figure 4-2. The Expert Overview.	4-8
Figure 4-3. Diagnosis Summary window; in this case, at the Application layer.	4-11
Figure 4-4. Diagnosis Detail displays and their related Expert thresholds.	4-14
Figure 4-5. Detail display for the diagnosis, "Broadcast storm."	4-15
Figure 4-6. Detail display for the diagnosis, "Duplicate net address."	4-16
Figure 4-7. Detail display for the diagnosis, "Excessive repeated requests."	4-17
Figure 4-8. Detail display for the diagnosis, "Excessive requests denied."	4-18
Figure 4-9. Detail display for the diagnosis, "File overlap/retransmission."	4-19
Figure 4-10. Detail display for the diagnosis, "High rate of congestion."	4-20
Figure 4-11. Detail display for the diagnosis, "High rate of line/burst errors."	4-21
Figure 4-12. Detail display for the diagnosis, "High rate of physical errors."	4-22
Figure 4-13. Detail display for the diagnosis, "High rate of remove from ring requests."	4-23
Figure 4-14. Detail display for the diagnosis, "High rate of ring entry."	4-24

Figure 4-15. Detail display for the diagnosis, "High rate of ring purges."	4-25
Figure 4-16. Detail display for the diagnosis, "LAN overloaded."	4-26
Figure 4-17. Detail display for the diagnosis, "Local Router."	4-27
Figure 4-18. Detail display for the diagnosis, "Multiple routers to station." . .	4-28
Figure 4-19. How the analyzer calculates a broken connection.	4-29
Figure 4-20. Detail display for the diagnosis, "Non-responsive station."	4-30
Figure 4-21. Detail display for the diagnosis, "Retransmissions."	4-31
Figure 4-22. Detail display for the diagnosis, "Ring beaconing."	4-32
Figure 4-23. Detail display for the diagnosis, "Slow file transfer."	4-33
Figure 4-24. Detail display for the diagnosis, "Slow server."	4-34
Figure 4-25. Detail display for the diagnosis, "Underloaded network."	4-35
Figure 4-26. Symptom and Network Object Summary window at the Expert Application layer.	4-37
Figure 4-27. Network Station Summary window.	4-38
Figure 4-28. The default Application Summary window.	4-41
Figure 4-29. Application and Connection layer Summary window formats. . .	4-41
Figure 4-30. Application Summary window in DLC station format.	4-42
Figure 4-31. Connection Summary window in Protocol format.	4-42
Figure 4-32. Network Station Summary window.	4-43
Figure 4-33. Network Station layer Summary window formats.	4-43
Figure 4-34. DLC Station Summary window.	4-44
Figure 4-35. DLC Station Summary window formats	4-44
Figure 4-36. Subnet Pairs Summary window.	4-45
Figure 4-37. Global Symptom Summary window.	4-46
Figure 4-38. Application Detail window.	4-47
Figure 4-39. Network Station Detail window.	4-49
Figure 4-40. How the analyzer interprets the DLC name and address of remote stations.	4-51
Figure 4-41. Subnet Pairs Detail Window.	4-52
Figure 4-42. Global Symptom Detail window.	4-53
Figure 4-43. Application Statistics window.	4-56
Figure 4-44. How the Expert analyzer calculates the value for Interframe time.	4-57
Figure 4-45. Connection Statistics window (in this case, for TCP/IP).	4-58
Figure 4-46. Network Station Statistics window.	4-59
Figure 4-47. DLC Station Statistics Window.	4-61
Figure 4-48. The Global Statistics window.	4-64
Figure 4-49. Setting a Network object filter. Notice the function key F2	4-70
Figure 4-50. Summary display after Network object filter has been set on the diagnosis, "Retransmissions between SALES and Kathy."	4-71

Figure 4-51. Network Stations Summary window. Notice the Classic Summary display in the background.	4-72
Figure 4-52. Network object filter on the server <i>BIZ-ONE</i>	4-72
Figure 4-53. The Display\Filters menu.	4-74
Figure 4-54. Displaying the current Network object filter.	4-75
Figure 4-55. <i>Symptom frames</i> filter. Notice the <i>x</i> preceding the filter.	4-76
Figure 4-56. Classic Summary display with <i>Symptom frames</i> filter enabled.	4-77
Figure 4-57. Application Summary screen with F7 (Lower layer) visible.	4-78
Figure 4-58. Pop-up box for selecting related network station to display.	4-79

List of Procedures

Chapter 1. Overview—What a Sniffer Analysis Server Does

To start an analyzer	1-10
To work with the Sniffer analyzer menus:	1-12

Chapter 2. Getting Familiar with the Expert Analyzer

To start capturing and analyzing frames in Expert mode:	2-6
To obtain more information about a diagnosis:	2-9
To display an Explain message during capture:	2-11
To view the protocols on which your analyzer can perform Expert analysis: ..	2-15

Chapter 3. Expert Analyzer Options

To add a specific IP network address and associated subnet mask:	3-9
To modify or delete existing IP network addresses and subnet masks:	3-10
To specify trustee names to be excluded from the Novell name search:	3-11
To delete or modify trustee names:	3-12
To set an Expert threshold:	3-13
To set the alarm level:	3-38
To configure the alarm throttle:	3-38
To set an Expert trigger:	3-39
To specify the highest Expert layer at which Expert analysis takes place:	3-44
To specify the Expert analyzer's action when memory is exhausted:	3-46
To create a report on a network object:	3-48
To define the Name width option:	3-51
To help the Expert analyzer learn symbolic names:	3-52

Chapter 4. Expert Analyzer Capture and Display

To display a Diagnosis Summary window:	4-10
To temporarily remove a diagnosis from the Expert window:	4-12
To restore removed diagnoses to the display:	4-12
To display a Diagnosis Detail window:	4-13
To display a Summary window at any of the Expert layers:	4-37
To change the format of the Summary window:	4-40
To display a Detail window from the Symptom and Network Object column of the Expert Overview:	4-48
To display a Symptom and Network Object Detail window from the Diagnoses column of the Expert Overview:	4-48

To display a Statistics window from the Symptom and Network Object column of the Expert Overview:	4-55
To display a Statistics window from the Diagnoses column of the Expert Overview:	4-55
To display the Global Statistics window:	4-64
To set an automatic Network object filter:	4-69
To display the current Network object filter:	4-73
To remove a Network object filter using the Network object menu item:	4-75
To temporarily disable or enable a Network Object filter:	4-76
To filter out frames that do not exhibit symptoms:	4-76
To use the Higher layer/Lower layer function keys:	4-78
To use the Next symptom/Previous symptom keys:	4-79

PREFACE

Preface

About This Manual

This manual describes the functions and operations of the Expert Sniffer® analyzer, a software application of the Distributed Sniffer System™ (DSS). It also provides recommendations on how to use the Expert analyzer effectively to detect and solve network problems. This manual describes only those operations relating to the Expert mode of the analysis application. For information on Classic mode operations, see the *Distributed Sniffer System: Analyzer Operations Manual*.

The Distributed Sniffer System consists of two types of product: Sniffer Servers and SniffMaster™ Consoles. Each Server observes the local or wide area network to which it is attached; Consoles control Servers and display the results of the Servers' activities.

Manuals for the Distributed Sniffer System

Two types of manuals accompany the Distributed Sniffer System. The primary manuals, which include this one, describe the system's normal operations; the supplementary manuals describe the programs that configure and test the system's various hardware and software components. The actual manuals in your shipment depend on the system configuration.

Figure i lists the primary manuals for the Distributed Sniffer System

For Information On...	Read...
Installing and configuring Servers and Consoles. Operating Consoles.	<i>Distributed Sniffer System: Console Installation and Operations Manual, Server Installation and Operations Manual, or Sniffer Server Installation Note.</i>
Operating the Server's Analyzer functions on an Ethernet, token ring, or wide-area network.	<i>Distributed Sniffer System: Analyzer Operations Manual.</i>
Operating the Server's Expert Analyzer functions on an Ethernet, token ring, or wide area network.	<i>Distributed Sniffer System: Expert Analyzer Operations (this manual).</i>
Operating the Server's Monitor functions on a token ring network.	<i>Distributed Sniffer System: Token Ring Monitor Operations Manual.</i>
Operating the Server's Monitor functions on an Ethernet network	<i>Distributed Sniffer System: Ethernet Monitor Operations Manual.</i>
Various network and protocol types.	<i>Distributed Sniffer System: Network and Protocol Reference Manual.</i>

Figure i. Primary manuals for the Distributed Sniffer System.

Figure ii lists the supplementary manuals for the Distributed Sniffer System.

For Information On...	Read...
IBM 16/4 token ring adapter (ISA)	<i>Token Ring 16/4 Network Guide to Operations</i>
IBM 16/4 token ring adapter (MCA)	<i>Token Ring 16/4 /A Network Guide to Operations</i>
InterLan NI5210 Ethernet controller (ISA)	<i>NI5210 Installation Manual</i>
InterLan NI9210 Ethernet controller (MCA)	<i>NI9210 Installation Manual</i>
4-Port Serial Adapter (ISA)	<i>QS-100D Installation Manual</i>
4-Port Serial Adapter (MCA)	<i>QS-1000 Installation Manual</i>

Figure ii. Supplementary manuals for the Distributed Sniffer System.

If the product shipment includes release notes or README files on disks, the information in the notes or files supersedes the information in this and other manuals.

Audience of This Manual

This manual has been prepared with the following assumptions:

- You are a network manager or troubleshooter who understands how networks operate.
- You are familiar with DOS.

Organization of This Manual

Figure iii describes the organization of this manual.

Chapter/Appendix	Contents
Chapter 1, "Overview-What a Sniffer Analysis Server Does"	Provides an overview of the Distributed Sniffer System and describes its capabilities. Also defines key terms, lists new functions, and provides an introduction to the user interface.
Chapter 2, "Getting Familiar with the Expert Analyzer"	Provides an overview of the Expert Sniffer analyzer and describes its capabilities. Also defines key Expert terms, and lists new functions.
Chapter 3, "Expert Analyzer Options"	Describes various Expert analyzer precapture options, including a description of the Expert layers, how to set an Expert threshold, and how to set an Expert trigger.

Figure iii. Scope of each chapter or appendix in this manual.

Chapter/Appendix	Contents
Chapter 4, "Expert Analyzer Capture and Display"	Describes all Expert screen displays. Provides information on how to navigate through the Expert displays to get the maximum information about network problems.
Appendix A, "Symptom and Diagnosis Messages"	Provides a list of solutions to common problems.

Figure iii. Scope of each chapter or appendix in this manual.

Navigational Aids Used in this Manual

This manual uses icons in the margin to help you locate important information as explained below:



IMPORTANT INFORMATION. Next to this icon is information that is especially important; you should be certain to read it carefully before you proceed. This icon also indicates useful and valuable ways to use the product.



CAUTION. Next to this icon is information that you must know to avoid damage to data files, program files, or hardware devices. This icon also indicates information that you must know to avoid possible injury to yourself or others.



PROCEDURE. Next to this icon is a series of steps for accomplishing a particular task.

To help you find procedures easily, a separate List of Procedures is provided in this manual in addition to the Table of Contents and List of Figures.

Conventions Used in This Manual

Special Notations

The following describes the conventions used in this manual:

Bold	Menu options and menu listings are in bold type. Two examples follow: Move to Display , and press Enter. To set a display filter, move to Display\Filters and use the spacebar to toggle the desired filter.
UPPERCASE	Filenames and commands you type at a DOS prompt are in uppercase. For example: Modify the AUTOEXEC.BAT file if necessary. To duplicate the file, use the COPY command.

<i>Bold italics</i>	Variables for which you insert values are in bold italics. For example: Type the number of minutes and seconds in the <i>mm:ss</i> format.
Screen font	Screen messages are printed in monospaced font. For example: If a monitoring session is in progress, the following message appears: You must stop monitoring before you can use this feature.

Terminology

Hexadecimal numbers in the manual are followed by "(hex)"; numbers without any notations are decimal. For example, "The maximum number of stations is 75. The default memory address is D8000 (hex)."

The terms "monitor" and "analyzer" refer to software applications that run on token ring or Ethernet Sniffer Servers. The term "Console" refers to control and display software running on a dedicated PC.

This manual sometimes uses abbreviated names for the various components of the Distributed Sniffer System. The term "analyzer" stands for the analysis application. The term "Expert analyzer" stands for the analysis application capturing or displaying in the Expert window.

Screen Displays and Keyboard Input

Enter all the keystrokes mentioned in the manual from the SniffMaster Console. Similarly, all the screen displays generated by a Server appear on the Console's screen.

The screen displays in this manual serve mainly as examples and may not be identical to the ones you see on your Console screen. For example, you can choose to have the Console show the Server name on each monitor display, but the screens in this manual do not show the name.

Other Sources of Information

Network General Corporation (NGC) provides other sources of information that can help you become familiar with the Distributed Sniffer System.

On-Line Help

After highlighting an item in a Console, Analyzer, or Monitor menu, you may notice a phrase or sentence in a panel near the bottom of the screen. It explains the meaning of the highlighted item.

When running an analyzer application, there are two kinds of on-line help. If you want to obtain general information on a particular feature of the analyzer application, press F1(**Help**) whenever its key label appears on the screen. A window containing a list of topics opens. Note that in the Expert window, the key label for F1 reads **Explain**. Explain screens provide context-sensitive solutions to specific network problems highlighted in the Expert window. Help screens provide general descriptions and instructions for the items in the analyzer's menus.

Technical Support

The toll-free number for obtaining technical support for the Distributed Sniffer System is listed below. Before calling, however, please check the Troubleshooting Guide in the *Distributed Sniffer System: Analyzer Operations* manual. You will find tips for troubleshooting your system before requesting help as well as information you will need to provide if you do request help.

Phone for Network General's Technical Support Department:	(800) 395-3151
FAX	(415) 327-9436

Training

NGC offers a comprehensive set of training courses focused on hands-on network analysis and troubleshooting using the Expert Sniffer Network Analyzer. For more information, contact your sales representative.

CHAPTER ONE: OVERVIEW—WHAT A SNIFFER ANALYSIS SERVER DOES

1

Overview—What a Sniffer Analysis Server Does

Overview

This chapter provides a general orientation to the Sniffer analysis Server. The chapter starts with a general description of the distributed analysis system and its components: *SniffMaster Consoles*, *Sniffer monitor Servers*, *Sniffer analysis Servers*, and *Sniffer combined monitoring and analysis Servers* (combining the functions of monitoring and analysis in a single Server).

The chapter depicts the organization of a Server's *analysis* functions by showing a map of the way information flows between them and back to the Console. Analysis has two main phases: *capture* (when frames are recorded in a storage buffer), followed by *analysis* (when the captured frames are interpreted and displayed). Capture can occur *live* from the network, or as a *replay* of previously captured data.



This manual describes the operation of the analysis application in Expert mode. For information on operating the analysis application in Classic mode, or information on the analyzer in general, see the *Distributed Sniffer System: Analyzer Operations Manual*.

The Distributed Sniffer System

The Sniffer analysis Server whose operations are described in this manual is one of the principal components of the Distributed Sniffer System. For a perspective on the entire system and the role of the SniffMaster Console in controlling it, see the companion publication, *Distributed Sniffer System: Console Installation and Operations Manual*.

About the Distributed Sniffer System

A Distributed Sniffer System consists of *SniffMaster Consoles* controlling network monitoring and analysis tools known as *Sniffer Servers*. A basic Distributed Sniffer System is illustrated in Figure 1-1.




Figure 1-1. Basic Distributed Sniffer System components.

SniffMaster Console

Consoles connect to Servers and allow you to observe your network and control the Servers' activities. Consoles use proprietary software for communicating with Servers.

Sniffer Servers

Servers are computers with proprietary software and hardware. They use two cards: a *Transport Card* that supports communication with Consoles and a *Monitor Card* that uses software to capture frames and collect statistics from the network.

DSS Software

SniffMaster Consoles receive network information from Servers which use monitoring and/or analysis software applications.

The monitoring application maintains a set of real-time counters, charts, and summaries of network activity. The monitor transmits alarms to Consoles based on user-specified threshold values.

The analysis application captures network traffic in two modes.

- Classic capture. Classic capture records network traffic for later interpretation.
- Expert capture. While capturing in Expert mode, the analyzer alerts you to symptoms and diagnoses as it captures traffic. Symptoms and diagnoses represent potential network problems detected by the analyzer. In this mode, alarms are sent to the Console when diagnoses become active.



This manual describes the operation of the analysis software application in Expert mode. For information on capturing in Classic mode, or general

information on the analysis application, see the *Distributed Sniffer System: Analyzer Operations* manual. For information on the monitoring application, see the *Distributed Sniffer System: (Ethernet or Token Ring) Monitor Operations Manual*.

Major Components of the Sniffer Analysis Server

The Sniffer analyzer—that is, the network analyzer program installed in a Sniffer analysis Server—is a software component of the Distributed Sniffer System. Figure 1–2 summarizes the major software components of a Sniffer analysis Server.




Figure 1–2. Major software components of a Sniffer analysis Server.

You can operate the analysis application in either Expert or Classic mode. When this manual mentions the “Expert Sniffer analyzer,” it is referring to the analysis application capturing or displaying in Expert mode. Similarly, the term, “Classic Sniffer analyzer,” refers to the analysis application capturing or displaying in Classic mode.

The Role of the Analyzer

An analyzer records and interprets network transmissions. The work of the analyzer occurs in two main stages:

- Capture The analyzer records network traffic for later interpretation. Capture can be filtered to record only traffic that meets certain criteria. Capture can be frozen when a user-definable trigger event occurs. This assures that the retained capture buffer includes traffic just before or after the event of interest.

During capture in Expert mode, frames are analyzed as they are stored in the buffer. Alarms may be generated and sent to the Console while in capture mode. The various Expert displays are dynamically updated as capture proceeds, allowing you to navigate between various levels of detail to solve network problems in real time.

While capturing frames, the analyzer software maintains and displays graphs or tables that summarize recorded traffic.¹

Display The analyzer interprets the recorded traffic. In the Classic window, the analyzer decodes the various layers of protocol in the recorded frames and displays them as English abbreviations or summaries. The analyzer can filter the display to show only those frames that meet certain criteria.

You can also display the captured frames in the Expert window, allowing you to investigate the symptoms and diagnoses the Expert analyzer detected. In the Expert window, all the views available during capture are also available during display. You can toggle display between the Classic and Expert windows by pressing the function key F3.

The Analyzer as (Mostly) Passive Observer

A Sniffer Server “hears” all traffic that passes over the segment it is observing. On a WAN/Synchronous link, it hears traffic in both directions (“from DTE” and “from DCE”). On a LAN, it hears all traffic that passes over the segment or subnet that it is monitoring. It is characteristic of a LAN that every station physically receives every transmission. Ordinarily, each station ignores all messages except broadcast messages and those addressed to it. The analyzer not only hears all transmissions, but, while in “capture” mode, it can record them, regardless of how they’re addressed.

In general, the Sniffer Server observes, tabulates, analyzes, or captures, but contributes no traffic to the network it is observing. However, when the analyzer is observing a LAN, it may contribute to the LAN’s traffic as follows:

- On Ethernet and token ring, an analyzer can generate test frames. In this buffer mode, it repeatedly transmits the single test packet you specify or a file of captured frames.
- On Ethernet, the analyzer can emit a pulse to test for cable defects. By default, the Ethernet analyzer emits a single test frame (as part of a time domain reflectometer test) just prior to starting capture. The analyzer does this to determine whether or not it is attached to an Ethernet cable. On some networks, this may be disruptive. If so, you can disable this feature in the Options menu of the analyzer. See the *Distributed Sniffer System: Analyzer Operations Manual* for more information.

1. The analyzer’s displays during capture resemble some of the displays produced by the monitor. Don’t confuse this mini-monitoring during capture with the full-blown monitor application, which is separate.

- On token ring, every station must participate in the ring by forwarding buffer mode traffic from its upstream neighbor to its downstream neighbor. The analyzer does that in the same way as other stations. However, the analyzer does not reply to the poll for standby monitors, and never acts as the ring's active monitor. It is thus invisible to most other stations.

Note: During traffic generation, however, the token ring analyzer may act as the active monitor if no other station is transmitting and responds to standby monitor polls.

- On token ring, the analyzer periodically transmits a frame addressed to "LAN Manager" announcing "trace tool present." If properly configured, the LAN Manager can force such a station to leave the ring immediately.

A Map of the Analyzer's Functions

The analyzer's activities are divided into the set of functions described below. The diagram in Figure 1-3 represents schematically the route by which information flows between the various functions. Following the path of the frames as they are captured, they are affected by the analyzer's principal functions as follows:

- Capture filters determine which frames are discarded and which are captured.
- Capture views show the capture's progress, in Expert, individual stations, pair counts, or skyline formats.
- Trigger detector scans arriving frames for a user-defined pattern or event. When it detects this pattern or event, it stops capture so that frames preceding or following the event are retained and writes the frames to disk.
- Capture buffer is the storage area for frames that have been accepted. From here they are subsequently interpreted and displayed.
- Object database is the storage area for Expert information, such as network objects, symptoms, and diagnoses.
- Protocol interpreters identify the protocols nested within each frame and interpret their contents.
- Display filters determine which frames in the capture buffer are displayed.
- Frames that pass the display filters can be displayed in three views:
 - Summary
 - Detail
 - Hex with ASCII or EBCDIC

Output of the display can be saved to a file, sent to a printer, or imported into spreadsheets.




Figure 1-3. Overview of Sniffer analyzer functions.

The Analyzer's Menus and Controls

While you operate a Sniffer analyzer, you're always working from a SniffMaster Console. There are menus to operate the Console and menus to operate the individual Servers. From the SniffMaster Console menus, you activate the connection to one or more Servers.

What You See When You Connect to a Server

When you display a Server's screen, you are observing what the Server is doing at the moment. Note that the Server was operating before you connected to it and that it will continue operating after you disconnect from it. The Server can continue operating whether or not you choose to display its screen at your Console.

If the analysis Server has been collecting data unattended, you see the display that was last requested, updated to show the current situation. If the analysis Server has been started but given no specific instructions, you see its initial selection menu. If an earlier instruction exited from the Server's menus and returned to DOS, you see the DOS prompt.

The Server's Selection Menu

When the analysis Server is newly installed, or whenever it has just been reset or powered up, upon connection you'll see its *main selection menu*. From the selection menu, you can tell the Server to run the Sniffer *monitor* or the Sniffer *analyzers*. You may also select the file transfer utility or you may decide to configure the Server.

In Figure 1-4, the selection menu lists the major choices available to you. (The items in the menu depend on the configuration of your particular Sniffer Server.)




Figure 1-4. Server selection menu.

In each menu, one item is *highlighted*.¹ The lower portion of the panel contains a brief explanation of the highlighted entry. Pressing one of the cursor keys moves the highlight to another entry. To execute the entry that's highlighted, press Enter.



To start an analyzer

1. From the SniffMaster Console, connect to a Server. (For details regarding this step at the Console, see the *Distributed Sniffer System: Console Installation and Operations Manual*.)

Result: You see the Server's current screen. When the Server has been newly installed or has been reset, you'll see its main selection menu.

2. In the Server's main selection menu, move the highlight to the analyzer you want and press Enter.

Tree-Structure of the Analyzer's Menus

The Sniffer analysis Server is entirely controlled from menus presented on the screen of the SniffMaster Console. When you choose to run an analyzer, control passes immediately to the analyzer's main menu. An example (for an Ethernet analyzer) is shown in Figure 1-5.

1. We use "highlight" to mean the distinctive display of the selected item at the center of the screen. Depending on the type of display you're using, this may be in a contrasting color, or flashing, or in reverse video.




Figure 1-5. Main menu of the Sniffer analyzer (in this case, for Ethernet).

All Sniffer analyzer menus have the same structure. While details vary according to the network and protocol interpreter suites installed, the organization is the same. The entire menu is a tree, with its root (the main menu) to the left and its branches and leaves to the right. Only a part of the menu is visible at a time. Using the cursor keys, you move a window over the menu. Since the window is fixed on the screen, the menu appears to move under the stationary window.

When the menu is active, the screen shows three panels side-by-side. You control the center panel. Within that center panel, the center row is highlighted. That is your location on the menu. When you first start a Sniffer analyzer, the center panel lists the alternatives available from the root of the tree. Some alternatives appear above the highlight, some below it. Initially, the highlight is on Capture.

When you press the Cursor Up key, the highlight appears to move, and the item above Capture becomes highlighted. The highlight doesn't really move; instead, the entire center panel scrolls downward so that the (stationary) highlight is now on the row above. Alternatively, to jump directly up or down to a particular item, you may type the first letter of its name. The highlight jumps to the next item beginning with that letter.

The panel to the right shows choices in the submenu that are associated with the item highlighted in the center panel. As soon as you bring a different item to the center highlight, the entire right panel changes. The right panel always shows the submenu that goes with the item that's highlighted in the center (see Figure 1-6).




Figure 1-6. Scrolling over the tree-structured menu.



To work with the Sniffer analyzer menus:

1. Press one of the four arrow keys to move the highlight to the desired menu item. Note that any options associated with that item appear in the panel to the item's right. As you move the highlight, the relevant options are displayed, while those associated with another option disappear.
2. For options followed by a \blacktriangleleft symbol, pressing Enter when the option is highlighted either executes the command or it displays a listing or dialog box. From this display, you can either choose an option or enter information. In Figure 1-5, for example, pressing Enter when the **From <Ethernet>** option is highlighted results in a listing of files from which you can choose one as the capture source.
3. For options connected by a vertical bar (radio control), you can choose an option by moving the highlight to that option and pressing Spacebar. All other options connected by the bar are automatically disabled. In the main menu, for example, you can choose between capturing in **Classic mode** or in **Expert mode**.

Note: A radio control is so called because—like an old-fashioned radio control—selecting one option deselects all others.

4. For options preceded by \checkmark or \times symbols, you can enable or disable those options by moving the highlight to them and pressing Spacebar. Any such options are always either enabled (\checkmark) or disabled (\times); pressing Spacebar toggles between the two states.

Features of the Expert Sniffer Analyzer

Figure 1–7 outlines some of the features provided by the Expert analyzer.

Global statistics display	The Expert analyzer provides statistics detailing the percentage composition of network traffic by protocol family. You can tell, at a glance, how much of your network's traffic is TCP/IP, how much is DECnet, and so on.
Expert analysis during capture	The Expert analyzer can analyze network traffic and generate diagnostic messages while capturing frames from the network or a file. It can also capture traffic in Classic mode and then perform Expert analysis on the frames in the capture buffer later.
Explain screens	In the Expert window, you can pause capture and press F1 to show a detailed context-sensitive Explain screen pertaining to a symptom, diagnosis, or network object that is highlighted.
Multiple-layer analysis	The Expert analyzer can analyze problems at the Application, Connection, Network Station, and Data Link layers. On a token ring network, it can also analyze problems at the Medium Access Control (MAC) layer. You can specify that the analyzer perform Expert analysis on only those layers that interest you.
Expert triggers	You can specify one or more network events as trigger events. For example, you can configure the analyzer to stop capturing immediately after detecting a duplicate network address.
Network object filters	After capture, you can automatically filter out frames that are irrelevant to a particular symptom, diagnosis, or network object. After filtering, the analyzer displays only those frames related to the selected object, making it easy for you to concentrate on one problem at a time.
Display with symptoms	You can elect that the Classic data display window show a one-line description of any symptom associated with a frame.
Filter on symptoms	You can elect to display only those frames exhibiting symptoms.

Figure 1–7. New features of the Expert Sniffer analyzer.

The following chapters describe each of these features in detail.

CHAPTER TWO: GETTING FAMILIAR WITH THE EXPERT ANALYZER

2

Getting Familiar with the Expert Analyzer

Overview

This chapter defines key Expert analyzer concepts, gives instructions on how to start the Sniffer analyzer in Expert mode, and describes how to navigate among the Expert analyzer screen displays. The chapter gives you a “feel” for how the Expert analyzer operates, but does not discuss in detail the various features of the analyzer. The screens in this chapter are samples that illustrate the effects of various steps; you might see different messages on your analyzer as you follow the instructions.



Remember that the Sniffer analyzer can capture in either Expert or Classic mode. The manual will sometimes make reference to the *Expert analyzer*. It should be understood that this means the Sniffer analyzer capturing or displaying in its Expert mode.

This chapter assumes that you have successfully set up your Distributed Sniffer System, attached the analysis card to the network, and displayed the Main Selection Menu. If you have not done so, refer to the *Distributed Sniffer System: Console Installation and Operations Manual* and the *Distributed Sniffer System: Server Installation and Operations Manual* for information on getting started with the Distributed Sniffer System.

Expert Analyzer Terminology

When you start capture in Expert mode, the analyzer immediately begins constructing a database of *network objects* from the traffic it sees. The Expert analyzer uses its real-time protocol interpreters to learn about all the network stations, routing nodes, subnetworks, and connections related to the frames in the capture buffer. Using this information, the Expert analyzer can detect and alert you to potential problems that may be plaguing the network. The analyzer categorizes network problems as being either *symptoms* or *diagnoses*. Network objects, symptoms, and diagnoses are defined below.

About Network Objects

The amount of raw data on a given network can be quite immense. By performing multilevel protocol analysis on the frames that pass through its real-time protocol interpreters, the Expert analyzer extracts a small number of network objects from the huge amount of information it processes.

Network objects can be any of the following:

- A DLC station
- A network station
- A connection
- An application

- A subnetwork

The Expert analyzer learns about the network to which it is attached by intelligently correlating the various network objects it creates.

About Symptoms

When the Expert Sniffer analyzer detects an abnormal or unusual network event, it considers such an event a “symptom” indicative of a possible network problem. The analyzer displays a symptom message in one of the Expert windows.

After establishing an accurate network baseline, experienced users can alter the Expert thresholds to modify what constitutes a symptom. That is, you can specify that a certain network parameter (for example, the number of identical requests sent by an application) must exceed a certain limit before the analyzer displays a symptom message. (For information on setting thresholds, see “Setting Thresholds for Symptoms and Diagnoses” on page 3–13.)

About Diagnoses

In addition to revealing symptoms, the analyzer also uncovers “diagnoses.” There are two types of diagnoses:

- A diagnosis caused by several symptoms or recurrences of a symptom. As a symptom becomes more severe, the analyzer concludes that the symptom is not only an indicator but also a problem in itself.

For example, if network traffic increases suddenly over a short period of time, the Expert analyzer may alert you to a **LAN overload** symptom. If the **LAN overload** symptom persists over a longer period of time, the analyzer will display a **LAN overload** diagnosis. You can define thresholds for this type of diagnosis. For example, you could specify that a **LAN overload** diagnosis be generated whenever a **LAN overload** symptom is active for more than 20 percent of a minute.

- A diagnosis caused by a single network event that is itself considered to be problematic. The analyzer immediately assumes that the event represents a problem; there are no user-defined thresholds.

For example, when the Expert analyzer detects two stations with the same network address, it will immediately display the symptom and diagnosis **Duplicate network address**. There is no threshold to exceed.

About Alarms

An alarm is a message sent to a Console to make an entry in the Console’s Alarm Log. An Expert alarm is derived from a diagnosis in such a way that the alarm fields convey information about the condition and lead you to more detailed diagnosis information on the Server that generated the alarm. The alarm does not replace the Expert diagnosis display on the Server.

Each time a diagnosis is activated or reactivated after being closed, an alarm may be sent. The actual rate at which alarms from a diagnosis are sent is determined by the **Expert settings \ Throttle** setting. The default is one alarm per minute, which means for the Server to “send no more than one alarm per minute from a single diagnosis.” No alarm is generated when a diagnosis is either updated or closed.

Alarms sent by an Expert Server display the following information on the Console’s Alarm Log:

- **Alarm Priority:** Set as configured on the Expert Server.
- **Timestamp:** The most recent time the diagnosis on the Expert Server went into the active state.
- **Offender:** This field is not set by Expert. Because alarms generated by the Expert Server may have their origins in more than one node, it is not always possible to assign a single offender address to an alarm. Each alarm will contain relevant addresses within its descriptive text while the offender field remains empty.
- **Alarm Type Description:** the text that appears on the **Diagnosis Summary Screens** of the Expert Server.



The Expert analyzer uncovers symptoms and provides diagnoses. You draw a conclusion based on the information gathered by the analyzer and your knowledge of the network. Figure 2–1 summarizes the role of the Expert analyzer in solving network problems.




Figure 2–1. Role of the Expert analyzer in solving network problems.

Starting the Sniffer Analyzer in Expert Mode

Network General provides the Expert Sniffer Analyzer application with a set of default Expert thresholds that determines under what conditions the Expert analyzer will indicate various network problems. These default settings make the Expert analyzer a turnkey application requiring little or no configuration.

This section describes how to start the Expert analyzer capturing with the default settings. There are other ways to run the Expert analyzer; the following procedure is just one of them. Chapters 3–4 describe how to customize a capture session.



To start capturing and analyzing frames in Expert mode:

1. From the SniffMaster Console, connect to an analysis Server which has the Expert Sniffer Analyzer software loaded. For information on connecting to Servers from the SniffMaster Console, refer to the *Distributed Sniffer System: Console Installation and Operations Manual*.

Result: If connection is successful, the Main Selection Menu of the Sniffer Server appears. Figure 2–2 is similar but may not be identical to the Main Selection Menu on your Sniffer Server.

Note: The screens shown in this example are from an Ethernet analyzer. However, the procedure is the same for any other network type.




Figure 2–2. Main Selection Menu of a Sniffer Server.

2. Using the cursor keys, highlight the **Analyzer** menu option, and press Enter.

Result: The Sniffer analyzer application is loaded into RAM. When initialization completes, the system will display a screen similar to Figure 2–3.




Figure 2-3. Initialization screen of the Sniffer Network Analyzer.

3. Press any key.

Result: The Main Menu of the Sniffer analyzer appears. From this menu you can control all Classic and Expert analyzer functions. Figure 2-4 shows the Main Menu of the Sniffer analyzer.




Figure 2-4. Main Menu of the Sniffer analyzer (in this case, for Ethernet).

When you start the Sniffer analyzer from the Main Selection Menu, it automatically defaults to Expert capture mode. Note that the pointer in the far

right panel of Figure 2-4 points to **Expert mode** rather than **Classic**. For information on capturing in Classic mode, see the *Distributed Sniffer System: Analyzer Operations* manual.

4. Press F10 (**New Capture**) to start capture. Alternatively, you can use the cursor keys to highlight **Capture** and press Enter.

Result: The analyzer begins capture in Expert mode. The Expert Overview appears (Figure 2-5), displaying the results of Expert analysis as it captures frames.




Figure 2-5. Expert Overview window of the Expert analyzer.

Notice that in Figure 2-5 the Diagnoses column already indicates three diagnoses made at the Expert application layer. The Expert analyzer has uncovered problems on your network based on the symptoms and network objects it has detected. You can decide whether you want to see the diagnoses and further investigate the cause of these problems.



The analyzer categorizes network problems according to the Expert layer at which they occur. Expert layers have a rough parallel in the OSI model. For a complete description of how the Expert model of the network compares to the OSI model, refer to "Expert Layers and the OSI Model" on page 3-4.

About the Expert Window

Once capture in Expert mode begins, you are in the *Expert window*. The term *Expert window* refers to the set of available Expert screen displays in which you can view the results of Expert analysis. In general, the following types of Expert screen displays are available in the Expert window.

- Overview
- Summary

- Detail
- Statistics

These screens vary depending on many factors; this chapter describes several. For a complete description of all displays available in the Expert window, refer to Chapter 4, "Expert Analyzer Capture and Display." Note that the Expert window is the same whether you are actively capturing frames, or engaged in post-capture display routines.

Getting More Information About a Diagnosis

The Expert Overview shows the number of diagnoses per Expert layer but not the diagnoses themselves. You might want to view the list of diagnoses and elect to investigate one diagnosis at a time.



To obtain more information about a diagnosis:

1. In the Diagnoses column of the Expert Overview, use the cursor keys to highlight an Expert layer that exhibits at least one diagnosis. Press Enter.

Result: A list of diagnoses at the selected Expert layer appears. Figure 2–6 is an example of the Diagnosis Summary screen at the Application layer.

Note: If no diagnoses have been detected at the highlighted level, nothing will happen when you press Enter. If there are diagnoses at the highlighted layer, the help line at the bottom of the capture display will change to read, "ENTER to see diagnoses."




Figure 2–6. Application Diagnosis Summary window. This view shows all diagnoses at the Application layer.

- You can obtain more detailed information on any diagnosis. Use the cursor keys to highlight a diagnosis and press Enter to display a Diagnosis Detail screen, which contains further information regarding the selected diagnosis.

For example, in Figure 2-6, the Diagnosis Summary view shows that the Expert analyzer has diagnosed the server BIZ-ONE as being slow. In Figure 2-7, the Diagnosis Detail screen shows which stations received a slow response from BIZ-ONE.




Figure 2-7. Application Diagnosis Detail screen.

The Diagnosis Detail screen in Figure 2-7 shows which nodes received a slow response from the server BIZ-ONE; however, it does not describe the network conditions that led the analyzer to arrive at this diagnosis or how you might go about correcting the problem. To get more information about this diagnosis, you may want to invoke the Expert analyzer's Explain screen.

Getting Context-Sensitive Explain Messages

The Expert analyzer displays concise diagnostic and symptom windows. If you do not fully understand the nature of the problem indicated by an Expert detail or summary window, or would like the opinion of the Expert analyzer, invoke the context-sensitive Explain message. Such a message tells you why the analyzer "thinks" that a problem exists, what other areas you might want to examine to determine the seriousness of the problem, and what thresholds affect the current symptom or diagnosis.

Explain messages are always available in the Expert window, whether during capture (if paused) or during post-capture display routines. You can pause capture at any time and invoke an Explain message. Do not confuse Explain messages with help messages, which are invoked by the same function key.

While viewing an Explain message, you can invoke Classic help “on top” of the Explain message. Help messages are also available anywhere in the analyzer’s menus by pressing the F1 key.

The help messages serve as reminders about items in the analyzer’s menus. Explain messages provide further information that is not in the current Expert view but may be important for your investigation of network problems. You can tell which type of message will appear by examining the dynamic function key labels at the bottom of the display. In Figure 2–7, F1 is labeled as **Explain**, and will display an Explain message when pressed, rather than a help message.



To display an Explain message during capture:

1. While in the Expert window, press F9 (**Pause**) to stop capture temporarily.
2. Press F1 (**Explain**).

Result: The Expert analyzer displays a context-sensitive Explain message related to the current Expert view or highlighted item.

Note: Classic help messages are available on top of Explain messages. The key label reading “Help” at the bottom of Figure 2–8 indicates this.



During post-capture display, Explain messages are always available in the Expert window by pressing F1.

Figure 2–8 shows the Explain message for the **Slow server** diagnosis from the previous example. Notice that the Application Diagnosis Detail view from Figure 2–7 is still visible behind the Explain screen.

Notice that
Classic help
messages are
available on top
of Explain
messages.




Figure 2–8. Explain screen for the diagnosis, *Slow server*.

Explain messages vary according to the context. For example, if the symptom message highlighted is “Many routers to remote network,” the Explain message

shows you specifically the connections among the network station and the routers. The network addresses and the configuration shown in the message can be different each time depending on the node and routers involved. Similarly, when you display a detail window for a diagnosis or symptom, the exact Explain message depends on the information in the detail window.

Getting More Information About Symptoms and Network Objects

You display the Expert analyzer's database of symptoms and network objects just as you would display information about diagnoses. From the Expert Overview, use the cursor keys to highlight the appropriate layer in the Objects/Symptoms column and press Enter. Figure 2-9 shows the Expert Overview with the Objects/Symptoms column highlighted at the Connections layer.



When you move the highlight to the Objects/Symptoms column, the highlight automatically expands to cover both columns. This indicates that you cannot view objects without viewing symptoms, and vice-versa.

You cannot view network objects without viewing symptoms.




Figure 2-9. Expert Overview with Objects/Symptoms column highlighted at Connections layer.

A list of network objects detected at the selected Expert layer appears. The list includes a description of the last symptom (if any) associated with each network object. This list is called a Summary window. Figure 2-10 is an example of the Summary window at the Connection layer.




Figure 2-10. Connection Summary window.

To get detailed information about a particular connection or symptom, use the cursor keys to highlight a connection in the Summary window and press Enter. A detailed display appears as shown in Figure 2-11. The Detail window provides information such as the network addresses of the two endpoints of a connection, the protocol used, and any symptoms associated with the particular connection, network station, or DLC station.

You can use the cursor keys to scroll through the Detail windows for any of the 15 connections detected by the analyzer.




Figure 2-11. Connection Detail window. This window provides detailed information about a specific connection.

Notice that at the bottom of the Connection Detail border in Figure 2-11, the display reads, "11 of 15." From the Detail window, you can use the cursor keys to page through the Detail windows for any of the 15 connections detected by the Expert analyzer. Alternatively, you can press Enter again, and see a Statistics window for a particular connection, network station, or DLC station. Figure 2-12 shows a typical Statistics window at the Connection layer.

The exact information provided in the Statistics window depends both on the Expert layer at which it is displayed and the protocol involved. For example, at the Connections layer, the Statistics window shows the number of requests, number of replies, total bytes, and average frame length on a particular connection. The Statistics window at the Applications layer, however, includes statistics for application requests and average file transfer performance. In general, the Statistics window will quantify and describe network traffic to or from a highlighted station.




Figure 2-12. Connection Statistics screen.

For more information on the various Expert displays available during capture, refer to Chapter 4, "Expert Analyzer Capture and Display."

Protocols Available for Expert Analysis

The Expert Sniffer analyzer can process frames on an Ethernet network segment, a token ring, or a WAN link. The protocol suites that the Expert analyzer interprets as of the date of this manual include the following:

Protocol Family	Constituent Protocols
TCP/IP	IP, TCP, NFS, RPC, TELNET, FTP, ARP, SNMP, ICMP, RIP, EGP, SMB, UDP, GGP, IGRP, DNS, X-Windows
XNS	XNS, PEP, SPP, NCP, SMB
Novell	PEP, SPX, RIP, SAP, NetBIOS, NetWare
DECnet	DAP, NSP, DRP, LAT, SMB
WAN/Synchronous	Frame Relay, X.25, HDLC, IGRP (Cisco), Bridge/Router (various proprietary versions of HDLC)

Figure 2–13. Protocols currently available for Expert analysis.



The Expert analyzer can perform Classic interpretation on many protocols for which Expert analysis is unavailable. The protocol suites on which your analyzer can perform Expert analysis may vary depending on the topologies installed. The procedure below shows you how to determine on which protocols your analyzer can perform Expert analysis.



To view the protocols on which your analyzer can perform Expert analysis:

1. Display the Main Menu of the Sniffer analyzer.
2. Use the cursor keys to move to the **Display \ Filters \ Protocol** menu.
Result: The menu in Figure 2–14 appears.
3. Notice that some of the protocols listed in the right panel are followed by an asterisk. The analyzer can perform Expert analysis on those protocols followed by an asterisk.

The analyzer can perform Expert analysis on those protocols marked with an asterisk.




Figure 2-14. The protocols on which the analyzer can perform Expert analysis.

CHAPTER THREE: EXPERT ANALYZER OPTIONS **3**

Expert Analyzer Options

Overview

This chapter explains the network layering scheme the Expert analyzer uses to categorize network problems and describes various precapture Expert options, including:

- How to specify TCP/IP subnet masks using the Expert analyzer's configuration function. You must be careful to configure the Expert analyzer with the subnet mask appropriate to the network it is analyzing. Configuring the Expert analyzer with an incorrect subnet mask can result in spurious symptoms and diagnoses in a TCP/IP environment.
- How to specify common Trustee names that should be excluded from the Expert analyzer's name search in a Novell environment.
- How to set Expert thresholds: You can adjust the Expert thresholds to control when the analyzer reveals symptoms and diagnoses.
- How to set alarm priorities to control the types of alarms sent to the Console.
- How to set a delay for reporting lower level alarms to the Console.
- How to set a delay on sending an alarm about the same diagnosis to the Console.
- How to set Expert triggers: Expert triggers allow you to specify a particular diagnosis as a trigger event, anchoring frames that interest you in the capture buffer.
- How to use the **Freeze/Reuse Allocation** and **Highest layer** options. These options help you to use memory and processor time optimally depending on your network analysis needs.

The chapter also describes how the analyzer learns the symbolic names of network entities by extracting relevant information from captured packets. When the analyzer learns a symbolic name, it will substitute that name for the address in the Expert displays. Several "tricks" to speed this process are discussed at the end of this chapter.

Expert Layers and the OSI Model

The Expert analyzer categorizes network problems according to the Expert layer at which they occur. During capture, the Expert analyzer uses its real-time protocol interpreters to map the information embedded in each frame onto its own model of network layers.



The network layering structure on the Expert analyzer is similar to the OSI model. However, the two schemes do not always exhibit a one-to-one mapping. Figure 3-1 explains what each Expert layer means and how it corresponds to the layers in the OSI model.




Figure 3–1. How the OSI model of network layers relates to the Expert's model.

The Expert analyzer's model of network layers is shown in the Expert Overview, illustrated in Figure 3-2. From this window, you can view subdisplays associated with network objects, symptoms, and diagnoses detected at the various Expert layers. For more information on the displays available in the Expert window, see Chapter 4, "Expert Analyzer Capture and Display."

Note: In addition to the four Expert layers, the Expert Overview also tallies Global Symptoms and Subnet Pairs. Global Symptoms are those symptoms which do not reside at any particular layer, such as Broadcast Storms. Subnet pairs provides information on all communicating subnets the Expert analyzer detects. These displays are described further in Chapter 4, "Expert Analyzer Capture and Display."




Figure 3-2. The Diagnosis Overview window. The four Expert layers are displayed at left, along with Subnet Pairs and Global Symptoms.

The Expert layering structure is also used to group thresholds for symptoms and diagnoses in the **Expert settings** menu. For more information on Expert thresholds, see "Setting Thresholds for Symptoms and Diagnoses" on page 3-13.

Configuring the Expert Analyzer

To ensure effective analysis of the network, two important options should be configured before capture begins. Whether or not you need to configure these options depends upon the protocol environment the Expert analyzer will observe.

- | | |
|-----------------|---|
| • Subnet Masks | Must be configured for a TCP/IP environment. |
| • Trustee Names | Can be configured for a Novell environment. |

To configure these items, use the Expert analyzer's configuration function, found in the **Expert settings \ Configuration** menu. The changes made with the configuration function are saved to the appropriate STARTUP.xxV file (where xx=EN for Ethernet, TR for token ring, or SY for WAN/Synchronous). For more information on the analyzer's use of files, see the *Distributed Sniffer System: Analyzer Operations Manual*.

Figure 3-3 shows the Expert analyzer's **Expert settings \ Configuration** menu.




Figure 3-3. Configuration menu of the Expert Sniffer analyzer.

Setting Subnet Masks

A traditional standard of TCP/IP subnet masks exists, which reserves specific bits within an IP network address for the subnet mask, depending on the class of address. The Expert analyzer comes with default subnet mask settings for each class of IP address:

<u>IP ADDRESS</u>	<u>EXPERT DEFAULT SUBNET MASK</u>
Class A	[255.255.0.0]

Class B [255.255.255.0]

Class C [255.255.255.0]



Networks may use non-traditional subnet masks. If the Expert analyzer is attached to a network segment which uses non-traditional subnet masks, it is possible that the analyzer will register spurious network objects and diagnoses. This happens because the analyzer expects address information at a location within the address field other than where it actually is.

Example: Using an Incorrect Subnet Mask

Figure 3-4 shows two different legal Class A IP broadcast addresses.




Figure 3-4. Two different Class A IP broadcast addresses.

The first address represents a traditional Class A IP broadcast address. The first field of the address is the network address, the second field is the subnet address, and the last two fields are the host address (in this case, broadcast). The Expert analyzer will correctly analyze this frame, using its default Class A subnet mask.

The second address shows a non-traditional Class A IP broadcast address. Instead of limiting the subnet address to the second field, this address uses the second and third fields as the subnet address, and only the fourth field as the host address (still broadcast). Using the default Class A subnet mask, the Expert analyzer would mistakenly interpret the subnet address as 1. The Expert analyzer would fail to register the broadcast address, and would create a spurious network object for the host address 2.255.



It is essential that you enter the IP network address and appropriate subnet mask for the networks from which the Expert analyzer will see frames. Failure to do so can result in false network objects and diagnoses.

The Expert analyzer's configuration function allows you to add, delete, or change user-configured subnet masks. You can also edit or delete the analyzer's default subnet masks.



To add a specific IP network address and associated subnet mask:

1. Move to the Expert settings \ Configuration \ Set subnet masks option.
2. Press Enter. The box in Figure 3-5 appears.

IP Network Address	Subnet Mask
<New subnet mask>	
<ClassA>	[255.255.0.0]
<ClassB>	[255.255.255.0]
<ClassC>	[255.255.255.0]

Use ↓ and ↑ then press ENTER, or ESC to return.

Figure 3-5. Set Subnet Masks box.

3. Highlight <New subnet mask>, and press Enter.
Note: If you have already entered the maximum number of addresses, the analyzer will indicate this. You will need to delete one of the existing addresses first. See the next procedure, on page 3-10.
4. The box in Figure 3-6 appears. Type in the new IP network address in the format [n.n.n.n], where each n is less than 256, and press Enter.
Note: The brackets are optional. However, if you include one bracket, you must include both.

SET SUBNET MASKS

Enter the new IP net address in the format [n.n.n.n], where each n < 256

Press ESC to abort

Figure 3-6. Entering the IP network address.

5. After you press Enter, a box (Figure 3-7) appears in which you enter the subnet mask associated with the IP network address you just entered. Enter the subnet mask in the form [n.n.n.n], and press Enter.

Note: Depending on the class IP network address you entered, the analyzer may supply the first fields of the subnet mask for you. The analyzer will not allow you to enter an illegal network address/subnet mask pair.

SET SUBNET MASKS

Enter the new IP net address in the format [n.n.n.n], where each n < 256:

[149.32.0.0]

Enter the new subnet mask in the format [n.n.n.n], where each n < 256:

[255.255.192.0]

Press ESC to abort

Figure 3-7. Entering the associated subnet mask.

- After you have entered the IP network address and subnet mask, the analyzer adds the new entries to the list in Figure 3-8.

SET SUBNET MASKS

IP Address	Subnet Mask
<New subnet mask>	
<ClassA>	[255.255.0.0]
<ClassB>	[255.255.255.0]
<ClassC>	[255.255.255.0]
[149.32.0.0]	[255.255.192.0]

Use ↓ and ↑ then press ENTER, or ESC to return.

Figure 3-8. List of defined IP network addresses and subnet masks.

You can also modify or delete existing IP network addresses and subnet masks.



To modify or delete existing IP network addresses and subnet masks:

- Move to the **Expert settings \ Configuration \ Set subnet masks** option and press Enter. The list in Figure 3-5 appears.
- Highlight the IP network address and associated subnet mask you want to modify or delete and press Enter.

The box in Figure 3-9 appears.

SET SUBNET MASKS

Enter the new IP net address in the format [n.n.n.n], where each n < 256:

[149.32.0.0]

Press DEL to delete it.

Press ESC to leave it unchanged.

Use ENTER to accept, or ESC to return.

Figure 3-9. Modifying or deleting the IP address.

- Do you want to delete this IP network address?

- If so, press the Delete key. The analyzer posts a warning box and then deletes both the IP address and the associated subnet mask.
 - If not, either press ESC to return to the Set Subnet Mask box, or modify the IP network address and subnet mask using the cursor keys.
4. Once you have deleted or modified the IP network address and subnet mask pair, the analyzer updates the list in Figure 3–8.

As the Expert analyzer captures TCP/IP frames, it will first check its list of user-configured IP network addresses and subnet masks and try to associate the proper address with the incoming frames. If the analyzer does not find the appropriate address in its list of addresses, it will apply the default subnet mask appropriate to the class of address it is currently analyzing.



Changes made by the Expert analyzer configuration function become active immediately. There is no need to restart the application. Additionally, any changes made by the Expert analyzer configuration function are automatically saved to the STARTUP.xxV file when you exit the analyzer. The next time the analyzer starts, it will start with the changes you made intact.

Setting Trustee Names

One of the central functions of the Expert analyzer is its ability to learn symbolic names by extracting information from the packets that pass through its real-time protocol interpreters. The Expert analyzer does this automatically, substituting symbolic names for addresses in the Expert displays as it learns them.

Because the Novell environment often uses trustee names to refer to groups of users during bindery requests, the analyzer may incorrectly substitute a name for a network address. For example, suppose the user Agnes is a member of the trustee group CCMAIL. When Agnes requests access to her CCMAIL, the Novell software will first check the bindery for the trustee name CCMAIL and then check if Agnes is a valid member of this group. During the course of this transaction, the analyzer may associate the trustee name CCMAIL with Agnes' station address.

To prevent inaccurate name-address assignment from happening, you can use the Expert analyzer's configuration function to specify trustee names that will be excluded from the Novell name search.



To specify trustee names to be excluded from the Novell name search:

1. Move to the **Expert settings \ Configuration \ Set trustee names** menu option.
2. Press Enter. The box in Figure 3–10 appears.




Figure 3-10. Set Trustee Names box

3. Highlight <New trustee name> and press Enter. The box in Figure 3-11 appears.

Note: If the maximum number of trustee names has already been entered, a pop-up box will inform you of this. You will need to delete an existing trustee name in order to add a new one.




Figure 3-11. Entering a new Trustee Name.

4. Enter the trustee name which you want the Expert analyzer to ignore during the Novell name search. The following common names are provided by default:
 - CCMail
 - SUPERVISOR
5. Press Enter. After the name has been entered, it will appear in the Set Trustee Names box in Figure 3-10.



To delete or modify trustee names:

1. Use the procedure above to go to the Set Trustee Names box.
2. In the list that appears, highlight the name you want to modify or delete. Press Enter.
3. In the box that appears, you can press the Delete key to delete a trustee name or modify a name using the keyboard.



Changes made by the Expert analyzer configuration function become active immediately. There is no need to restart the application. Additionally, any changes made by the Expert analyzer configuration function are automatically saved to the STARTUP.xxV file when you exit the analyzer. The next time the analyzer starts, it will start with the changes you made intact.

Setting Thresholds for Symptoms and Diagnoses

The thresholds in the analyzer's **Expert settings\Thresholds** menu determine whether the analyzer generates a symptom or diagnosis message based on a given network event. This section describes how to set the Expert thresholds.



The default thresholds supplied with the Expert analyzer have been carefully calculated to ensure accurate and informative symptom and diagnosis detection. Before changing any of the thresholds, make sure you understand:

- How the Expert thresholds interact with one another to determine symptom and diagnosis detection. This section describes each threshold, and the symptoms and diagnoses associated with them.
- Your network. The final responsibility for creating an informative set of Expert thresholds lies with you. You should not change any of the Expert thresholds until you have established a network baseline and are sure the new values are appropriate for your particular network.

For example, after capturing with the default Expert thresholds you may find that the analyzer is registering repeated **LAN overload** diagnoses. Upon closer examination you find that the amount of traffic on this particular segment was, in fact, quite normal for your particular network. If that is the case, you may want to increase the **LAN overload** threshold to a higher rate of traffic, ensuring that the analyzer reveals a diagnosis only when the amount of traffic on this segment presents a problem.

Note: You can always use the **Use defaults** command in the Options menu to reset all the Expert thresholds to their original values. Be aware that the **Use defaults** command will reset all settings in the analyzer's menus to their original values. For more information on using the **Use defaults** command, refer to the *Sniffer Network Analyzer Operations* manual.



To set an Expert threshold:

1. From the Main Menu, use the cursor keys to move to the **Expert settings\Thresholds** menu.
2. Move the highlight to the Expert layer associated with the threshold you want to change.

Result: The right panel displays a list of thresholds associated with the highlighted layer, as shown for the Connection layer in Figure 3-12.




Figure 3-12. The Expert settings \ Thresholds \ Connection layer menu.

3. Use the cursor keys to move the highlight to the desired threshold. Press Enter.

Result: A dialog box opens.

4. Type the new value for the desired threshold and press Enter.

The newly defined threshold takes effect the next time you do either of the following:

- Start capture in Expert mode
- Display the frames in the capture buffer



When you display frames after changing an Expert threshold, the analyzer automatically performs Expert analysis on all frames in the capture buffer, generating symptom and diagnosis messages according to the new Expert thresholds. Previous analysis results are lost. For more information on this concept, see "Effects of Changing Expert Thresholds" on page 3-30.

Symptom and Diagnosis Thresholds at Each Expert Layer

This section describes the meaning of each user-defined Expert threshold and how it affects symptom and diagnosis detection. Depending on the topologies you ordered from the factory, the exact thresholds available on your analyzer may be a subset of those described here. Figure 3–13 shows the available thresholds at each Expert layer. The thresholds are described in the same order in which they appear in the analyzer's menus.

How the Expert Thresholds Interact

Many of the Expert thresholds work in tandem to determine symptom and diagnosis detection. For example, at the Data Link layer, the analyzer displays a symptom message when network traffic exceeds the Expert threshold, **LAN overload** (by default, 30 percent of available bandwidth). In each minute, if network traffic exceeds the **LAN overload** threshold for more than 20 percent of the time (defined by the threshold **LAN overload %**), the analyzer will diagnose that the network is overloaded.

In other words, one threshold (**LAN overload**) specifies when a symptom is detected. The second threshold, usually specified as a percentage (in this case, **LAN overload %**), specifies at what point a symptom becomes problematic enough to be considered a diagnosis. Figure 3–13 indicates pairs of thresholds that work in this manner by displaying them side by side.

Expert Layer	Expert Threshold	Related Expert Threshold
Application Layer	Minimum Application Requests	
	Response Time	Slow Response Percentage
	Filter Time	Denied Count
	Filter Time	Loop Percentage
	Denied Request Percentage	
	Local Transfer/Remote Transfer	Slow File Percentage
Connection Layer	No Responses	
	Retransmission Percentage	
	Zero Window	
	Idle Timer	
	Fast Retransmission	
	TCP Keep Alive	
	DEC Keep Alive	
Network Layer	Multiple Routers	
	DEC Hello	
	Duplicate Percentage	
DLC Station Layer	LAN Overload	LAN Overload Percentage
	Broadcast Symptom	Broadcast Diagnosis
	Physical Errors	
	WAN Overload*	WAN Overload Timer*
	WAN Underload*	WAN Underload Timer*
	Congestion Percentage*	
MAC Layer (Token Ring)	Ring Entries	
	Receiver Congestion	
	Station Removed	
	Ring Errors	
	Ring Purge Symptom	Ring Purge Diagnosis

* WAN/Synchronous (Sniffer Internetwork Analyzer) only.

Figure 3-13. Expert thresholds available at each Expert layer.

Application Thresholds

The Expert thresholds at the Expert Application layer are related to the quality of connections and file transfers. The thresholds are described in the same order as they appear in Figure 3–13.

Minimum Application Requests

The **Min appl req** threshold specifies the minimum number of application requests that must have been sent by a specific application before the analyzer will display an Application layer diagnosis related to that application.

Suppose **Min appl req** is set to 100 (the default). If Station A has sent Station B 25 file requests and a file retransmission occurs, the analyzer will not generate the **File retransmission** diagnosis (or any other diagnosis) because there have not yet been 100 application requests between Station A and Station B. The **Min appl req** threshold helps ensure that the Expert analyzer bases a symptom or diagnosis on reliable statistics, not a few isolated instances of abnormal network activities at the Application layer.

Possible values range from 0 to 999; default value is 100.

Response Time

The threshold **Response time** specifies the time limit within which a Server should respond to an application request. If the Server sends a response after the timer expires, the analyzer considers the response “slow.” This threshold alone does not generate a symptom or diagnosis. However, if the ratio of slow responses to normal responses exceeds the threshold set by **Slow resp %**, the analyzer generates the diagnosis **Slow server**.

Response time measures the time (in milliseconds) between when an application request is sent and a response is received.

Possible values range from 0 to 999 milliseconds; default value is 100 milliseconds.

Slow Response Percentage

The **Slow Response Percentage** threshold determines whether the analyzer considers a server slow in responding to application requests. The diagnosis is **Slow server**.

The value is the ratio between slow responses and normal responses in percentage. This percentage is calculated by the following expression:

$$\text{Number of slow responses} / \text{Number of normal responses} \times 100$$

A response is considered slow if the response time exceeds the value defined by the threshold **Response time**.

Possible values for the **Response time %** threshold range from 0 to 100 percent; default value is 20 percent.

Filter Time

The **Filter time** threshold specifies (in seconds) the maximum time interval during which the analyzer counts repeated requests and denied requests. Each time an application process sends out a request, the analyzer resets the filter timer. If the same request is sent out again before the filter timer expires, the second request is considered a repeated request. For example, if the **Filter time** threshold is set to five seconds and an application sends out the same request one minute after the first one, the second request is not considered a repeated request.

The **Filter time** threshold also determines whether the analyzer counts a given denied request. For example, some printers poll servers at regular intervals (such as once every five seconds) to find out if there are print jobs in their queues. If there are no print jobs, the printer's request is denied. Because this is a regular occurrence, you should set **Filter time** low enough so that the analyzer will not register normal network activity (a server denying a printer's request) as excessive denied requests. In this example, if **Filter time** were set less than five seconds, the repeated server polls by the printer would not be counted as denied requests.

The **Filter time** threshold by itself does not result in a diagnosis. However, in tandem with the **Loop %** threshold (see below), it does affect when the diagnosis, "Too many loops (*number of loops*) by *station name* to *station name*," appears.

Additionally, in tandem with the **Denied count** and the **Denied request percentage** threshold, the **Filter time** threshold controls when the symptom, "*x* denied requests," and the diagnosis, "Excessive denied requests," appear.

Possible values for the **Filter time** threshold range from 0 to 999 seconds; default is 1 second.

Denied Count

The **Denied count** threshold specifies the quantity of denied requests for a given application at which the analyzer will generate the symptom "*x* denied requests." Notice that the analyzer defines denied requests using the **Filter time** threshold. That is, a request is only counted as denied if it is denied within the time range specified by the **Filter time** threshold (see above for details).

For example, suppose the following thresholds were set:

- **Filter time** = 1 second
- **Denied count** = 2

In this case, the analyzer will only count a request as denied if it occurs within one second from the last denied request. Once the analyzer detects more than two denied requests for a given application, it generates the "*x* denied requests" symptom.

Possible values for the Denied count threshold range from 1 to 100. The default is 2.

Loop Percentage

While the threshold **Filter time** specifies at what point the analyzer considers an application process request to be a repeated request, the threshold **Loop %** specifies at what point the quantity of these repeated requests presents a problem.

The value of **Loop %** is the ratio between repeated requests and normal requests. A repeated request is one that is sent out even though the proper response to the previous request has already been seen by the analyzer. The analyzer does not count certain repeated requests. For example, if a repeated request is sent after the **Filter time** threshold expires, the analyzer “forgets” the previous request and does not consider this one a repeated request. A normal request is any request that is not deemed repeated by the analyzer.

Note: Repeated requests exclude the read or write requests involved in file transfers.

The analyzer calculates the value for **Loop %** by the following equation:

$$\text{Number of Repeated Requests} / \text{Number of Normal Requests} \times 100$$

The diagnosis is, “Too many loops (*number of loops*) by *station name* to *station name*.” The analyzer displays separate diagnosis messages for different connections, even if the connections originate from the same station. For example, if Station A is sending a high number of repeated requests to both Server 1 and Server 2, the following diagnoses appear:

Too many loops (68) by Station A to Server 1
Too many loops (70) by Station A to Server 2

Possible values for the **Loop %** threshold range from 0 to 100 percent; default value is 30 percent.

Denied Request Percentage

The **Denied req %** threshold specifies the maximum acceptable percentage of denied versus successful application requests for a given application. If this percentage is exceeded, the analyzer reveals the diagnosis, **Excessive requests denied from *station name***.

The value for **Denied req %** is calculated as follows:

$$\text{Number of denied requests} / \text{Number of successful requests} \times 100$$

Note that the analyzer uses the **Filter time** threshold to determine whether it should consider a request as denied or not. See the **Filter time** section on page 3–18.

Possible values range from 0 to 100 percent; the default is 20 percent.

Local Transfer/ Remote Transfer

The **Local Transfer** and **Remote Transfer** thresholds specify the minimum acceptable rate of data transfer for a file transfer between two stations. If the rate

of a given file transfer falls below the specified minimum data rate, the analyzer will reveal the symptom **Low Throughput**.

Meaning:

- **Local transfer**— Speed of file transfer between two stations on the same subnetwork. Possible values range from 0 to 999 Kbytes/s; default is 200 Kbytes/s.
- **Remote transfer**— Speed of file transfer between two stations separated by at least one bridge/router (that is, with a hop count greater than or equal to one). Possible values range from 0 to 999 Kbytes/s; default is 50 Kbytes/s.

Note: **Local transfer** and **Remote transfer** are separate thresholds. The analyzer applies two different minimum transfer rates depending on whether a given connection is defined as remote or local. Local transfers have hop counts of zero. Remote transfers have hop counts of one or more. Normally, file transfer becomes slower as the hop count increases, so you should set the **Local transfer** threshold to a greater value than **Remote transfer**.

The frequency of slow file transfers between two stations affects when the analyzer displays the diagnosis, **Slow File Transfer**. See the definition for **Slow File Percentage**, below.

Slow File Percentage

The **Slow File Percentage** threshold specifies the maximum percentage of slow file transfers versus normal file transfers for a given connection. If the specified ratio is exceeded, the analyzer diagnoses that the file transfer process between two stations is too slow. The diagnosis is **Slow File Transfer**.

Slow File Percentage is calculated as the ratio between slow file transfers and normal file transfers. Slow file transfers are those whose rates are less than the **Local transfer** or **Remote transfer** thresholds. Normal file transfers are those whose rate exceeds the minimum acceptable data rate specified by the **Local transfer** or **Remote transfer** thresholds. **Slow File Percentage** is calculated by the following equation:

$$\text{Number of slow file transfers} / \text{Number of normal file transfers} \times 100$$

Note: The analyzer will make a diagnosis only after 10 file transfers have taken place.

Possible values range from 0 to 100 percent; default value is 30 percent.

File Overlap/Retransmissions

Note: The **Slow file percentage** threshold also specifies the maximum percentage of file retransmissions versus normal file transfers for a given connection. If the specified ratio is exceeded, the analyzer diagnoses that there are too many retransmissions on the connection. The diagnosis is **File overlap/retransmissions**.

Connection Thresholds

The Expert thresholds in this section refer to specific connections detected at the Expert Connection layer. The thresholds are organized in the same order they are found in the **Expert settings \ Thresholds \ Connection** menu.

No Responses

The **No Responses** threshold specifies the number of consecutive retransmissions in the same direction on a single connection without response that implies a connection is broken. For example, if **No responses** has been set to 3 (the default), the analyzer will diagnose that a connection is lost after a packet has been retransmitted 3 times. The analyzer will generate both a diagnosis and a symptom message. The message is **Non-responsive station: Station name**.

Possible values range from 0 to 999; default value is 3.

Retransmission Percentage

The **Retransmission Percentage** threshold specifies the maximum acceptable percentage of retransmitted packets versus successfully transmitted packets in the same direction on a single connection at the Connection layer. If this percentage is exceeded, the analyzer generates the diagnosis **Retransmissions**. The value for **Retrans %** is calculated as follows:

$$\text{Number of retransmitted packets} / \text{Number of non-retransmitted packets} \times 100$$

Possible values range from 0 to 100 percent; default value is 10 percent.

Zero Window

The **Zero Window** threshold specifies the duration of a zero window before the analyzer displays the symptom message, **Zero window for x seconds**. A network station receiving data notifies the sender of its buffer size (the window size). A zero window indicates that the receiver's buffer is full. Transmission to this station stops until it sends a non-zero window advertisement.

The threshold value is the time between a zero window advertisement and the subsequent non-zero window advertisement.

Possible values range from 0 to 999 seconds; default is 5 seconds.

Idle Timer

The **Idle Timer** threshold specifies in minutes the maximum time a connection at the Expert Connection layer can remain idle. A connection is considered idle if no packets are sent in either direction. If the idle time of a given connection exceeds the **Idle Timer** value, the analyzer generates the symptom **Idle more than x minutes**.

Possible values range from 0 to 999 minutes; default value is 10 minutes.

Fast Retransmission

The **Fast Retransmission** threshold specifies the minimum time between packet retransmissions. If a station retransmits a packet before the analyzer's **Fast retrans** timer has expired, the analyzer generates the symptom **Retransmission with too short timer**.

Possible values range from 0 to 999 milliseconds; default value is 100 milliseconds.

TCP Keep Alive

The **TCP Keep Alive** threshold is used to specify whether a retransmitted frame represents a real retransmission or a "keep alive" frame. For example, if **TCP keep alv** is set to 10 seconds, a frame retransmitted less than 10 seconds after its first transmission is not considered a TCP keep alive.

Possible values range from 0 to 999 seconds; default is 25 seconds.

DEC Keep Alive

The **DEC Keep Alive** threshold is used to specify whether a retransmitted frame represents a real retransmission or a "keep alive" frame. For example, if **DEC keep alv** is set to 10 seconds, a frame retransmitted more than 10 seconds after its first transmission is considered a DEC keep alive.

Possible values range from 0 to 999 seconds; default is 5 seconds.

Network Station Thresholds

The Expert thresholds in this section refer to symptoms and diagnoses at the Network layer. Symptoms and diagnoses at the Network layer are associated with network addressing and routing problems. The thresholds are organized as they are found in the **Expert settings \ Thresholds \ Network Station** menu.

Multiple Routers

The **Multiple Routers** threshold specifies the maximum number of local routers through which local traffic can be routed to a remote station. If there are more routers than specified, the analyzer displays the diagnosis **Multiple routers to station** *station name*.

Possible values range from 0 to 10; default is 3.

DEC Hello

If the DECnet hello timer is less than the value specified for **DEC hello**, the analyzer will trigger the symptom **Small hello time**.

DECnet uses hello packets for neighbor identification. In a DECnet environment, a station needs to know of at least one intermediate system (a router) to which it can hand off packets with unknown destinations. Hello

packets let a station find this default intermediate system. The DECnet hello timer controls how often hello packets are sent. Because hello packets contribute to network overhead, the hello timer should be set as high as possible, depending on the stability of the environment. A short hello timer can lead to high network traffic and routing problems.

Possible values range from 0 to 999 seconds; default is 10 seconds.

Duplicate Percentage

The Expert analyzer uses several different algorithms to detect the presence of duplicate network addresses on the network. The **Duplicate address percentage** threshold allows you to fine-tune the algorithm specific to the DECnet environment.

In the DECnet environment, stations are required to send a hello packet at a specified time interval (for an explanation of the DEC Hello packet, see, "DEC Hello," above). The analyzer uses these hello packets to detect duplicate network addresses. Because the time between hello packets for a given station should theoretically remain a constant, the analyzer will generate a **Duplicate net address** diagnosis if it detects a discrepancy in the intervals for hello packets sent from a single network address. Because of fluctuations in the intervals of hello packets with the same network address, the analyzer assumes that two different stations are sending hello packets with the same network address.

Theoretically, the interval between hello packets for a given network station should remain constant. However, due to various network irregularities, the interval tends to vary within a small range of the specified interval. As capture proceeds, the analyzer "learns" the usual interval for hello packets from a given station. The **Duplicate address percentage** threshold specifies the maximum percentage discrepancy between the usual DEC hello interval as learned by the analyzer and the measured DEC hello interval of a given frame. Figure 3-14 illustrates the concept of the **Duplicate address percentage** threshold.




Figure 3-14. How the analyzer calculates the value of Duplicate address percentage.

If your network is very busy, or has a lot of "noise," you may want to set the Duplicate address percentage threshold at a high percentage to avoid spurious **Duplicate Network Address** diagnoses. Possible values range from 0 to 100 percent; the default is 10 percent.

DLC Station Thresholds

This section describes the Expert thresholds related to symptoms and diagnoses detected at the Expert Data Link layer. Symptoms and diagnoses at the Data Link layer are associated with problems such as broadcast storms and traffic bursts. The thresholds are organized as they are found in the **Expert settings\Thresholds\DLC Station** menu. Token ring-specific (MAC level) thresholds are described starting on page 3-26. WAN/Synchronous-specific thresholds are described starting on page 3-28.

LAN Overload

The **LAN Overload** threshold specifies the network load at which the analyzer should generate a **Network overload** symptom. Network load is measured as a percentage of maximum bandwidth.

Possible values range from 1 to 100 percent; default is 30 percent for Ethernet and 60 percent for token ring.



Because of the token-passing nature of token ring networks, collisions are non-existent. Network loads can therefore remain trouble-free at higher volumes on token ring than on Ethernet. This explains the difference in default values for the **Network overload** threshold.

LAN Overload Percentage

The **LAN Overload Percentage** threshold specifies at what point the analyzer diagnoses that the network is overloaded. The diagnosis is **Overloaded network**.

LAN overload % is measured as the percentage of each minute the network is in overload mode. Whether the network is considered to be in overload mode depends on the setting of **LAN overload**.

Figure 3-15 illustrates the relationship between **LAN overload** and **LAN overload %**. In this example, the threshold **LAN overload** is defined as traffic greater than 30 percent of maximum bandwidth, and the threshold **LAN overload %** is defined as 20 percent. The total number of seconds during which the network experiences an overload is about 20. That is, the network is in overload mode for 30 percent of the time during this minute, which is higher than the **LAN overload percentage** threshold (20 percent). The analyzer diagnoses that the network is overloaded.




Figure 3-15. The relationship between the thresholds *LAN overload* and *LAN overload%*.

Broadcast Symptom

The **Broadcast Symptom** threshold specifies the rate of broadcast/multicast packets per second above which the analyzer will generate the symptom **Broadcast/Multicast storm**.

Possible values range from 0 to 999; default value is 40 broadcast packets per second.

Broadcast Diagnosis

The **Broadcast Diagnosis** threshold specifies the rate of broadcast/multicast packets per second above which the analyzer will generate the diagnosis **Broadcast storm**.

Characteristically, the value chosen to trigger a broadcast storm *diagnosis* (**Broadcast dg**) will be greater than that chosen to trigger a broadcast storm *symptom* (**Broadcast sy**).

Possible values range from 0 to 999; default value is 120 broadcast packets per second.

Physical Errors

The **Physical Errors** threshold specifies the maximum acceptable number of physical errors per second per station.

If the number of frames with physical errors sent by a given station exceeds the threshold, the analyzer generates the diagnosis **High rate of physical errors by station name**.

Note: The analyzer also tracks the number of physical error frames received by each station. However, this quantity does not affect when the **High physical level error rate** diagnosis is generated.

Possible values are 0 to 999 errors per second; default value is 4 errors per second per station.

Token Ring-Specific (MAC level) Thresholds

This section describes Expert thresholds that are specific to token ring; particularly, thresholds relating to the MAC level. The Expert analyzer captures and decodes all MAC level (including Report Soft Error) frames on the ring, providing accurate detection of token ring symptoms and diagnoses.

The thresholds are organized in the same order they are found in the **Expert settings\Thresholds\DLC Station** menu.

Ring Entries

The **Ring Entries** threshold specifies the rate of ring entries per minute per station at which the analyzer will generate the **High rate of ring entries** diagnosis. For example, if **Ring entries** is set to 2 (the default), the analyzer will generate the diagnosis when the rate of ring entries for a particular station equals or exceeds two per minute.

A station inserting to a ring physically “breaks” the ring as its relay in the multistation access unit (MAU) opens and the lobe becomes part of the ring. The ring recovers quickly, as this is normal token ring behavior. However, it is abnormal if there is more than one ring entry per minute for a given station. Default values are set accordingly.

Possible values are 0 to 999 ring entries per minute; default value is 2 per minute.

RX Congestion (Receiver Congestion)

The **RX Congestion** threshold specifies the rate of receiver congestion errors per minute per station at which the analyzer will generate the **High rate of receiver congestion** diagnosis. For example, if **RX congestion** is set to 60 (the default), the analyzer will generate the diagnosis when the rate of receiver congestion errors for a particular station equals or exceeds 60 per minute.

Receiver congestion errors indicate that a station detected a frame on the ring with its own destination address but was unable to copy it because it had no buffer space available. A new receiver congestion error is generated each time a new frame is rejected. Receiver congestion errors can be important guides when judging the adequacy of current servers and gateways on the ring. An abundance of receiver congestion errors from an interconnecting device may point to its obsolescence.

Possible values are 0 to 999 receiver congestion errors per minute. Default is 60 receiver congestion errors per minute.

Station Removed

The **Station Removed** threshold specifies the rate of Station Remove Requests per minute at which the analyzer will generate the diagnosis **High rate of remove from ring requests**. For example, if Station Remove is set to 1 (the default), the analyzer will generate the diagnosis when the rate of Station Remove Requests detected by the analyzer exceeds one per minute.

Station Remove Requests are sent by the Configuration Report Server, a virtual entity responsible for the overall health of the ring.

Possible values are 1 to 999 requests per minute. Default is 1 request per minute.

Ring Errors

The **Ring Errors** threshold specifies the rate of ring errors per minute per station at which the analyzer will generate the diagnosis **High rate of line/burst errors**. The threshold specifies the total of both line errors and burst errors per minute. For example, if **Ring errors** was set to three, the analyzer would generate the **High rate of line/burst errors** diagnosis when the rate of total line and burst errors for a given station exceeded three per minute.

Possible values are from 0 to 999 ring errors per minute. Default is 1 ring error per minute.

Ring Purge Symptom

The **Ring Purge Symptom** threshold specifies the rate of ring purges per station per minute at which the analyzer will generate the symptom **High rate of ring purges**. Ring purge frames are sent by the active monitor when it detects that a token has been lost, and are part of normal token ring behavior. However, an excessive amount of ring purge frames on the network can indicate potential hardware problems.

Possible values are from 0 to 999 ring purge frames per minute. Default is 30 ring purge frames per minute.

Note: When the **Ring purge sy** threshold is exceeded, the analyzer generates a *symptom*. The analyzer generates a *diagnosis* when the **Ring purge dg** threshold is exceeded. See below.

Ring Purge Diagnosis

The **Ring Purge Diagnosis** threshold specifies the rate of ring purges per station per minute at which the analyzer will generate the diagnosis **High rate of ring purges**. For a brief description of ring purge frames, see the section, "Ring Purge Symptom," above.



Characteristically, the value chosen to trigger a **High rate of ring purges diagnosis (Ring purge dg)** will be greater than that chosen to trigger a **High rate of ring purges symptom (Ring purge sy)**.

Possible values are from 0 to 999 ring purge frames per minute. Default is 60 ring purge frames per minute.

WAN/Synchronous (Sniffer Internetwork Analyzer) Thresholds

This section describes those Expert thresholds that are specific to the Sniffer Internetwork Analyzer (that is, the Sniffer analyzer for WAN/Synchronous).

The thresholds are organized in the same order they are found in the **Expert settings\Thresholds\DLG station** menu.

WAN Overload

The **WAN Overload** threshold works in tandem with the **Overload Timer** threshold to specify the point at which the analyzer generates the **Network Overload** symptom and the **Overloaded Network** diagnosis.

The **WAN Overload** threshold specifies whether the Expert analyzer considers the network to be in an overload condition. The Expert analyzer considers the network to be in an overload condition if both the DTE and DCE network loads are in excess of the load specified by the **WAN Overload** threshold. The Expert analyzer will continue to consider the network to be in an overload condition until either the DTE or DCE network load falls below the load specified by the **WAN Overload** threshold.

When the duration (in consecutive seconds) of the overload condition exceeds the time specified by **Overload Timer** (below), the analyzer will generate the **Network Overload** symptom (in the Global Symptoms view) and the **Overloaded Network** diagnosis.

Possible values range from 1 to 100 percent; default is 80 percent.

Overload Timer

The **Overload Timer** threshold works in tandem with the **WAN Overload** threshold to specify the point at which the analyzer diagnoses that the WAN is overloaded. The diagnosis is **Overloaded Network**.

The **Overload Timer** threshold specifies the duration (in seconds) of a WAN Overload condition at which the Expert analyzer will generate an **Overloaded Network** diagnosis. Whether the network is considered to be in an overload condition depends on the setting of the **WAN Overload** threshold.

Possible values range from 1 to 999 seconds; default is 60 seconds.

WAN Underload

The **WAN Underload** threshold works in tandem with the **Underload Timer** threshold to specify the point at which the analyzer generates the **Network Underload** symptom and the **Underloaded Network** diagnosis.

The **WAN Underload** threshold specifies whether the Expert analyzer considers the network to be in an underload condition. The Expert analyzer considers the network to be in an underload condition if both the DTE and DCE network loads are below the load specified by the **WAN Underload** threshold. The Expert analyzer will continue to consider the network to be in an underload condition until either the DTE or DCE network load increases above the load specified by the **WAN Underload** threshold.

When the duration (in consecutive minutes) of the underload condition exceeds the time specified by **Underload Timer** (below), the analyzer will generate the **Network Underload** symptom (in the Global Symptoms view) and the **Underloaded Network** diagnosis.

Possible values range from 0 to 100 percent; default is 10 percent.

Underload Timer

The **Underload Timer** threshold works in tandem with the **WAN Underload** threshold to specify the point at which the analyzer diagnoses that the WAN is underloaded. The diagnosis is **Underloaded Network**.

The **Underload Timer** threshold specifies the duration (in minutes) of a WAN Underload condition at which the Expert analyzer will generate an **Underloaded WAN** diagnosis. The setting of **WAN Underload** determines whether or not the network is considered to be in an underload condition.

Possible values range from 1 to 999 minutes; default is five minutes.

Congestion Percentage

The Congestion Percentage threshold specifies the point at which the analyzer will generate congestion-related symptoms. The Congestion Percentage threshold is calculated differently depending on the type of access protocol used by the WAN link to which the analyzer is attached.

Frame Relay

There are two Frame Relay congestion symptoms:

- **Excessive Forward Congestion.** The Expert analyzer generates this symptom when the percentage of forward explicit congestion notification (FECN) frames to total frames on the link exceeds the percentage specified by the **Congestion Percentage** threshold.
- **Excessive Backward Congestion.** The Expert analyzer generates this symptom when the percentage of backward explicit congestion notification (BECN) frames to total frames on the link exceeds the percentage specified by the **Congestion Percentage** threshold.

HDLC

On an HDLC link, the Expert analyzer generates the **Overcongested WAN** symptom when the percentage of receiver not ready (RNR) frames to

RNR+Receiver Ready (RR) frames exceeds the **Congestion Percentage** threshold.

Possible values range from 0 to 100 percent; default is 10 percent.

Effects of Changing Expert Thresholds

When you display frames after changing any of the Expert thresholds, the analyzer automatically reanalyzes the frames in the capture buffer. During analysis, the Expert analyzer uses the new Expert settings to generate symptom and diagnosis messages.



WARNING: When the Expert reanalyzes the frames in the capture buffer, it releases all the network objects it has created, including those gleaned from frames no longer in the capture buffer. The results of post-capture Expert analysis will be based solely on information found in the frames currently in the capture buffer. Once network objects associated with frames outside of the capture buffer have been released, they cannot be regained.

Changing the Expert settings will most likely change the results of Expert analysis on a given set of network data. There are at least two ways changing an Expert threshold will affect the results of Expert analysis:

- A modified threshold doesn't affect the captured data, but the analysis results change because previously analyzed frames are no longer in the capture buffer.
- A modified threshold is relevant to the data currently in the capture buffer. If this is the case, lowering the Expert thresholds will generally increase the number of symptom or diagnosis messages.

The examples below illustrate each of these possibilities.

Example One: Changing a Threshold Irrelevant to the Data in the Capture Buffer

Figure 3-16 illustrates the effect reanalyzing a subset of the frames that have passed through the capture buffer can have on the results of Expert analysis. In this example, the **Physical errors** threshold was set to two for both the original capture session as well as the post-capture analysis. During the original capture session, the analyzer generates the **Physical error** diagnosis when the threshold is exceeded. However, during post-capture analysis, a frame exhibiting one of the physical errors is now outside of the capture buffer. Because the analyzer no longer knows of the existence of that frame, the threshold is not exceeded, and no diagnosis is generated.




Figure 3–16. Results of Expert analysis can vary depending on when performed.

Example Two: Changing a Threshold Relevant to the Data in the Capture Buffer

In some cases, the effect of a modified Expert threshold is not as obvious. Consider the following example:

You are capturing frames from a trace file and analyzing with the data link threshold settings as follows:

- **LAN overload** = 30% (percentage of available bandwidth)
- **LAN overload %** = 20
- **Broadcast sy** = 2
- **Broadcast dg** = 1
- **Physical err** = 4

Under these data link thresholds, the analyzer detects a broadcast storm symptom after capturing frame 38 at 16:18:14.3693.

Suppose you capture again from the same file with this new threshold setting:

- **LAN overload** = 8%

Although the thresholds related to broadcast storms remain unchanged, the new analysis results show no broadcast storm symptoms or diagnoses. Instead, the analyzer detects a Network overload symptom at 16:18:13.7949.

What happened? With the decreased threshold for **LAN overload**, it became much easier to trigger a Network overload symptom. Frame 38 captured at 16:18:13.7949 exceeded the new threshold for **LAN overload**, and the analyzer alerted us to a LAN overload symptom. The analyzer never realized that Frame

38 also exceeded the **Broadcast sy** threshold. Because the analyzer stops analyzing a frame after detecting the first symptom or diagnosis associated with a frame, it is possible that a frame has more than one symptom, and the analyzer only displays a message for the first symptom or diagnosis detected.

Figure 3–17 illustrates the time passage between the detection of the two symptoms.




Figure 3–17. A single frame exhibiting two symptoms. Only the first is detected by the analyzer.

Console Alarms

This section describes the meaning of each user-defined alarm. Depending on the topologies you ordered from the factory, the exact alarms available on your analyzer may be a subset of those described here. Figure 3–18 shows the available alarms at each Expert layer. The alarms are described in the same order in which they appear in the analyzer's menus.

Expert Layer	Alarm Generated	Related Expert Threshold
Application Layer	Slow File Process	Slow File Percentage
	Slow Server	Slow Response Percentage
	Loop On Requests	Loop Time Percentage
	File Retransmission	Slow File Percentage
	Requests Denied	Denied Count/Denied Request Percentage
Connection Layer	Broken Connection	No Responses
	Retransmission	Retransmission Percentage
Network Layer	Duplicate Address	Duplicate Percentage
	Local Router	
	Multiple Router	Multiple Router
DLC Station Layer	Network Overload	LAN Overload Percentage
	Broadcast Storm	Broadcast Diagnosis
	Physical Error	Physical Error Count
MAC Layer (Token Ring)	Token Ring Entries	Ring Entries
	Ring Purges	Ring Purge Diagnosis
	Token Ring Bursts	Ring Errors
	Receive Congestion Burst	Receive Congestion Error Count
	Station Removed	Station Removed Count
	Beacon	

Figure 3–18. Alarm Priorities available for each Expert layer.

Application Layer Alarms

The alarms at the Expert application layer are described in this section in the same order they appear in Figure 3–18. Note that these alarms are generated based on related Expert thresholds specified in the **Expert settings\Thresholds** menu. For information on these related Expert thresholds, refer to the section, “Symptom and Diagnosis Thresholds at Each Expert Layer,” beginning on page 3–15.

Slow File Process

The **Slow File Process** alarm is generated to the Console based on the **Slow File Percentage** threshold. The **Slow File Percentage** threshold specifies the maximum percentage of slow file transfers versus total file transfers. An alarm is also generated to the Console when the **Local Transfer** or **Remote Transfer** threshold settings have been exceeded.

The default setting is **Warning**.

Slow Server

The **Slow Server** alarm is generated to the Console based on the **Slow Response Percentage** threshold. The **Slow Response Percentage** threshold determines whether the analyzer considers a server slow in responding to application requests. An alarm is also generated to the Console when the **Response Time** threshold has been exceeded.

The default setting is **Major**.

Loops on Requests

The **Loops on Request** alarm is generated to the Console based on the **Loop Percentage** threshold. The **Loop Percentage** threshold specifies the ratio between repeated requests and normal requests.

The default setting is **Inform**.

File Retransmissions

The **File Retransmissions** alarm is generated to the Console based on the **Slow File Percentage** threshold. The **Slow File Percentage** threshold specifies the maximum percentage of file retransmissions versus normal file transfers for a given connection.

The default setting is **Inform**.

Requests Denied

The **Requests Denied** alarm is generated to the Console based on the **Denied Count** and **Denied Request Percentage** thresholds that specify the maximum number of denied requests and the acceptable percentage of denied versus successful application requests for a given application.

An alarm is also generated to the Console when the **Filter Time** threshold has been exceeded.

The default setting is **Warning**.

Connection Layer Alarms

The alarms at the Expert connection layer are described in this section in the same order they appear in Figure 3-18. Note that these alarms are generated based on related Expert thresholds specified in the **Expert settings \ Thresholds** menu. For information on these related Expert thresholds, refer to the section, "Symptom and Diagnosis Thresholds at Each Expert Layer," beginning on page 3-15.

Broken Connection

The **Broken Connection** alarm is generated to the Console based on the **No Responses** threshold that specifies the maximum number of consecutive retransmissions in the same direction on a single connection without a response.

The default setting is **Inform**.

Retransmission

The **Retransmission** alarm is generated to the Console based on the **Retransmission Percentage** threshold. The **Retransmission Percentage** threshold specifies the maximum acceptable percentage of retransmitted packets versus successfully transmitted packets in the same direction on a single connection at the connection layer.

The default setting is **Major**.

Network Layer Alarms

The alarms at the Expert network layer are described in this section in the same order they appear in Figure 3-18. Alarms generated at the network layer are associated with network addressing and routing problems. Note that these alarms are generated based on related Expert thresholds specified in the **Expert settings \ Thresholds** menu. For information on these related Expert thresholds, refer to the section, "Symptom and Diagnosis Thresholds at Each Expert Layer," beginning on page 3-15.

Duplicate Address

The **Duplicate Address** alarm is generated to the Console based on the **Duplicate Percentage** threshold that specifies the maximum percentage discrepancy between DEC hello intervals.

The default setting is **Critical**.

Local Router

The **Local Router** alarm is generated to the Console when a router forwards local traffic. The default setting is **Minor**.

Multiple Routers

The **Multiple Routers** alarm is generated to the Console based on the **Multiple Routers** threshold. The **Multiple Routers** threshold specifies the maximum number of local routers through which local traffic can be routed to a remote station.

The default setting is **Inform**.

DLC Station Layer Alarms

The alarms at the Expert data link layer are described in this section in the same order they appear in Figure 3-18. Alarms generated at the data link layer are associated with problems such as broadcast storms and traffic bursts. Note that these alarms are generated based on related Expert thresholds specified in the **Expert settings \ Thresholds** menu. For information on these related Expert thresholds, refer to the section, "Symptom and Diagnosis Thresholds at Each Expert Layer," beginning on page 3-15.

Network Overload

The **Network Overload** alarm is generated to the Console based on the **LAN Overload Percentage** threshold. The **LAN Overload Percentage** threshold specifies at what point the analyzer diagnoses that the network is overloaded.

The default setting is **Minor**.

Broadcast Storm

The **Broadcast Storm** alarm is generated to the Console based on the **Broadcast Diagnosis** threshold that specifies the rate of broadcast and multicast packets per second above which the analyzer generates the Broadcast storm diagnosis.

The default setting is **Minor**.

Physical Error

The **Physical Error** alarm is generated to the Console based on the **Physical Error Count** threshold that specifies the maximum acceptable number of physical errors per second per station.

The default setting is **Major**.

Token Ring-Specific (MAC level) Alarms

This section describes those alarms specific to token ring; particularly, those alarms relating to the MAC level. Note that these alarms are generated based on

related Expert thresholds specified in the **Expert settings \ Thresholds** menu. For information on these related Expert thresholds, refer to the section, "Symptom and Diagnosis Thresholds at Each Expert Layer," beginning on page 3-15.

Token Ring Entries

The **Token Ring Entries** alarm is generated to the Console based on the **Ring Entries** threshold that specifies the rate of ring entries per minute per station above which the analyzer generates the High rate of ring entries diagnosis.

The default setting is **Minor**.

Ring Purges

The **Ring Purges** alarm is generated to the Console based on the **Ring Purge Diagnosis** threshold that specifies the rate of ring purges per station per minute above which the analyzer generates the High rate of ring purges diagnosis.

The default setting is **Minor**.

Token Ring Bursts

The **Token Ring Bursts** alarm is generated to the Console based on the **Ring Errors** threshold that specifies the rate of ring errors per minute per station above which the analyzer generates the High rate of line/burst errors diagnosis.

The default setting is **Inform**.

Receive Congestion Burst

The **Receive Congestion Burst** alarm is generated to the Console based on the **Receiver Congestion** threshold that specifies the rate of receiver congestion errors per minute per station above which the analyzer generates the High rate of receiver congestion diagnosis.

The default setting is **Major**.

Station Removed

The **Station Removed** alarm is generated to the Console based on the **Station Removed** threshold that specifies the rate of Station Remove Requests per minute above which the analyzer generates the High rate of remove from ring requests diagnosis.

The default setting is **Minor**.

Beacon

The Beacon alarm is generated to the Console when the Server is in a beaconing state. The default setting is **Critical**.

Alarm Levels

The alarm level of the Server is indicated on the Console's Server Status screen. This indicates the highest priority alarm detected by the Server. To lower the alarm level on a Monitor Server, you must acknowledge or clear the alarm on the Server.

For Expert Servers, the alarm level indicates the highest level alarm currently active on the Server. As new diagnoses are generated or go active, the alarm level is raised if the diagnosis is of higher priority than the current alarm level. The alarm level will be lowered when the highest active alarm on the Server has been lower than the Server alarm level for some amount of time. This amount of time may be set between 1 and 5940 minutes (that is, up to 99 hours) from the **Expert settings \ Level timer** menu. The default setting is five minutes.



To set the alarm level:

1. Move to the **Expert settings \ Level timer =** field.
2. Press Enter.

A dialog box is displayed with the current setting.

3. Enter the amount of time you want between 1 and 5940 minutes and press Enter.

Alarm Throttle

Diagnoses are triggered by some threshold level of symptom. When the symptom level is near the configured threshold for triggering a diagnosis, you may see the diagnosis toggling between active and inactive states. An alarm is sent to the Console on each transition into the active state.

Alarm throttle allows you to configure the Server to not send an alarm about the same diagnosis more than once every x minutes, where x can range from zero to 5940 minutes (that is, up to 99 hours). The default setting is one minute.



To configure the alarm throttle:

1. Move to the **Expert settings \ Throttle =** field.
2. Press Enter.

A dialog box is displayed with the current setting.

3. Enter the amount of time you want between 0 and 5940 minutes and press Enter.

Expert Triggers

Expert triggers allow you to use diagnoses as trigger events, anchoring capture to make sure the frames that interest you are either saved to hard disk as a snapshot or remain in the capture buffer. This section describes the mechanics of setting an Expert trigger. It does not discuss in detail the meanings of the triggers, which are described in the next few sections.



You can specify an Expert trigger along with external and pattern triggers. If you use these different types of triggers, you should read "The Order in Which the Analyzer Processes Triggers" on page 3-42 to understand how the analyzer processes triggers.



To set an Expert trigger:

1. Use the cursor keys to move to the **Trigger\Expert Trigger** menu.
2. Move the highlight to the layer at which you want to specify an Expert trigger.

Result: A list of Expert triggers associated with the highlighted layer appears in the right menu panel. Figure 3-19 shows the Expert triggers associated with the Application layer.

In Figure 3-19, notice that each Expert trigger is preceded by either an x or a √. Triggers preceded by a √ are enabled; those preceded by an x are disabled. You can use the Spacebar to toggle between enabled/disabled. By pressing alt-Spacebar, you can reverse all selections in the current display.

3. Move the highlight to a trigger you want to enable. Press the Spacebar to change its tag from an x (disabled) to √ (enabled). Repeat this process for each trigger you want to enable or disable. In Figure 3-19, the Expert trigger **Slow server** is enabled.
4. In Figure 3-19, the menu item **Expert trigger** is also preceded by a √. You can enable or disable all Expert triggers as a group.
5. Set other trigger options, such as **Stop capture**, **Disk snapshot**, and **Trigger position**. For more information on these options, see the *Distributed Sniffer System: Analyzer Operations Manual*.
6. Press F10 (**New capture**) to start capture.

Result: When capture begins, the new trigger takes effect.




Figure 3-19. The Trigger \ Expert trigger \ Application layer menu.

Effects of an Expert Trigger

The frame causing an Expert trigger is marked with a T in the summary view. The diagnosis was probably not caused by the marked frame alone. The mark simply indicates where the diagnosis is made. For example, if you set the diagnosis **Broadcast storm** to be the trigger event, the trigger frame indicates at what time the analyzer decided that a broadcast storm happened; it doesn't mean that the frame itself caused a broadcast storm.

After an Expert trigger occurs, the analyzer does the following:

- Emits a beep, notifying you that a trigger event has occurred.
- Continues or stops capture, depending on the settings of **Stop capture** and **Trigger position**.

If **Stop capture** is disabled, the analyzer continues capturing, and it is possible that the frame associated with an Expert trigger could be pushed out of the buffer by the time you stop capture.

If **Stop at trigger** is selected, the analyzer continues capturing until the frame associated with the Expert trigger is in the position described by **Trigger position**. For example, if **Trigger position** is 100 percent pretrigger, capture stops immediately after the trigger event has happened. In this case, the related alarm will not be sent to the Console and any other alarms queued but not yet sent will not be sent to the Console.

If **Stop when full** is selected, the analyzer continues capturing until the buffer is full. If a trigger event occurs, the trigger frame remains in the buffer, but its relative position is not predetermined.

- If **Disk snapshot** is selected, the analyzer stores the frames surrounding the trigger event to the disk. Depending on the configuration of the various **Disk snapshot** options, the analyzer can either continue capturing or stop after the first trigger. Refer to the *Distributed Sniffer System: Analyzer Operations Manual* for further information on how disk snapshots are taken.

For general information on setting and manipulating triggers, refer to the *Distributed Sniffer System: Analyzer Operations Manual*.

Available Expert Triggers

The Expert triggers are organized by Expert layers, each of which contains several trigger options. Figure 3–20 summarizes the Expert triggers available at each Expert layer.

Expert Layer	Expert Threshold
Application Layer	Slow file process
	Slow server
	Loops on request
	File retransmission
	Requests denied
Connection Layer	Broken connection
	Retransmission
Network Station Layer	Duplicate address
	Local router
	Multiple routers
	Subnet down
	Bad routing table
	Subnet conflict

Figure 3–20. Expert triggers available at each Expert layer.

Expert Layer	Expert Threshold
DLC Station Layer	Overloaded LAN
	Broadcast storm
	Physical error
	Overloaded WAN
	WAN underload*
	HDLC retransmits*
	Overcongested WAN*
	Underload congestion*
MAC Layer (Token Ring)	Token ring entry
	Ring purge
	Receiver congestion
	Station removed
	Beaconing ring
	Token ring burst

*Sniffer Internetwork Analyzer (WAN/Synchronous) only

Figure 3–20. Expert triggers available at each Expert layer.

The Order in Which the Analyzer Processes Triggers

Normally, if you specify multiple triggers, whichever frame that fulfills a trigger condition first is considered the trigger frame and is marked with a T.

However, if you specify both Classic and Expert triggers, it is possible that the analyzer will ignore the Expert trigger event even though it precedes the Classic event. This is because the analyzer processes Classic triggers faster than Expert triggers. The following example explains this concept.

Example: Processing Expert and Classic Triggers

Suppose you specify one Classic pattern-match trigger and one Expert trigger. In Figure 3–21, frame 90 fulfills the condition of the Expert trigger and frame 100 fulfills that of the pattern-match trigger. Because the analyzer processes the Classic pattern-match trigger on frame 100 before it performs Expert analysis on frame 90, frame 100 is marked as the trigger frame instead of frame 90. The analyzer does not consider frame 90 to be the first trigger event. As a result, you might not be aware that a frame associated with the Expert trigger has ever occurred.



You can avoid this problem by enabling only Expert triggers. If no Classic triggers are enabled, you are assured that the analyzer will recognize the Expert trigger event accurately.




Figure 3–21. The order in which the analyzer processes triggers.

Customizing a Capture Session

You can customize an Expert capture session by specifying the screen format, capture filters, frame size, and so on. In addition, there are several Expert-specific options which allow you to further customize a capture session. This section describes the following menu options:

- **Highest layer** Specifies the highest Expert layer at which Expert analysis will take place.
- **Freeze/Reuse Allocation** Specifies whether the Expert analyzer should reuse its memory when there is no more room for new network objects.
- **Print Network Objects** Allows you to print information about a network object to a file or to a printer.
- **Name Width** Allows you to specify the width (in characters) allotted to names in Expert displays.

Each of these options is described below.

Highest Layer Option

The **Highest layer** option allows you to specify the highest layer at which Expert analysis will take place. For example, if **Highest layer** were set to **Application** (the default), all four Expert layers would be analyzed. However, if **Highest layer** were set to **Network Station**, only the Network Station and DLC Station layers would be analyzed. Because the **Highest layer** option allows you to perform Expert analysis on selected layers only, you can conserve memory and processor time during capture.

Because the amount of traffic on a particular network segment can be huge, the Expert analyzer may sometimes miss some frames. When you need Expert analysis on a very busy network segment, or you know at what layer the problem you are looking for resides, you may want to use the **Highest layer** option.

For example, suppose you were concerned with the number of broadcast frames on a very busy network segment. Using the **Highest layer** option, you could specify that the analyzer only perform Expert analysis at the DLC Station layer; the Expert layer concerned with broadcast frames. After capture, when memory and processor time is no longer at a premium, you could reset the **Highest layer** option to **Application**. When you press F3 (**Data display**), the analyzer will reanalyze the frames in the capture buffer for all four Expert layers.



WARNING: When the Expert reanalyzes the frames in the capture buffer, it releases all the network objects it has created, including those gleaned from frames no longer in the capture buffer. The results of post-capture Expert analysis will be based solely on information found in the frames currently in the capture buffer. Once network objects associated with frames outside of the capture buffer have been released, they cannot be regained. See the discussion in “Effects of Changing Expert Thresholds” on page 3–30 for more information on this concept.



To specify the highest Expert layer at which Expert analysis takes place:

1. Move to the **Expert settings \ Highest layer** menu.

Result: The menu in Figure 3–22 appears. Notice that the **Application** layer is currently the highest layer that will receive Expert analysis. That is the default.




Figure 3–22. *Expert settings \ Highest layer menu*. Notice that the radio control is set to *Application*, the default.

2. Move the highlight to the highest layer at which you want Expert analysis to take place. Press either Enter or Spacebar.

Result: The radio control moves to the selected layer. All layers below (and including) the selected layer will receive Expert analysis.



Remember that the layers used by the Expert analyzer do not correspond exactly to the OSI model. For a diagram of how the Expert model of network layers maps onto the OSI model, see Figure 3–1 on page 3–5.

Freeze/Reuse Allocation Option

As the Expert analyzer captures frames from the network, it uses the information in those frames to build a database of network objects. Because some networks can be immensely complex in their structure, at some point the Expert analyzer will have no more memory for new network objects in its database. The **Freeze/Reuse Allocation** option allows you to specify what action the analyzer should take when it runs out of memory for new network objects.

The two options are:

- **Freeze allocation**

The analyzer will create no more new objects, but will instead continue to interpret network traffic in accordance with the information it has already stored in its database. Symptoms and diagnoses will be revealed according to the information already in the Expert analyzer's database.

- **Reuse allocation**

The analyzer will continue to add new objects to its database, overwriting those objects that are least interesting. This is the default. See "How the Expert Analyzer Reuses Network Objects," below.



Depending on the configuration of your unit, the Expert analyzer's database has an upper limit of about 600 network objects.

How the Expert Analyzer Reuses Network Objects

When the Expert analyzer reuses the memory associated with less interesting network objects, it does so via a "smart" algorithm that, in effect, allows it to "forget" outdated network information. The list below summarizes the types of network objects the analyzer will and will not reuse:

The analyzer will not reuse:

- Network objects that have symptoms or diagnoses associated with them
- A network object currently highlighted in the Expert window

The analyzer will reuse:

- Network objects with two or less associated frames and no associated errors

For example, the Expert analyzer will create objects in its database for network stations that have never transmitted or received a frame. Various routing protocols, such as the Routing Information Protocol (RIP), require regular route advertisements showing which stations can be accessed by a given router. The Expert analyzer can learn about non-transmitting stations from such route advertisements. When **Reuse allocation** is selected, the Expert analyzer will reuse objects associated with non-transmitting stations such as these in favor of new information.



To specify the Expert analyzer's action when memory is exhausted:

1. Use the cursor keys to move to the **Capture \ Expert mode** menu.

Result: A display such as that in Figure 3-23 appears. Notice that currently the radio control points to **Reuse allocation**. That is the default.

2. Use the cursor keys to highlight the desired option, as described above. Press either Enter or Spacebar.

Result: The radio control moves to the highlighted option. The new option will be effective the next time capture starts.




Figure 3-23. Capture \ Expert mode menu.

Print Network Objects Option

Just as you can save, print, or import displayed frames, the Expert analyzer also allows you to print information about network objects to a file or printer. This section gives an overview of the options associated with printing reports on network objects. For a complete discussion of the analyzer's printing capabilities, see the *Distributed Sniffer System: Analyzer Operations Manual*.

To prepare for printing a report on a network object, you can define the following options:

- The destination (either a printer or file)
- File format
- Page titles (if any)
- Page size

Figure 3-24 shows the options associated with printing reports on network objects.




Figure 3-24. Menu items associated with printing network objects.

In general, printed reports for network objects combine the information found in the Expert Detail and Statistics windows for a particular object. Printouts of network object information are always preceded by a printout of the Expert Overview. When data is printed, there are no indications of highlighting or color.

The procedure that follows outlines the steps for printing reports on network objects. For more information about each of the options associated with the **Print** option as it pertains to network objects, see the sections after the procedure.



To create a report on a network object:

1. After capture, display data in the Expert window by pressing F3 (**Data display**).
2. From a display accessible from the Objects/Symptoms column of the Expert window, highlight the object for which you want to create a report. Objects include applications, connections, network stations, and DLC stations.

Note: You cannot create reports for subnets, global symptoms, or diagnoses.

3. Press F6 (**Display options**).

Result: The Display Options menu appears (Figure 3-24).

4. In the Display Options menu, define the destination by moving to the desired option and pressing Spacebar.

► Device LPT1
Device LPT2
File

5. Determine whether to include page titles. Move to **Print page titles** and press Spacebar to enable (√) or disable (x) the option.
6. Determine the page size. Move to the **Page size** option and press Enter. In the dialog box that appears, enter a value between 5 and 99 as the desired number of lines per page. The default is 50 lines per page.
7. Move to **Print** and press Enter. Depending on the report destination you specified, the report is either printed on the chosen printer or saved as a file.

If you chose the **File** option, a dialog box appears. Enter the filename, using no more than eight characters. Do not include an extension; the Sniffer analyzer automatically attaches the extension .PRN to the filename you entered.

Defining the Destination: Printer or File

You can either print displayed data or save it to disk as a file. Figure 3–25 shows a sample report on a network object. In this case, the network object is a connection between the workstation **PamsWorkstation** and the NFS server **MIS-Server**.

Report destination options include:

LPT1	A parallel printer attached to the Sniffer Server's LPT1 port.
LPT2	A printer attached to the SniffMaster Console from which you are operating the Server. (The Console may then redirect the output to a file on its own hard disk, if it has been configured to do so.) For a discussion of Console configurations, see the <i>Distributed Sniffer System: Console Installation and Operations Manual</i> .
File	A file that is saved to the Sniffer Server's hard disk.

For more details on the physical setup of attached printers, see the *Distributed Sniffer System: Console Installation and Operations Manual*.




Figure 3-25. Printed report on a network object.

Choosing Page Titles

You can choose whether to include page titles for each page. Page titles specify the date and time the data was recorded, the network name (for a "live" capture) or the name of the file (for a capture from a file), and the page number. There are two blank lines between the heading and the start of the data.

If you enable the **Print page titles** option, you also cause explicit page breaks because the Sniffer analyzer includes a form-feed character after the last non-blank line of each page.

Choosing Page Size

You can also set the page size, which determines the number of lines per page. The default is 50 lines. Depending on whether you enabled the **Print page titles** option, this setting would result in either 50 printed lines or, with a page title, two blank lines and 47 lines of data. Since each page break is indicated by an explicit form feed, there is no separate setting for the physical length of the paper.

Name Width Display Option

You can define the width of the name field in the Expert summary and detail displays, from 6 characters up to 31 characters (the default is 15 characters). For example, if the Expert analyzer discovers many large names, you may want to make the name field wider to accommodate the names.

Once you've increased the name width, other information fields may be partially hidden beyond the right limit of the display. That information is still there; you simply need to scroll to reach it. The Expert analyzer allows you to use the cursor keys to scroll horizontally and read information temporarily "hidden" at the edge of the display.

If the display includes a name longer than the specified name width, the Sniffer analyzer truncates that name and replaces its last two visible characters with dots (to show that the name has been truncated). For example, if the **Name width** option specifies an 8-character field and the analyzer discovers the 10-character name "FileServer," the Summary view would show "FileSe. ."



To define the Name width option:

1. Move to **Name width=** and press Enter.

The **Name width** command is available in three places in the Sniffer analyzer menus:

- In the **Capture \ Screen Format \ Expert window** menu.
- In the **Display** menu.
- From the **Display Options** menu. The **Display Options** menu is available by pressing F6 (**Disply options**) during post-capture display.

All three locations are linked. If you change the name width in one location, it is automatically synchronized throughout the menus.

2. In the dialog box that appears, enter the desired name width.

Note: The width you specify in this dialog box will apply to both the Expert and Classic summary and detail displays.

How the Expert Analyzer Learns Symbolic Names

During capture, the Expert analyzer uses its real-time protocol interpreters to learn about the symbolic names for the various network stations, servers, routers, and other network stations. The Expert analyzer can rapidly decode the frames it captures, associating the symbolic names it finds with the related network stations. As the analyzer learns names, it will substitute the symbolic names for the hex, IP, or DECnet addresses in the Expert displays.

Some network protocols have a command that lists all users currently logged on to a given file server. When this occurs, the Expert analyzer captures the relevant packets and extracts all the names from that packet, associating them with the appropriate network address. The following procedure shows how to use this "trick" to help the analyzer learn names almost instantly.



To help the Expert analyzer learn symbolic names:

1. From a workstation "visible" by the Sniffer Network Analyzer, type the following command:

-If Novell:
 USERLIST /A

-If DECnet
 SHOW KNOWN NODES

-If TCP/IP running Sun Network Information Services™ (also known as Sun Yellow Pages).
 YPCAT HOSTS.BYNAME
2. Once the Expert analyzer captures the relevant packets, it will substitute the symbolic names it has learned for the addresses in the Expert displays.
3. At the end of the capture session, you may want to use the **Save names** option to save all of the names the Expert analyzer has learned to the name table. For more information on the **Save names** option and how the analyzer works with the name table, see the *Distributed Sniffer System: Analyzer Operations Manual*.

Note: The Expert analyzer still "knows" the actual address of each station. That information is available in the Detail window. See the next chapter for more information on the Detail window.

Note: In a Novell environment, this trick only works for those stations which are currently logged on to the file server to which the request is made. For example, if WorkStation A is logged on to the file server BIZ-ONE and makes a USERLIST /A request, the analyzer will only learn the symbolic names of those stations currently logged on to BIZ-ONE.

Note: Two Console alarms generated by the same diagnosis will display different station names in the text description field if the symbolic name was identified between the sending of the two alarms.

CHAPTER FOUR: EXPERT ANALYZER CAPTURE AND DISPLAY **4**

Expert Analyzer Capture and Display

Overview

You can display the results of Expert analysis at many different levels of detail. This chapter describes the various displays containing the results of Expert analysis. The chapter is organized as follows:

- How to navigate through the Expert displays.
- Description of the Global Statistics display
- Descriptions of the various Diagnosis displays. Each Diagnosis detail display is described.
- Descriptions of the various Symptom and Network Object displays.

The chapter also discusses traversing the various Expert displays to get the maximum amount of information on a network problem or connection.



All the Expert screen displays available during capture are also available during post-capture display. You can navigate through the Expert window during display just as you would during capture. The instructions and descriptions in this chapter are unique to neither capture nor display but only to the Expert window.

Displaying Analysis Results In the Expert Window

When you start capture in Expert mode, the analyzer automatically sets the screen format to the Expert window. By default, the analyzer displays the Expert Overview. The Expert Overview provides your “home base” for tracking and investigating network problems detected by the analyzer. The Expert Overview tabulates all detected network objects, symptoms, and diagnoses, organizing them by the Expert layer at which they occur. You can use the cursor keys to highlight the various fields in the Expert Overview and press Enter to view more detailed screens.

For definitions of, “network objects,” “symptoms,” and, “diagnoses,” see the sections beginning on page 2–3.

Figure 4–1 summarizes the various displays available in the Expert window.




Figure 4-1. Schematic of the various Expert windows.



Figure 4-1 introduces an important concept for working with the Expert analyzer. Note that while the Expert displays begin with the Expert Overview, subsequent displays are divided between two categories:

- Diagnosis-related displays
- Symptom and Network Object-related displays

Although the various displays in these two categories are similar in content, their purposes are different. The diagnosis-related displays allow you to track network problems that demand immediate attention. The symptom and network object displays provide you with a barometer of the overall health of your network. Typically, the quantity of symptoms on a given network will greatly exceed the number of diagnoses.

Expert analysis results can be displayed at four levels of detail—overview, Summary, detail, or statistics displays. The list that follows briefly describes the contents of each display.

Overview

The Expert Overview provides a summary of all information detected by the Expert analyzer. The Expert Overview tabulates the number of network objects, symptoms, and diagnoses detected at each Expert layer, in addition to a one-line summary of some critical diagnoses.

It may be helpful to think of the Expert Overview as a “home base” from which you can traverse out to the various Expert analyzer submenus. By highlighting the various fields in the Expert Overview and pressing Enter, you can receive more detailed information about specific network problems detected by the Expert analyzer.

Summary

The Diagnosis Summary window contains a list of all diagnoses detected at the selected layer. This list contains brief descriptions of the detected diagnoses and when they occurred.

Symptom and Network Object Summary windows list all network objects detected at the selected layer and a one-line description of the last symptom (if any) associated with each network object. Summary windows are described starting on page 4-36.

Detail

Diagnosis Detail displays show specific information about a particular diagnosis. The information in this view is designed to help you solve the network problem indicated by the diagnosis. Information in this display could include the addresses of the most active stations during a traffic burst, the address of a slow server, or the name of a non-responsive station. The exact information depends on the particular diagnosis. The various Diagnosis Detail displays are described starting on page 4-13

Symptom and Network Object Detail windows show detailed information about the highlighted network object and any symptoms associated with that object. This information could include the addresses of all stations connected to a selected server, the average packet length of frames on a particular connection, and so on. The exact information depends on the Expert layer and the highlighted network object. Symptom and Network Object Detail windows are described starting on page 4-47.

Statistics

Statistics displays provide specific information about a particular connection or network station. The information in this view could include total bytes transferred on a connection, average frame length, average file performance and number of broadcast frames sent. The exact information depends on the Expert layer selected. Statistics displays are described starting on page 4-54.



In addition to these views, there is also a Global Statistics view. The Global Statistics view provides a percentage breakdown by protocol family of all detected network traffic. Additionally, the Global Statistics view provides information on bandwidth utilization and general information about the current capture session. The Global Statistics window is described starting on page 4-64.

Each of these displays is described further in later sections.

Navigating the Expert Window

You can always navigate among the various Expert displays using these methods:

- To move from a general to specific display, highlight a field that interests you and press Enter. (Use Cursor Up, Cursor Down, PgUp, PgDn, Home, and End to move the highlight.) For example, in the Expert Overview, you can highlight the Diagnoses field at the Application layer and press Enter to display a list of diagnoses detected at the Application layer.
- To move from a specific to a general display, press Esc.

- If the width allotted to names in the Expert displays has been expanded with the **Name width** command, there may be some information out of sight at the right edge of the Summary displays. The analyzer will indicate this by replacing the last two visible characters with periods. (For example, "Fileserver" might become "Fileserv..") You can use the cursor keys to scroll horizontally until the hidden information becomes visible. Horizontal scrolling is available only in the Expert Summary displays (and in the Classic display window). For more information on the **Name width** command, see "Name Width Display Option" on page 3-51.
- There are also several function keys which can speed your navigation through the Expert Overview. These keys are described in "Advanced Navigation Techniques" on page 4-77.

Explain messages are available at each level of display. However, capture must be paused before pressing F1 (**Explain**) to invoke these messages. Explain messages are context-sensitive; their contents change according to the information being displayed. To terminate the display of an Explain screen, press Esc. You can display as many explain messages as you want while capture is paused. Simply switch to another display or highlight a different field in the current display and press F1 to invoke the message for that topic.

Note: During post-capture Display routines, Explain messages are always available in the Expert window by pressing F1 (**Explain**).



The best way to learn how to navigate through the Expert displays is to experiment with your analyzer, navigating through the various windows.

The Expert Overview Display

When you start capture in Expert mode, the Expert Overview appears (Figure 4-2). The Expert Overview provides a summary of network activity at each Expert layer. There are separate counters for the number of network objects, symptoms, and diagnoses detected at each Expert layer, allowing you to maintain a constant overview on the health of your network.




Figure 4-2. The Expert Overview.

The Expert Overview is organized as a table with six rows and three columns. The rows represent the four Expert layers, plus one row for subnet pairs and one row for global symptoms. Subnet Pairs and Global Symptoms are not Expert layers. The purpose of these fields is to provide more information about subnets and global symptoms, such as traffic bursts.

The three columns include:

- **Objects** - the number of network objects detected at this Expert layer (that is, the number of connections at the Application layer, connections at the Connection layer, Network Stations, and DLC Stations detected since capture started).
- **Symptoms** - the number of symptoms detected at this Expert layer.
- **Diagnoses** - the number of diagnoses detected at this Expert layer.

For definitions of network objects, symptoms, and diagnoses, see "Expert Analyzer Terminology" on page 2-3.

Navigating through the Expert Overview

Each cell within the Expert Overview table is a gateway to more detailed subscreens. By using the cursor keys to highlight a particular field and pressing Enter, you can see more detailed information about the objects, symptoms, and diagnoses at the highlighted layer. These subdisplays are described in later sections.

Note: While Objects and Symptoms are tabulated separately, you cannot view them separately, because their displays are integrated. The cursor indicates this by highlighting both columns, as in Figure 4-2.

Note: The analyzer has an upper limit of 100 diagnoses. While it is unlikely that you would ever reach this point (unless thresholds were set artificially low), the analyzer can record no more than 100 diagnoses during a given capture session. If this is a problem, you may want to set the Expert thresholds higher (see "Setting Thresholds for Symptoms and Diagnoses" on page 3-13), consider setting a capture filter, or change **Highest layer** to a lower Expert layer (see "Highest Layer Option" on page 3-44).

Other Counters in the Expert Overview

The Expert Overview shows the same statistics near the bottom of the screen as any capture display. For example, it includes the number of frames captured, the percentage of network usage, buffer utilization, and so on, which you would also see on an analyzer capturing in Classic mode. The exact format depends on the options you select in the **Capture \ Screen format** menu. For more information on these counters, see the *Distributed Sniffer System: Analyzer Operations Manual*.

Diagnosis-Related Displays

This section describes the various displays accessible from the **Diagnoses** column of the Expert Overview. The Expert displays accessible from the **Objects/Symptoms** column of the Expert Overview are described starting on page 4-36. Note that the same displays are available in the Expert window regardless of whether the analyzer is capturing or displaying frames.

You may want to refer to Figure 4-1 on page 4-4 for a schematic of the various Expert windows and how they relate to one another.

Diagnosis Summary Window

The Diagnosis Summary window lists all diagnoses generated by the Expert analyzer at the selected Expert layer. The analyzer updates the appropriate diagnosis count in the Expert Overview each time it makes a diagnosis. Each diagnosis is a conclusion that the analyzer makes when predefined thresholds have been exceeded. The procedure below explains how to display a Diagnosis Summary window.



To display a Diagnosis Summary window:

1. In the Expert Overview, use the cursor keys to highlight a particular layer in the Diagnoses column that shows at least one diagnosis. Press Enter.

Result: The Diagnosis Summary window appears, as shown in Figure 4-3.

Note: The Summary window appears only if diagnoses exist at the selected layer.

Each diagnosis in the Summary window represents an important “clue” that might lead to the discovery of a network problem.




Figure 4-3. Diagnosis Summary window; in this case, at the Application layer.

The following list describes the three types of information shown in the Summary display:

First Time	The time when the analyzer first makes the diagnosis.
Duration	The length of time during which the diagnosis is valid. Suppose the diagnosis is Excessive error responses from BIZ-ONE , as in Figure 4-3. This means that the ratio of denied application requests to successful requests has exceeded the Error resp threshold in the Expert settings\Thresholds menu. This condition has been active for a total of two hours and 25 minutes.
Diagnosis	An asterisk in the first column indicates that the diagnosis is still active. In the above example, it means that BIZ-ONE is currently denying excessive application requests. The asterisk disappears and the counter for duration stops incrementing when the percentage of denied requests drops below the Error resp threshold. If the diagnosis condition begins again, the analyzer will increment the existing counter cumulatively. The duration counter does not imply consecutive time.
	A statement describing a potential network problem. It may or may not be a valid conclusion. Before making a final judgment, you might want to take into account circumstances that are not known to the analyzer.



You should press F1 to display the Explain message related to the highlighted diagnosis. The Explain message reminds you of the thresholds that affect the diagnosis and includes suggestions on how to examine other statistics to assess the seriousness of the problem. To return to the Summary display, press Esc.

Temporarily Removing Diagnoses From the Expert Window

During your investigation of network problems, you may want to limit the diagnostic displays in the Expert window to only those problems which currently concern you. The procedure below explains how to temporarily remove a diagnosis from the Expert window.



To temporarily remove a diagnosis from the Expert window:

1. Use the cursor keys to display one of the following:
 - A Diagnosis Summary window
 - A Diagnosis Detail window
2. Highlight the diagnosis which you want to temporarily remove from the display.
3. Notice the dynamic function key label at the bottom of the display for F7 (**Remove diag**). Figure 4-3 shows the label.

Press F7 (**Remove diag**) to temporarily remove the highlighted diagnosis from display.

You can remove as many diagnoses as you like, narrowing the display to show only those that concern you. The removed diagnoses have not been erased; they have simply been removed from display. The procedure below explains how to restore them.



To restore removed diagnoses to the display:

1. Use the cursor keys to display one of the following:
 - A Diagnosis Summary window
 - A Diagnosis Detail window
2. If there are diagnoses that have been removed, and can now be restored, the function key label F8 (**Restore diags**) appears. Press F8 to restore the removed diagnoses.

Note: You cannot restore diagnoses individually. Pressing F8 restores all diagnoses removed during the current Expert session.

Note: Diagnoses that have been removed are not used in determining the overall Server alarm level reported to the Console.

Diagnosis Detail Displays

Diagnosis Detail displays provide information important to the investigation of a network problem. The exact information in the Detail display depends on the nature of the highlighted diagnosis. For example, the Detail display for the **Slow server** diagnosis lists the addresses of all stations that received a slow response from a given server. This section describes the Detail display for each diagnosis made by the Expert analyzer. The procedure below explains how to view a Diagnosis detail display.



To display a Diagnosis Detail window:

1. In the Expert Overview, use the cursor keys to highlight a particular layer in the Diagnoses column that shows at least one diagnosis. Press Enter.

Result: The Diagnosis Summary window appears.

2. In the Summary window, use the cursor keys to highlight the diagnosis you want to investigate. Press Enter.

Result: The Diagnosis Detail display for the selected diagnosis appears.

Figure 4-4 summarizes the Diagnosis Detail displays and their related Expert thresholds. The displays are organized in alphabetical order.

Diagnosis	Detail Window shown on:	Related Expert Threshold	Threshold described on:
Broadcast Storm	page 4-15	Broadcast Diagnosis	page 3-25
Duplicate Network Address	page 4-16	Duplicate Address Percentage	page 3-23
Excessive Repeated Requests	page 4-17	Filter Time/Loop %	page 3-18
Excessive Requests Denied	page 4-18	Denied Request %	page 3-19
File Overlap/Retransmission	page 4-19	Slow File %	page 3-20
High Rate of Congestion	page 4-20	Receiver Congestion	page 3-26
High Rate of Line/Burst Errors	page 4-21	Ring Errors	page 3-27
High Rate of Physical Errors	page 4-22	Physical Errors	page 3-25
High Rate of Remove from Ring Reqs	page 4-23	Station Removed	page 3-27
High Rate of Ring Entries	page 4-24	Ring Entries	page 3-26
High Rate of Ring Purges	page 4-25	Ring Purge Diagnosis	page 3-27
LAN Overloaded	page 4-26	LAN Overload / LAN Overload % WAN Overload / Overload Timer	page 3-24 page 3-28
Local Router	page 4-27	No threshold	
Multiple Routers to Station	page 4-28	Multiple Routers	page 3-22
Non-responsive Station	page 4-29	No responses	page 3-21
Retransmissions	page 4-31	Retransmission %	page 3-21
Ring beaconing	page 4-32	No threshold	
Slow File Transfer	page 4-33	Slow File %	page 3-20
Slow Server	page 4-34	Response Time/Slow Response %	page 3-17
Underloaded Network	page 4-35	WAN Underload/Underload Timer	page 3-28

Figure 4-4. Diagnosis Detail displays and their related Expert thresholds.

Broadcast Storm

The analyzer diagnoses a broadcast storm condition when the number of broadcast frames per second exceeds the threshold specified by **Broadcast dg** in the **Expert Settings** menu. For more information on the **Broadcast dg** threshold, see page 3–25.

The detail display, shown in Figure 4–5, provides the following information:

- **Total number of broadcast storms.** Number of broadcast storm diagnoses made by the analyzer during this capture session. When the number of broadcast frames per second falls below the **Broadcast dg** threshold, the current broadcast storm is considered to be finished. If the threshold is exceeded again, a new broadcast storm diagnosis will be generated.
- **Total number of frames in all storms.** Total number of frames associated with all broadcast storms currently diagnosed by the analyzer.
- **Duration of broadcast storms.** Total length (in seconds) of all broadcast storms currently diagnosed by the analyzer.




Figure 4–5. Detail display for the diagnosis, "Broadcast storm."

Duplicate Network Address

The analyzer generates the **Duplicate net address** diagnosis when two or more DLC stations are associated with the same network address. In a DECnet environment, the **Duplicate Address percentage** threshold can be used to fine-tune this diagnosis. For more information on the **Duplicate Address percentage** threshold, see page 3-23.

The detail display for the **Duplicate net address** diagnosis provides the following information:

Network address	The network address associated with more than one DLC station.
DLC stations	The addresses of all DLC stations associated with the duplicate network address.

Figure 4-6 shows a typical detail display for the **Duplicate net address** diagnosis. In this example, the network address [192.42.252.50] is associated with both the DLC stations Sun 07972C and Intrln0591A2.




Figure 4-6. Detail display for the diagnosis, "Duplicate net address."

Excessive Repeated Requests

The analyzer generates the **Excessive repeated requests** diagnosis when the number of loops on a given connection exceeds the **Loop %** threshold of total application requests. For more information on the **Loop %** threshold and how the analyzer recognizes loop packets, see the sections "Filter Time," and "Loop Percentage," starting on page 3-18.

The detail display for **Excessive repeated requests** provides the following information:

Total requests loops	The total number of repeated requests sent out by this station. The requests can be of different types.
Mean time between requests	The total amount of time a station sends repeated requests divided by the total number of repeated requests.
Server impacted	Server impacted is the server to which this station sends the repeated requests.

Figure 4-7 shows a typical detail display for the Excessive repeated requests. In this example, the station ANCHOR has sent excessive repeated requests to the server BIZ-ONE.




Figure 4-7. Detail display for the diagnosis, "Excessive repeated requests."

Excessive Requests Denied

The analyzer generates the diagnosis **Excessive requests denied** when the percentage of denied versus successful application requests exceeds the **Denied request %** threshold in the **Expert settings** menu. For more information on this threshold, see page 3-19.

The information provided by the detail display for this diagnosis is described at the left of Figure 4-8.




Figure 4-8. Detail display for the diagnosis, "Excessive requests denied."

File Overlap / Retransmission

The analyzer generates the **File overlap/retransmission** diagnosis when the percentage of file transfers that are retransmissions has exceeded the **Slow file%** threshold in the **Expert Settings** menu. For more information on this threshold, see page 3-20.

This diagnosis indicates excessive retransmissions of the same file request, or overlap between two file requests. The detail display provides the following information.

- The address or symbolic name of the station sending repeated or overlapping file requests
- The total number of file transfers in which this station was involved
- The number of file transfers which were overlapping file requests
- The number of file transfers which were retransmissions

Figure 4-9 shows the detail display for the **File overlap/retransmission** diagnosis.




Figure 4-9. Detail display for the diagnosis, "File overlap/retransmission."

High Rate of Congestion

The analyzer generates the **High rate of congestion** diagnosis when it detects a particular station exhibiting more receiver congestion errors per minute than specified by the **RX Congestion** threshold. Receiver congestion errors occur when a station detects a frame on the ring with its own destination address but is unable to copy it because of a lack of buffer space. For more information on the **RX Congestion** threshold, see page 3-26.

Figure 4-10 shows a typical detail display for the **High rate of congestion** diagnosis. In this example, there have been 69 total receiver congestion errors detected for the station MajorDomo. The information provided by this detail display is described at the left of Figure 4-10.




Figure 4-10. Detail display for the diagnosis, "High rate of congestion."

High Rate of Line or Burst Errors

The analyzer generates the **High rate of line/burst errors** diagnosis when the total MAC level line errors plus burst errors for a particular station exceeds the **Ring errors** threshold. For more information on the **Ring errors** threshold, see page 3-27.

Figure 4-11 shows a typical detail display for the **High rate of line/burst errors** diagnosis. In this example, the station AGNES has had a total of 2309 line errors plus burst errors during this capture session. The information provided by this detail display is described at the left of Figure 4-11.




Figure 4-11. Detail display for the diagnosis, "High rate of line/burst errors."

High Rate of Physical Errors

The analyzer generates the diagnosis **High rate of physical errors** when the number of physical errors per second detected for a given station exceeds the **Physical err** threshold in the Expert settings menu. For more information on how the analyzer tracks physical errors, refer to page 3-25.

The detail display for the **High rate of physical errors** diagnosis includes the following information:

Name	The address or symbolic name of the offending station.
Packet count	The total number of packets exhibiting physical errors sent by the offending station. You can press Enter to see the Network Object Detail display. That display shows both the number of physical error packets sent and received by the offending station.
Physical error rate	The maximum rate of physical error packets per second sent by the offending station.

Figure 4-12 shows a typical detail display for the **High rate of physical errors** diagnosis. In this example, the station SALES has transmitted a total of 266 packets exhibiting physical errors. The maximum rate at which these physical error packets were sent was 14/second, exceeding the default **Physical err** threshold of 4/second per station.




Figure 4-12. Detail display for the diagnosis, "High rate of physical errors."

High Rate of Remove from Ring Requests

The analyzer generates the diagnosis **High rate of remove from ring requests** when the rate of Remove from Ring requests detected by the analyzer exceeds the **Station Removed** threshold in the Expert Settings menu. Remove from Ring requests are sent by the Configuration Report Server, a virtual ring entity responsible for overall ring health. For more information on the **Station Removed** threshold, see page 3-27.

Figure 4-13 shows a typical detail display for the **High rate of remove from ring requests** diagnosis. The display shows the number of remove from ring requests per minute detected by the analyzer. Pressing Enter from this display shows the addresses of the stations to which remove from ring requests have been sent.




Figure 4-13. Detail display for the diagnosis, "High rate of remove from ring requests."

High Rate of Ring Entries

The analyzer generates the **High rate of ring entry** diagnosis when the number of ring entries per minute for a given station exceeds the **Ring entries** threshold. For more information on the **Ring entries** threshold, see page 3-26.

Figure 4-14 shows a typical detail display for the **High rate of ring entry** diagnosis. In this example, the station AGNES has entered the ring five times. The information provided by this display is described at the left of Figure 4-14.




Figure 4-14. Detail display for the diagnosis, "High rate of ring entry."

High Rate of Ring Purges

The analyzer generates the **High rate of ring purges** diagnosis when the number of purge frames per minute sent by a given station exceeds the threshold specified by **Rng purge dg** in the Expert settings menu. Ring purge frames are sent by the active monitor when it detects that a token has been lost. For more information on the **Rng purge dg** threshold, see page 3-27.

Figure 4-15 shows a typical detail display for the **High rate of ring purges** diagnosis. In this example, the station SALES-323 has sent a total of 1899 ring purge frames during this capture session. The information in the detail display for this diagnosis is described at the left of Figure 4-15.




Figure 4-15. Detail display for the diagnosis, "High rate of ring purges."

LAN Overloaded

The analyzer generates the **LAN overloaded** diagnosis when the percentage of each minute the network is in burst mode exceeds the **LAN overload %** threshold. Whether the network is considered to be in burst mode depends on the setting of the **LAN overload** threshold. For a detailed discussion of these two thresholds and how they interact, see page 3-24.

Because the **LAN overloaded** diagnosis is directly related to the quantity of **Network overload** symptoms, the detail display shows the name or symbolic address of each network station whose traffic is associated with a **Network overload** symptom. Included in the display is the exact number of **Network overload** symptoms with which each particular station is associated. The stations are organized in descending order. Figure 4-25 shows the detail display for the **LAN overloaded** diagnosis.

Each listed station is associated with one or more Network overload symptoms. The number in parentheses shows exactly how many. Notice that the stations are organized in descending order.




Figure 4-16. Detail display for the diagnosis, "LAN overloaded."

Local Router

The analyzer generates the diagnosis **Local router** when two DLC stations on the same network segment are communicating via one or more routers, rather than directly from one DLC station to the other.

The detail display for this diagnosis is shown in Figure 4-17. The information in the detail display is described at the left of Figure 4-17.




Figure 4-17. Detail display for the diagnosis, "Local Router."

Multiple Routers to Station

The analyzer generates the diagnosis **Multiple routers to station address** when there are more routers on the local network that can route to a remote station than specified by the **Multiple routers** threshold in the **Expert Settings** menu. For more information on the **Multiple routers** threshold, see page 3-22.

The detail display for the diagnosis **Multiple routers to station** is shown in Figure 4-18. The information in the detail display is described at the left of Figure 4-18.




Figure 4-18. Detail display for the diagnosis, "Multiple routers to station."

Non-Responsive Station

The analyzer generates the diagnosis **Non-responsive station** (and considers a connection broken) when the number of consecutive identical retransmissions without response on a given connection exceeds the **No Responses** threshold in the **Expert Settings** menu.

The analyzer considers a broken connection to start when the number of retransmissions exceeds the **No responses** threshold and to end when the sender sends a new packet. Figure 4–19 illustrates how the analyzer calculates the duration of a broken connection.




Figure 4–19. How the analyzer calculates a broken connection.

Figure 4-20 shows the detail display for the diagnosis **Non-responsive station**. For more information on the **No responses** threshold, see page 3-21.




Figure 4-20. Detail display for the diagnosis, "Non-responsive station."

Retransmissions

The analyzer generates the **Retransmissions** diagnosis when the number of retransmissions (expressed as a percentage of total frames on the connection) exceeds the **Retrans %** threshold. For more information on the **Retrans %** threshold, see page 3-21.

The detail display for the **Retransmissions** diagnosis provides the following information:

- The addresses or symbolic names of the endpoint of the connection exhibiting the **Retransmission** diagnosis
- The total number of frames sent on this connection
- The number of frames retransmitted on this connection

Figure 4-21 shows a typical detail display for the **Retransmissions** diagnosis. In this example, 29 frames have passed between the server RND and the workstation AGNES. Of these 29 frames, two were retransmissions.




Figure 4-21. Detail display for the diagnosis, "Retransmissions."

Ring Beaconing

The analyzer generates the **Ring beaconing** diagnosis when it detects a single MAC beacon frame. Beacon frames indicate that there is a problem in the token ring that makes the ring inoperable. A ring can be beaconing due to a physical break in the ring or a timeout during active monitor contention.

The information at the left of Figure 4-22 describes the contents of a typical detail display for the **Ring beaconing** diagnosis.




Figure 4-22. Detail display for the diagnosis, "Ring beaconing."

Slow File Transfer

The analyzer generates the **Slow file transfer** diagnosis when the ratio of slow versus normal file transfers is greater than the **Slow file %** threshold in the Expert settings menu. For more information on this threshold and how the analyzer determines whether a file transfer is "slow," see the "Denied Request Percentage" and "Slow File Percentage" sections, starting on page 3-19.

The detail display for the **Slow file transfer** diagnosis shows the address or symbolic name of the station that requests the file transfer, as well as the number of slow file transfers versus total file transfers. Figure 4-23 shows a typical detail screen for the **Slow file transfer** diagnosis.




Figure 4-23. Detail display for the diagnosis, "Slow file transfer."



In Figure 4-23, notice that the analyzer has printed the message, "High amount of data transferred on this connection!" When the Expert analyzer notices a network event it considers particularly troublesome, it will sometimes print a warning message directly on the screen. In this case, the workstation, "RICH," is involved in a dangerously high-traffic connection. To view statistics on this connection, press Enter to see the Application Detail screen containing the address of the server responding to Rich's requests and any symptoms that may be associated with this connection.

Slow Server

The analyzer generates the **Slow server** diagnosis when the ratio of slow responses to total responses for a particular station exceeds the **Slow resp %** threshold in the Expert settings menu. For more information on this threshold and how the analyzer determines whether a response is "slow," see the "Minimum Application Requests" and "Response Time" sections, starting on page 3-17.

The detail display for the **Slow server** diagnosis shows the name or symbolic address of the slow server. The display also shows the name or symbolic address of each station that has received a slow response from the named server. The analyzer adds a station name to the list as soon as it detects that the station has received a slow response from this server. Figure 4-24 shows the detail display for the **Slow server** diagnosis.




Figure 4-24. Detail display for the diagnosis, "Slow server."

Underloaded Network

The analyzer generates the **Underloaded network** diagnosis when the duration of an underload condition exceeds the **Underload Timer** threshold. Whether the network is considered to be in an underload condition depends on the setting of the **WAN underload** threshold. If the network load (for both DTE and DCE) is less than that specified by **WAN underload**, then the analyzer considers the network to be in an underload condition. For a detailed discussion of these two thresholds and how they interact, see page 3-28.

The detail display shows the name or symbolic address of the most active stations during the WAN underload.




Figure 4-25. Detail display for the diagnosis, "Underloaded network."

Symptom and Network Object-Related Displays

This section describes the various displays accessible from the **Objects/Symptoms** column of the Expert Overview. The Expert displays accessible from the **Diagnoses** column of the Expert Overview are described starting on page 4-10. Note that the same displays are available in the Expert window regardless of whether the analyzer is capturing or displaying frames.

You may want to refer to Figure 4-1 on page 4-4 for a schematic of the various Expert windows and how they relate to one another.

About Symptom and Network Object-Related Displays

Symptom and Network Object displays are similar to the various diagnosis-related displays, except that:

- The counts pertain to symptoms detected, not diagnoses.
- Even if no symptoms are detected at a particular layer, you can still select that layer and press Enter to display a list of connections, network addresses, or DLC addresses.
- The **Objects/Symptoms** column also displays pairs of communicating subnets. You can highlight the subnet field and press Enter to see a list of communicating subnet pairs. (The purpose of this field is to provide more information about the subnets; symptoms are not associated with subnets.)
- The **Objects/Symptoms** column also displays Global Symptoms. Global symptoms include LAN and WAN Overloads.

You can navigate through the symptom and network object-related displays just as you would the diagnosis-related displays. Highlighting a field and pressing Enter causes a Summary window to appear. However, the Symptom and Network Object Summary displays are different from the Diagnosis Summary displays, inasmuch as they display a list of *all* network objects detected by the Expert analyzer instead of just those exhibiting symptoms.

Symptom and Network Object Summary Windows

Symptom and Network Object Summary windows provide a list of all network objects detected by the Expert analyzer at the highlighted Expert layer. The Summary windows act as a gateway to the more detailed windows, summarizing general data about the various applications, connections, network stations, and DLC stations detected by the analyzer.

For example, Figure 4-26 shows the Summary window at the Expert Application layer. It lists all the Application layer connections detected by the analyzer during this capture session, the addresses of the connecting stations, the number of frames that have passed between the two stations, and the number of symptoms associated with those frames. From here, the display shows that the connection between the workstation, BLAIR, and the server BIZ-ONE currently has 123 associated symptoms, including the last symptom

detected, **Low throughput**. You can explore this connection further by highlighting it and pressing Enter to see the related Detail window.




Figure 4-26. Symptom and Network Object Summary window at the Expert Application layer.

Displaying the Summary Window

The following procedure describes how to display the Summary window at any of the Expert layers.



To display a Summary window at any of the Expert layers:

- From the Symptom and Network Object Overview, use the cursor keys to highlight the desired Expert layer. The available Expert layers include:
 - Application Layer
 - Connection Layer
 - Network Station Layer
 - Subnet Pairs
 - DLC Station Layer
 - Global Symptoms

Note: Subnet Pairs and Global Symptoms are not true Expert layers. The purpose of these fields is to provide more information about communicating subnet pairs and global symptoms, such as traffic bursts.

- Press Enter.

Result: The Summary window for the selected layer appears, displaying a list of connections, network addresses, or DLC addresses. The exact format of the display depends on the Expert layer selected.

Result: The Summary window for the selected layer appears, displaying a list of connections, network addresses, or DLC addresses. The exact format of the display depends on the Expert layer selected.

Information in the Summary Windows

The information presented in the Summary windows is very similar at each of the four Expert layers. However, the Subnet Pairs and Global Symptom windows are slightly different. Those windows are described in later sections.

The Summary windows for the Network Station and DLC layers will contain less information than those at the Application and Connection layers. This is because the analyzer detects information for single stations at the Network Station and DLC layers, whereas at the Application and Connection layers it detects information about connections between two stations. This means that there is twice as much address information to present in the Summary windows for these Expert layers.

Figure 4-27 is an example of the Summary window at the Network Station layer. Notice that the information presented is very similar to that in Figure 4-26 but for only one station.




Figure 4-27. Network Station Summary window.

Information Fields in the Summary Windows

The list below summarizes (in alphabetical order) the information fields found in the Summary windows. Not all the information described here is found in every screen. The exact information in the Summary window depends on the Expert layer and the object highlighted.

Bytes	Can be either "Sent bytes," or "Received bytes." Specifies the number of bytes sent or received by the corresponding station. Available only in Network Station or DLC Station Summary window.
Conn	The total number of connections made by this station.
DLC Station Address	<p>The DLC addresses of the server, router, or other devices involved in the connection. When the DLC address is not the same as the network address, the analyzer will display the address in parentheses. This can happen when frames are routed to a station from a remote segment. In that case, the analyzer displays the DLC address and name of the router rather than that of the remote station (the net station address will be the actual address of the remote station). See Figure 4-40 on page 4-51 for a graphic representation of this phenomenon.</p> <p>The analyzer will also display a + sign in front of those DLC stations which have been reached by more than one router.</p>
Frames	In the Connection Summary window, Frames is the total number of frames transmitted on the specified connection. In the Network Station and DLC Station Summary windows, Frames is measured separately for frames sent and frames received by each station detected by the Expert analyzer.
Last Symptom	A one-line identifier of the last symptom associated with this connection or station.
Net Station Address	<p>The network addresses of the stations involved in the connection. If the Expert analyzer has learned the names associated with the addresses, it will display them instead of the hex, IP, or DECnet addresses.</p> <p>The analyzer automatically attempts to interpret the first three bytes of the address as the name of the NIC's manufacturer. When it is able to find the manufacturer's code in its table of manufacturers, the analyzer replaces the first three bytes of the station address with an ASCII abbreviation of the manufacturer's name. For example, in Figure 4-28, the characters, "NwkGnl," are substituted for the hex characters 000065.</p>
Protocol	A one-line identifier of the protocol used on a connection or by a station. If the analyzer does not recognize the protocol in use, it will substitute the well-know port name (which is usually also a protocol name, such as Telnet or FTP).

Requests	The number of application requests made on the highlighted connection.
Symptoms	The total number of symptoms associated with this connection or station.

Keep in mind that the Expert analyzer will dynamically update the Summary window as it learns more about the network to which it is attached. For example, as soon as the analyzer knows the symbolic name associated with a station address, it will substitute that name for the hex address.

Changing the Format of the Summary Window

The information found in each Summary window is a subset of the information in the list above. However, you can vary the information fields in the Summary window at all four Expert layers:

- Application
- Connection
- Network Station
- DLC Station

The following procedure explains how to change the format of the Summary window.



To change the format of the Summary window:

1. Display the Summary window for the desired layer. See page 4-37 for complete instructions.

Result: Depending on the layer of the Summary window, a label for the function key F4 appears at the bottom of the display. The label for the function key will change depending on the display format it will bring up next. For example, in one view it reads, "View DLC Stn," and in another, "View protocol."

2. Press F4.

Result: Pressing F4 allows you to cycle through the Summary display formats available at the specified layer. Each time you press F4, the information fields in the Summary window will change.

The following sections describe the various display formats available in the Summary window for each Expert layer.

Application and Connection Layer Summary Window

Figure 4-28 shows the default format for the Application Summary window.




Figure 4-28. The default Application Summary window.

Notice that the Summary window lists the network addresses of the endpoints of each application layer connection detected by the analyzer. You can also view the connections in terms of the DLC addresses of the two endpoints. The display formats available for the Connection Summary window are exactly the same as those available at the Application layer. The only difference is that the Application Summary window counts application requests while the Connection Summary window counts the total number of frames transmitted on a connection. The available display formats for the Summary windows at the Application and Connection layers are summarized in Figure 4-29.

Shown in...	Format	Column Entries				
Figure 4-28	Net Station Format (default)	Net Station 1	Net Station 2	Requests Frames*	Symptoms	Last Symptom
Figure 4-30	DLC Station Format	DLC Station 1	DLC Station 2	Requests Frames*	Symptoms	Last Symptom
Figure 4-31	Protocol Format	Net Station 1	Net Station 2	Requests Frames*	Symptoms	Protocol

*The Frames counter appears in the Connection Summary window, while the Requests counter appears in the Application Summary window.

Figure 4-29. Application and Connection layer Summary window formats.

Figure 4-30 shows the Application Summary window in the DLC Station format.




Figure 4-30. Application Summary window in DLC station format.

Figure 4-31 shows the Connection Summary window in the Protocol format.




Figure 4-31. Connection Summary window in Protocol format.

Network Station Summary Window

Figure 4-32 shows the default format for the Network Station Summary window. The information fields found in the Network Station Summary window are described beginning on page 4-38.




Figure 4-32. Network Station Summary window.

The available display formats for the Network Station Summary window are summarized in Figure 4-33.

Format	Column Entries					
Protocol Format	Net Station	Frames Sent	Frames Received	Connections	Symptoms	Protocol
Symptom Format	Net Station	Frames Sent	Frames Received	Connections	Symptoms	Last Symptom
DLC Station Format	DLC Station	Frames Sent	Frames Received	Connections	Symptoms	Last Symptom
Bytes Format	Net Station	Bytes Sent	Bytes Received	Connections	Symptoms	Last Symptom

Figure 4-33. Network Station layer Summary window formats.

DLC Station Summary Window

Figure 4-34 shows the Protocol display format for the DLC Station Summary window. The information fields found in the DLC Station Summary window are described beginning on page 4-38.




Figure 4-34. DLC Station Summary window.

The available display formats for the DLC Station Summary window are summarized in Figure 4-35.

Format	Column Entries				
Symptom Format	DLC Station	Frames Sent	Frames Received	Symptoms	Last Symptom
Bytes Format	DLC Station	Bytes Sent	Bytes Received	Symptoms	Last Symptom
Protocol Format	DLC Station	Frames Sent	Frames Received	Symptoms	Protocol

Figure 4-35. DLC Station Summary window formats

Subnet Pairs Summary Window

The Subnet Pairs Summary window lists all the pairs of communicating subnets detected by the Expert analyzer during its current capture session. The Expert analyzer learns about subnets by analyzing the information in the frames it captures. Symptoms are not categorized as occurring "at the subnet layer." The symptom counts in the Subnet Pairs Summary window refer to symptoms at all four Expert layers associated with the highlighted pair of subnets.

The Subnet Pairs Summary window (Figure 4-36) contains the following information:

Subnet 1	A subnet which the Expert analyzer learned about from routing information embedded in frames. When the analyzer learns the symbolic name of the subnet, it will substitute it for the hex address.
Subnet 2	Often the address of the subnet to which the Expert analyzer is attached. The analyzer provides the subnet address.
Frames	If there is a pair of subnets listed, the Frames count measures the total number of frames that have been transmitted between the two subnets. If there is only one subnet listed (instead of a pair), then the Frames count describes the activity internal to that subnet.
Hops	The hop count between the two subnets. If the hop count is zero, it indicates either a local subnet or that no Routing Information Protocol (RIP) packets have been seen.
Symptoms	The total number of symptoms associated with traffic between these two subnets at the Expert Application and Connection layers. A subnet that has a high ratio of symptoms to packets is likely to have some kind of problem, or an area in which operation can be made more efficient.
Protocol	The protocol in use on Subnet 1.




Figure 4-36. Subnet Pairs Summary window.

Global Symptom Summary Window

The Global Symptom Summary window provides information on global symptoms detected by the Expert analyzer during its current capture session.

Global symptoms include, but are not limited to:

- Network Overload
- Broadcast/Multicast Storm
- WAN Underload

Figure 4-37 shows the Global Symptom Summary window.




Figure 4-37. Global Symptom Summary window.

The Global Symptom Summary window contains the following information:

- | | |
|------------|---|
| Start Time | The time and date at which the symptom was first detected by the analyzer. |
| Duration | The length of time (in milliseconds) during which the symptom was valid. |
| | If there is an asterisk in the far left column, as in Figure 4-37, the symptom is still active. |
| Symptom | A one-line description of the symptom detected. |



You can control when the analyzer generates Network Overload symptoms and diagnoses by setting the **LAN Overload** and **LAN Overload %** thresholds in the **Expert Settings\Thresholds\DLC Station** menu. Similarly, WAN Overload symptoms and diagnoses are controlled by the **WAN Overload Timer** and

WAN Overload % thresholds. Broadcast/Multicast storm symptoms and diagnoses are controlled by the **Broadcast sy** and **Broadcast dg** thresholds. For information on Expert thresholds, refer to "Setting Thresholds for Symptoms and Diagnoses" on page 3-13.

Symptom and Network Object Detail Windows

The Symptom and Network Object Detail windows provide specific information about particular connections, network stations, or DLC stations. Figure 4-38 shows the Detail window for a connection between the NetWare server BIZ-ONE and the workstation AGNES at the Application layer. The analyzer provides the DLC and network addresses of the endpoints of the connection, the protocol in use, and a list of all the symptoms associated with this connection. At this point, you would probably pause capture by pressing F9 (**Pause**), and press F1 (**Explain**) to read the context-sensitive Explain message associated with these symptoms.




Figure 4-38. Application Detail window.

Displaying the Detail Window

There are two ways to display the Detail window:

- From the Symptom and Network Object column of the Expert Overview
- From the Diagnoses column of the Expert Overview



To display a Detail window from the Symptom and Network Object column of the Expert Overview:

1. In the Symptom and Network Object column, use the cursor keys to highlight the Expert layer containing the connection, network station, or DLC station in which you are interested.
2. Press Enter.

Result: The Summary window for the selected Expert layer appears.

3. Use the cursor keys to highlight the desired connection, network station, or DLC station in the Summary window.
4. Press Enter.

Result: A Detail window similar to Figure 4-38 appears. The exact format of the Detail window depends on the layer selected and the number of symptoms detected.

You can also display a Symptom and Network Object Detail window from the Diagnoses column of the Expert Overview.



To display a Symptom and Network Object Detail window from the Diagnoses column of the Expert Overview:

1. In the Diagnoses column of the Expert Overview, use the cursor keys to highlight an Expert layer containing at least one diagnosis.
2. Press Enter.

Result: The Diagnosis Summary for the selected layer appears.

3. Use the cursor keys to highlight the desired diagnosis and press Enter.

Result: The Diagnosis Detail window appears.

Note: The Diagnosis Detail window is different from the Symptom and Network Object Detail window. The Diagnosis Detail window provides specific information on a diagnosis, while the Detail window provides more general information such as network addresses, DLC addresses, and symptoms detected.

4. Press Enter.

Result: The Detail window for the connection, network station, or DLC station associated with the selected diagnosis appears. Figure 4-38 is an example of a Detail window.

Note: From the Diagnoses column of the Expert Overview, you cannot display the Subnet Pairs or the Global Symptom Detail windows. These windows can only be displayed from the Symptom and Network Object column of the Expert Overview.



Note: From the Symptom and Network Object column of the Expert Overview, you can use the cursor keys to scroll through the Detail windows for each connection, network station, or DLC station listed in the Summary display (from the Diagnoses column of the Expert Overview, you cannot). When you return to the Summary window from the Detail windows, the analyzer will

automatically highlight the connection or address associated with the Detail display from which you came.

Figure 4-1 on page 4-4 summarizes the relationships between the various Expert windows.

Information in the Detail Windows

The information presented in the Detail windows is very similar at each of the four Expert layers. However, the Subnet Pairs and Global Symptom Detail windows are somewhat different. Those windows are described in later sections.

The Detail windows for the Network Station and DLC layers will contain less information than those at the Application and Connection layers. This is because the analyzer detects information for single stations at the Network Station and DLC layers, while at the Application and Connection layers it detects information about connections between two stations. This means that there is twice as much address information to present in the Detail window.

Figure 4-39 is an example of a Detail window at the Network Station layer. Notice that the information presented is the same as in Figure 4-38 but for only one station.




Figure 4-39. Network Station Detail window.

The list below summarizes the information found in the Detail windows. Not all the information is found in every screen. The exact information in the Detail display depends on the Expert layer and the object highlighted.

Protocol	The protocol in use on this connection. If the analyzer does not recognize the protocol in use, it will substitute the well-know port name (which is usually also a protocol name, such as Telnet or FTP).
Appl ID	<p>The application ID for this connection. Most protocols use an identification scheme to give unique names to connections between network stations. The Expert analyzer learns the identification scheme for the particular protocol involved and displays that information.</p> <p>For example, TCP uses Port numbers, DECnet uses Logical link numbers, and Novell uses Connection IDs. The Expert analyzer displays the identification scheme appropriate to the protocol in use.</p>
Net name	The symbolic name for this station. This field will remain blank until the analyzer learns the symbolic name.
Net addr	The network address of this station.
subnet	The subnet on which this station resides.
DLC name	The symbolic DLC name for this station. This field will remain blank until the analyzer learns the symbolic name.
DLC addr	<p>The DLC address for this station. The analyzer automatically attempts to interpret the first three bytes of the address as the name of the NIC's manufacturer. When it is able to find the manufacturer's code in its table of manufacturers, the analyzer replaces the first three bytes of the station address with an ASCII abbreviation of the manufacturer's name.</p> <p>The DLC address of a station may be different than the network station address. This occurs when the analyzer captures frames from a remote station. The analyzer will show the DLC address of the router rather than that of the originating station. When this occurs, the DLC address will be followed by the message (remote routed). Figure 4-40 shows how this can happen.</p>

Because the MIS server is remote to Bob's Station (i.e., separated by a router), the analyzer will show frames routed from the MIS Server to Bob's Station as having the net station address "MIS" but having the DLC name "BIZ-ONE" and the DLC address "Novell03E076" (i.e., that of the router). Because the DLC name and address are different from the net station name and address, the analyzer will display it in parentheses in the Summary display.




Figure 4-40. How the analyzer interprets the DLC name and address of remote stations.

Total symptoms

Total number of symptoms associated with this connection or station. The Detail window also lists each symptom associated with the selected connection or station, followed by a dynamic counter.

Detail windows will often include a short message about a particular symptom detected by the analyzer. For more information on these messages, press F1 (**Explain**) to invoke the Explain message pertinent to the current display.

Subnet Pairs Detail Window

The Subnet Pairs Detail window displays the number of packets transferred between two subnets and the number of symptoms (at the Connection and Application Expert layers) associated with those packets. The symptoms are presented with an individual counter for each Expert layer.

Additionally, the Detail window lists any routers used to access the subnet on which the Expert analyzer is not attached. The hop count is included. Figure 4-41 is an example of a Subnet Pairs Detail window.

You can scroll through the Detail windows for all subnets detected by the analyzer.




Figure 4-41. Subnet Pairs Detail Window.

The list below describes the information in the Subnet Detail window:

Hop count between subnets	Lists the number of hops between these two subnets.
Frames	Lists the number of frames exchanged at the Expert Connection layer. The % of total frames counter is the ratio between the number of frames exchanged at the Expert Connection layer and the total number of frames exchanged at all layers. This gives you an idea of the "useful" traffic on your network.
Routers to subnet	Lists the routers used to access the subnet.
Symptoms	Lists the number of symptoms detected at the Application and Connection Expert layers.

The information in the Subnet Pairs Detail window varies according to the protocol in use. For example, Figure 4-41 shows the Subnet Pairs Detail window for a pair of communicating Novell subnets. The Subnet Pairs Detail window for a DECnet network includes protocol-specific information, such as DECnet areas. TCP/IP Subnet Pairs Detail windows are similar to the Novell window. However, you should be aware of how to define the subnet mask for the various TCP/IP networks to which you will attach the Expert analyzer. See "Setting Subnet Masks" on page 3-7 for more information on defining the subnet mask.

You display the Subnet Pairs Detail window in the same way you display any Detail window. See "To display a Summary window at any of the Expert layers:" on page 4-37.

Note: One of the entries in the Subnet Summary window will not list a pair of communicating subnets. That is the entry for the subnet to which the Sniffer Network Analyzer is attached. Its Detail window will measure frames and symptoms for its specific subnet alone.

Global Symptom Detail Window

The Global Symptom Detail window provides specific information on certain global symptoms. Global symptoms include:

- LAN Overload
- Broadcast/Multicast Storm
- WAN Overload
- WAN Underload

You can control when these symptoms are generated by adjusting the Expert thresholds. For more information on Expert thresholds, see "Setting Thresholds for Symptoms and Diagnoses" on page 3-13.




Figure 4-42. Global Symptom Detail window.

The Global Symptom Detail window (Figure 4-42) is displayed in the same way you display any Detail window. See "To display a Summary window at any of the Expert layers:" on page 4-37.

Information in the Global Symptom Detail Window

The list below summarizes the information found in the Global Symptom Detail Window:

Active time	Length of time for which the LAN Overload or Broadcast/Multicast storm symptom was active.
State	Current status of the named symptom. Status is either closed or active.
Max load %	Maximum network load during the time the named symptom was active. Measured as a percentage of available bandwidth, where available bandwidth is the theoretical maximum of the medium in use (for example, 10 Mbps is the theoretical maximum for Ethernet).
Average load %	Average network load during the time the named symptom was active. Measured as percentage of available bandwidth (see Max load % , above).
Broadcasts	Number of broadcast frames detected.
Active stations	Number of active stations transmitting during the time the LAN Overload or Broadcast\Multicast storm symptom was active. The stations are listed by address or symbolic name.
Frames	Total number of frames associated with the highlighted overload.
Symptoms	Total number of symptoms associated with frames associated with highlighted overload.

Symptom and Network Object Statistics Windows

Statistics windows provide in-depth statistics relating to a selected application, connection, network station, or DLC station. Statistics windows provide information on topics such as average file performance, number of frames sent, and the number of connections for a given station. The exact information depends on the layer for which the Statistics window is displayed and the protocol in use.

The following sections describe the Statistics windows for each of the following Expert layers:

- Application
- Connection
- Network Station
- DLC Station



Note: There are no Statistics windows associated with the Subnet Pairs or Global Symptom screens.

Displaying a Statistics Window

There are two ways to display a Statistics window:

- From the Symptom and Network Object column of the Expert Overview
- From the Diagnoses column of the Expert Overview



To display a Statistics window from the Symptom and Network Object column of the Expert Overview:

1. In the Symptom and Network Object column of the Expert Overview, display the Summary window for the Expert layer containing the connection, network station or DLC station in which you are interested.
2. From the Summary window, display the Detail window for the desired connection, network station, or DLC station.
3. Press Enter.

Result: A Statistics window similar to Figure 4-43 appears. The exact format of the Statistics window depends on the layer selected, the protocol in use, and the number of symptoms detected.

You can also display a Statistics window from the Diagnoses column of the Expert Overview.



To display a Statistics window from the Diagnoses column of the Expert Overview:

1. In the Diagnoses column of the Expert Overview, use the cursor keys to highlight an Expert layer containing at least one diagnosis.
2. Press Enter.

Result: The Diagnosis Summary for the selected layer appears.

3. Use the cursor keys to highlight the desired diagnosis and press Enter.

Result: The Diagnosis Detail window appears.

4. Press Enter.

Result: The Detail window associated with the selected diagnosis appears. (This Detail window is different from the Diagnosis Detail window.)

5. Press Enter.

Result: The Statistics window associated with the selected diagnosis appears. Figure 4-43 shows a Statistics window at the Application layer.

Figure 4-1 on page 4-4 summarizes the relationships between the various Expert windows.

Application Statistics Window

The Application Statistics window provides statistics related to specific connections detected at the Application layer. Figure 4-43 is an example of the Statistics window for an Application layer connection between the server BIZ-ONE and the workstation MajorDomo.




Figure 4-43. Application Statistics window.

The Application Statistics window provides the following statistics:

Application requests	The number of file requests detected for this connection.
Total file transfers	The number of files transferred on this connection.
Hops	The number of hops between the endpoints of this connection.
Bytes transferred	The number of bytes transferred on this connection.

If the analyzer has detected at least one file transferred on a given connection, the Statistics window will also contain statistics on average file performance. Average file performance statistics include:

Throughput	Measures the average speed at which data was transferred between the two stations. Units are in Kbytes/s.
Packet data length	Average length of data packets on this connection. Units are in bytes.

Interframe time for station

Average response time for a given station. With a request/reply protocol such as Novell PEP, the Interframe time is simply the average of the delta times between when a station receives a request and when it sends a reply.

In a windowing protocol, such as TCP/IP, or DECnet, the Interframe time is the average of both the delta time between when a station receives a request and sends a reply and the delta times between replies to a single file request. Figure 4-44 summarizes how Interframe time is calculated for both types of protocols.




Figure 4-44. How the Expert analyzer calculates the value for Interframe time.

Connection Statistics Window

The Connection Statistics window provides information on specific connections detected at the Connections layer. The exact information in the Statistics window depends on the protocol in use. Figure 4-45 is an example of the Statistics window for a connection using the TCP/IP protocol.




Figure 4-45. Connection Statistics window (in this case, for TCP/IP).

The following information is found in the Connection Statistics window regardless of the protocol used:

Total frames	Total number of frames transmitted on this connection.
Total bytes	Total number of bytes transferred on this connection. This number includes the headers of all frames transmitted.
Hops	The number of hops between the endpoints of this connection.
Average frame length	The average length of the frames transmitted on this connection. Units are in bytes.

The Connection Statistics window also provides protocol-specific statistics. Figure 4-45 shows the statistics provided for a TCP/IP connection.

Network Station Statistics Window

The Network Station Statistics window provides statistics for individual network stations. Notice that the counters in Figure 4-46 are the same as those in the Connection Statistics window in Figure 4-45. However, in the Network Station window, these counters pertain to the highlighted station alone, rather than a connection. The list below summarizes the information found in the Network Station Statistics window.




Figure 4-46. Network Station Statistics window.

Total frames	Total number of frames transmitted and received by this station.
Total bytes	Total number of bytes transmitted and received by this station. This number includes the headers of all frames.
Hops	Total number of hops associated with frames sent and received by this station.
Average frame length	The average length of all frames transmitted and received by this station. Units are in bytes.
Absolute utilization	Network utilization for this DLC station computed as a percentage of maximum theoretical available bandwidth. For example, the theoretical maximum available bandwidth for Ethernet is 10 Mbps. Absolute utilization is updated every second and is measured over the time period since the first frame of the current capture session was passed into the capture buffer.

Relative utilization	Network utilization for this DLC station computed as a percentage of traffic seen by the analyzer. For example, if the analyzer has seen 100 bytes of traffic and Station A has sent 50 of them, then Station A's relative utilization is 50 percent.
Connections to net stations	<p>The Statistics window lists all DLC stations to which the highlighted station has connected, as well as a counter of how many times.</p> <p>In Figure 4-46, the network station Alice has connected to the DLC station Jeff once.</p>
Associated DLC addresses	The Statistics window provides the DLC addresses of stations associated with the selected network station (see below).

If frames have been routed from a remote network segment, the two stations may not be the same. In that case, the associated DLC station would probably be the router or server through which the frames were routed. If this is the case, the hop count will be greater than one, indicating that frames have been remote routed. Then, the DLC station address will probably be different from the network station address.

DLC Station Statistics Window

Just as the Network Station Statistics window provides statistics for network stations, the DLC Station Statistics window provides statistics for DLC stations. Figure 4-47 shows the DLC Station Statistics window for the DLC station BIZ-ONE.




Figure 4-47. DLC Station Statistics Window.

The DLC Station Statistics window is very similar to the Network Station Statistics window, inasmuch as it contains several of the same counters. These counters include:

- Total frames
- Total bytes
- Average frame length

However, the DLC Station Statistics window also provides the following information:

Absolute utilization

Network utilization for this DLC station computed as a percentage of maximum theoretical available bandwidth. For example, the theoretical maximum available bandwidth for Ethernet is 10 Mbps.

Absolute utilization is updated every second and is measured over the time period since the first frame of the current capture session was passed into the capture buffer.

Broadcasts/Multicasts

Number of broadcast/multicast frames sent and received.

Received/Sent	<p>On an Ethernet network, the Statistics window describes the type of Ethernet frames sent and received by the highlighted station. In Figure 4-47, the DLC station, "BIZ-ONE," sent and received 802.3 and other Ethertype frames.</p>
Relative utilization	<p>Network utilization for this DLC station computed as a percentage of traffic seen by the analyzer. For example, if the analyzer has seen 100 bytes of traffic and Station A has sent 50 of them, then Station A's relative utilization is 50 percent.</p>
Associated network stations	<p>This field lists up to the first 21 network station addresses with which the highlighted DLC station address is associated. If there are more than 21 stations, the analyzer generates the message, "xx network stations associated with this DLC station (first 21 shown below)."</p> <p>In Figure 4-47, since the DLC station, "BIZ-ONE," is a server, it transfers data for many network stations (leading its DLC address to be associated with a multitude of network station addresses. For an illustration of this concept, see Figure 4-40 on page 4-51). However, if the highlighted DLC station were a workstation, the Associated network stations list would probably include only the workstation itself.</p>

Additional Token Ring Counters in the DLC Station Statistics Window

On token ring, the DLC Station Statistics window provides the following additional information:

Station status	This field tells you whether the highlighted station is currently ON RING or OFF RING.
Upstream neighbor	Identifies the highlighted station's upstream neighbor by address or symbolic name.

Additionally, the DLC Stations Statistics window tabulates ring purge frames and informs you if the highlighted station is the active monitor.

The Global Statistics Window

The Global Statistics window provides a comprehensive percentage breakdown by protocol family of the traffic found on your network, as well as information about the current capture session. The information in the Global Statistics window is not immediately related to the investigation of symptoms and diagnoses; however, it does provide valuable insight on the types of traffic found on your network. Figure 4-48 shows the Global Statistics window for an Ethernet network.




Figure 4-48. The Global Statistics window.

The Global Statistics window is always available from the Expert Overview by using the F2 key. However, you cannot display the Global Statistics window from the various Expert subdisplays.



To display the Global Statistics window:

1. In the Expert Overview, notice the function key label F2 (**View stats**). Press F2.

Result: The Global Statistics window appears, as in Figure 4-48.

Note: After displaying the Global Statistics window, the function key label for F2 changes from **View stats** to **View expert**. You can use this key to toggle between the two views.

Composition of the Global Statistics Window

The Global Statistics Window consists of three categories of information:

- Composition of Traffic by Protocol Family
- Bandwidth Utilization

- Run Information

Each of these three categories is visible in Figure 4-48 and is described below.

Composition of Traffic by Protocol Family

The Expert analyzer dynamically tabulates all network traffic according to its protocol family. The results are presented both graphically (as a histogram) and as a numeric percentage. The thermometer-style horizontal bar allows you to see at a glance which count is increasing. The exact percentage of total traffic is displayed at the left end of the bar. For example, in Figure 4-48, TCP/IP traffic accounts for 54.33 percent of all network traffic, while AppleTalk accounts for only 4.42 percent.

How the Expert Analyzer Categorizes Packets into Protocol Families

In compiling the histogram, the expert system counts all the bytes in all the frames, except for the following.

1. Frames excluded by the capture filters.
2. Frames that arrive while capture is paused (F9 has been pressed).
3. Frames that are skipped because the expert analysis is unable to keep up with the influx of frames (in this case the “% analyzed” statistic, described below, will be less than 100%).
4. Internetwork analyzer only: FCS bytes, flag bytes and bits inserted by the bit-stuffing process.

Each frame is categorized into one of the protocol families listed at the left of the histogram. If none of the listed protocols apply, a frame is categorized as “Others”. If more than one protocol applies, a frame is categorized according to the highest protocol analyzed.

For example, on a Frame Relay link, all traffic can technically be considered to be Frame Relay. However, encapsulated within most of these Frame Relay packets are LAN packets with higher-level protocols— for example, IP. The Expert analyzer would categorize all bytes in a Frame Relay packet with an encapsulated IP layer as part of the TCP/IP family. The only Frame Relay packets that the analyzer would categorize into the Frame Relay protocol family would be LMI frames, such as FECN and BECN frames. This convention lets you answer questions such as, “By how much would traffic be reduced if we removed all the TCP/IP stations from this network segment?”

Note: The expert system does not always parse to the highest layer of a frame. For example, the current software release will not recognize an AppleTalk frame that is encapsulated in a TCP/IP frame. Therefore it will categorize such a frame as TCP/IP rather than AppleTalk.

“Protocol Family” is a generic term for a related set of protocols. For example, the TCP/IP protocol family counter in the Global Statistics screen tabulates all protocols with an IP layer— not just TCP over IP. The other Protocol Families operate similarly.

Percentage Bandwidth Utilization

This category of counters measures the average, current, and maximum percentage of bandwidth used during the current capture session. **Current bandwidth usage** is measured over the interval of one second, on a "sliding-window" basis. That is, a new measurement is made every tenth of a second over the interval of one second (that is, measurements would be made from 1.0 to 2.0 seconds, from 1.1 to 2.1 seconds, and so on). **Maximum percentage of bandwidth** is the largest of these "current" bandwidth usage values. **Average bandwidth usage** is calculated by counting all frames that have entered the buffer since the start of the current capture and dividing this value by the total number of seconds the analyzer has been capturing frames (not paused).

Note: Although the analyzer makes many measurements per second, the counters are updated only once every second.

On the Sniffer Internetwork Analyzer (the Sniffer analyzer for WAN/Synchronous), the counts for percentage bandwidth utilization are expanded to measure **From DTE** and **From DCE** separately.



The **From DTE** and **From DCE** percentage bandwidth utilization counters are separate from one another. That is, they do not need to add up to 100 percent. Each WAN link consists essentially of two separate pipes with traffic travelling in opposite directions. Since each "pipe" is independent of the other, percentage bandwidth utilization could theoretically go to 100 percent for either one.

Additionally, there are statistics for average, current, and maximum number of packets per second. For example, in Figure 4-48, the maximum number of packets per second during this capture session was 87, while the maximum percentage of bandwidth utilization was five percent.

Run Information

The Run Information counters provide statistics about the current capture session as follows:

Bandwidth	The theoretical maximum amount of traffic that could travel over the network being analyzed. For example, the Bandwidth counter for Ethernet is 10 Mbps. For networks that do not have an established theoretical maximum (such as WANs) the analyzer can use a variety of algorithms to "figure out" the theoretical maximum.
Duration	The length of time between the first frame accepted into the analyzer's capture buffer during the current capture session and the most recent frame accepted into the capture buffer. The Duration counter is incremented each time a new frame is accepted into the buffer. The increment is based on the elapsed time between the accepted frame and the previous frame.



The Elapsed time counter (in the upper right corner of the display) simply keeps a running total of the time elapsed since capture was started. Whereas the Elapsed time counter has an upper limit of 99:59:99 (100 hours), the Duration counter will measure accurately up to a maximum period of 42 days.

There will sometimes be some discrepancy between the Duration counter and the Elapsed time counter in the upper right corner of the display. This can happen for the following reasons:

- When capture is paused, the Elapsed time counter does not increment. However, the Duration counter is measuring real time since the first frame was accepted. Therefore, when capture is resumed, the Duration counter will jump ahead to where it is higher than the Elapsed time counter. The amount of time the Duration counter is greater than the Elapsed time counter will be equal to the amount of time capture was paused.
- Under heavy traffic loads, the clock may be slow as the analyzer devotes more processing time to incoming traffic. As the analyzer catches up, the clock will be updated.

Start run

The time and date the current capture session was begun.

Note: The time and date correspond to those that the PC regards as current. If the PC's time and date are incorrect, the analyzer's will be as well. You can use the DOS commands `Time` and `Date` to change the time and date the PC regards as current.

% Analyzed

Because the amount of data passing over a network segment is potentially huge, the Expert analyzer will sometimes develop a backlog of frames waiting to be analyzed. The **% Analyzed** counter details how much of the data from the current capture session has been analyzed. During heavy traffic loads, this counter may fall below 100 percent. When capture stops, the analyzer will continue to perform Expert analysis until all unanalyzed frames still in the capture buffer have been processed.

Note: Under heavy traffic loads, the Expert will sometimes skip frames, never performing Expert analysis on them. At the end of a capture session, the **% Analyzed** counter indicates the percentage of total frames (that is, those seen during the current capture session) analyzed, giving you an idea of how many frames the Sniffer "saw" but was unable to analyze.

Effects of Capture Filters on Global Statistics



The statistics in the Global Symptoms window are based solely on those frames that reach the capture buffer. If you have set capture filters (such as protocol filters, station address filters, or destination class filters), various frames that do not pass these filters will never reach the capture buffer. Accordingly, the Expert analyzer's Global Statistics will not take these frames into account. This can render the Expert's statistics inaccurate.

This is particularly misleading in the case of the capture filters for protocols. For example, if in a DECnet environment you set a capture filter to exclude all DRP frames, the Expert analyzer will falsely report that some inordinately small percentage of your network traffic is DECnet. To ensure accurate statistics, you should set capture filters carefully.

Effects of Frame Size Option on Global Statistics

The **Frame Size** option allows you to specify (in bytes) what portion of each frame is passed into the capture buffer by the Expert analyzer. You can elect to "slice" frames after 32, 64, 128, 256, and 512 bytes. Frame slicing exists to boost capture performance. However, because the Expert analyzer bases its Global Statistics solely on that data which is passed into the capture buffer, frame slicing can cause inaccurate statistics in the Global Statistics window.



Generally, the Expert analyzer needs the first 128 bytes of each frame to compile accurate Protocol Family statistics. If **Frame Size** is set lower than 128 bytes, inaccurate Protocol Family statistics will result. To ensure accurate Protocol Family statistics, you will want to set the **Frame Size** option to **Whole frame** (the default).

Expert Display Filters

This section describes display filters that are specific to the Expert analyzer. Display filters determine which frames in the capture buffer will be displayed. Eliminating a frame from display with a display filter does not remove the frame from memory. Rather, it simply removes the frame from display. If the display filter eliminating a given frame from display were to be disabled, that frame would reappear. For a complete discussion of available display filters, see the *Distributed Sniffer System: Analyzer Operations Manual*.

This section describes the following Expert display filters:

- Network object display filter
- Symptom frames display filter

Network Object Filter

From the Expert window, you can determine what frames to include in the display. For example, you can include in the subsequent display only those frames that are related to a particular diagnosis or that are transmitted on a selected connection. This avoids cluttering up the display with frames that are

irrelevant to the problem you want to investigate. The filtering is “automatic” because it does not require you to set up a filter as you normally would with the **Filters** option in the **Display** menu. Instead, you use the function key F2 (**Filter&disply**) to implement the **Network object** filter and determine the frames included for display.



The F2 key works as a toggle for setting and removing Network object filters. You cannot set a new **Network object** filter until you have cleared the existing one (unless, of course, there is no existing one).

The **Network object** filter does not remove frames from the capture buffer but omits them from the display. When some frames are skipped, the frames that remain visible have the same frame numbers as before. Thus, you may see frame 30 followed by frame 35 because the network object filter excludes frames 31-34.



To set an automatic Network object filter:

1. Display the contents of the capture buffer in the Expert window.
2. The Expert window appears. Display an Expert Summary screen and highlight one of the following:
 - In a Diagnosis Summary screen, a diagnostic message at any layer.
 - In a Symptom and Network Object Summary window, a connection at the Application or Connection layers, or a station at the Network Station or DLC Station layers.

The function key F2 (**Filter&disply**) appears at the bottom of the screen. Figure 4-49 shows the Diagnosis Summary screen at the Connection layer.

Note: If a **Network object** filter is already set, you will have to clear the existing filter before setting a new one. The label for the function key F2 will indicate this by reading **Remove filter** rather than **Filter&disply**. See “Removing the Network Object Filter” on page 4-75 for more information.

3. Press F2 (**Filter&disply**).

In response, the analyzer automatically filters out all frames irrelevant to the highlighted diagnosis, symptom, or network object, and takes you to the Classic window specified in the **Display** menu.

SUMMARY—Delta T—DST—SRC					
M	1	LTM listnrs	DEC	0971E5	Ethertype=803F (DEC LAN moni
	2	0.0121 LTM listnrs	DEC	069D6A	Ethertype=803F (DEC LAN moni
	3	0.0036 LTM listnrs	DEC	14D199	Ethertype=803F (DEC LAN moni
	4	0.0340 FFFFFFFF	U-B	DD6000	Network unknown, not analysed by
Connection Diagnosis Summary					
First Time		Duration		Diagnosis	
* 09/06 08:30:05		1m54s	Local router: BIZ-ONE & 02608C0DA329		
* 09/06 08:30:11		1m48s	Retransmissions: SALES & Paul		
09/06 08:30:21		21s	Retransmissions: SALES & Order Entry		
09/06 08:30:30		36s	Retransmissions: SALES & KATHY		
4 of 4, 0 removed; Use ↑, ENTER to see detail, ESC to return					
Use F2 to filter frames on this connection and return to data display					
1	2	3	5	7	10
Explain	Remove	Data	Menus	Remove	New
	filter	display		diag	capture

Figure 4-49. Setting a Network object filter. Notice the function key F2.

Example: Setting a Network Object Filter

For example, in Figure 4-49 the analyzer has diagnosed four problems at the Connection layer. If you want to focus on the frames that are relevant to the highlighted diagnosis ("Retransmissions between SALES and Kathy"), highlight the diagnostic message. Then press F2 (**Filter&disply**) to display only those frames relevant to the highlighted diagnosis. The subsequent display is shown in Figure 4-50. Notice that the display starts with frame 448 and that the frame numbers are not contiguous. The displayed frames are the ones that lead to the diagnosis, "Retransmissions between SALES and Kathy."

SUMMARY	Delta T	DST	SRC	
448		KATHY	SALES	NCP R OK
449	0.0015	SALES	KATHY	NCP C Propose buffer size of 102
662	3.7548	SALES	KATHY	NCP C Propose buffer size of 102
816	2.2551	SALES	KATHY	NCP C Propose buffer size of 102
2382	5.0895	KATHY	SALES	Wrong reply sequence
				NCP R OK
2791	7.8534	SALES	KATHY	NCP C Propose buffer size of 102
2792	0.3288	KATHY	SALES	NCP R OK Accept buffer size of 1
2794	1.3018	SALES	KATHY	NCP C Logout
2798	0.3244	SALES	KATHY	Transport retransmission
				NCP C Logout
2800	0.1573	SALES	KATHY	Transport retransmission
				NCP C Logout
2806	0.6434	SALES	KATHY	Transport retransmission
				NCP C Logout
2822	2.1982	SALES	KATHY	NCP C Logout
2825	0.4053	KATHY	SALES	NCP R OK
2826	0.0024	SALES	KATHY	NCP C Get server's clock
2859	0.7583	SALES	KATHY	Transport retransmission
				NCP C Get server's clock

Frame 448 of 5842

1 Help	2 Set mark	3 Expert window	5 Menus	6 Display options	7 Prev frame	8 Next frame	9 Select frame	10 New capture
--------	------------	-----------------	---------	-------------------	--------------	--------------	----------------	----------------

Figure 4-50. Summary display after Network object filter has been set on the diagnosis, "Retransmissions between SALES and Kathy."



The **Network object** filter lets you zero in on a particular diagnosis or symptom. However, you can also filter frames on any network object that interests you, whether or not the object has associated symptoms. For example, you can display the Network Stations Summary screen, as shown in Figure 4-51. To see all the frames to and from the server "BIZ-ONE," highlight the server's name and press F2 (**Filter&disply**). The Classic window shown in Figure 4-52 appears, containing all the frames to and from BIZ-ONE on its two connections.




Figure 4-51. Network Stations Summary window. Notice the Classic Summary display in the background.




Figure 4-52. Network object filter on the server BIZ-ONE.

Limitations of the Network Object Filter



The **Network object** filter has two limitations, listed below:

- Some symptoms and diagnoses, such as Broadcast storm, have no associated network object on which the analyzer can filter. In those cases, the F2 function key label will not appear at the bottom of display, indicating that a **Network object** filter cannot be set.
- Occasionally you may set a **Network object** filter on an object that no longer has associated frames in the capture buffer. In that case, the message "No frames are eligible for display" will appear.

For example, the analyzer may detect a connection between Agnes and the server BIZ-ONE at the beginning of a capture session. After capture has proceeded for several hours, capture is paused, and a **Network object** filter is set on that connection. While the analyzer knows that connection took place, the actual transmitted frames have been pushed out of the capture buffer by newer data. To ensure that the data you are interested in remains in the capture buffer, use a capture filter, or a trigger.

Note: The "No frames are eligible for display" message can also appear when the highlighted object has never actually sent or received a frame. For example, in the Network Stations Summary screen in Figure 4-51, if you highlight OPTICAL1, pressing F2 (**Filter&disply**) does not cause any filtering because OPTICAL1 has neither sent nor received frames.

Other Notes About the Network Object Filter

The Expert analyzer uses several algorithms to decide which frames are associated with the network object chosen as a filter. Sometimes, these algorithms may eliminate frames you consider relevant. For example, if you set a network object filter on a Novell Netware connection layer connection, the Expert analyzer would show all those related frames with NCP layers, but possibly would eliminate from display some connection maintenance frames that it considers irrelevant.

Displaying the Network Object Filter

The Expert analyzer allows you to view the network object on which it is filtering at any time.



To display the current Network object filter:

1. Move to **Display \ Filters**.

The display in Figure 4-53 appears.




Figure 4-53. The Display\Filters menu.

2. Move to **Network object** and press Enter.

The analyzer displays the object on which the analyzer is currently filtering. Figure 4-54 shows a **Network object** filter on the connection between the two network stations, SALES and Kathy. Only frames associated with this connection will be displayed under the current **Network object** filter.

Note: If no **Network object** filter is currently set, the analyzer will display the message:

No Network object filter has been set.
Go to the Expert window to set a filter.




Figure 4-54. Displaying the current Network object filter.

Removing the Network Object Filter

Existing **Network object** filters must be removed before you can set a new one. **Network object** filters can be removed in two ways:

- Using the F2 (**Remove Filter**) function key. The function key F2 acts as a toggle for setting and removing **Network object** filters. This is the preferred method.
- Using the **Network object** filter menu item in the Display/Filters menu.

For information on setting a new filter, see "To set an automatic Network object filter:" on page 4-69.



To remove a Network object filter using the Network object menu item:

1. Move to **Display\Filters\Network object** and press Enter.

The display in Figure 4-54 appears.

2. Press the Delete key to remove the current **Network object** filter.

Temporarily Disabling the Network Object Filter

Once a **Network object** filter is set, you may want to temporarily disable it without having to reset it later. In Figure 4-53, notice that the menu entry for the **Network object** filter is preceded by a √. By using the spacebar to toggle the √ to an x, you can temporarily disable the **Network object** filter without removing it.



To temporarily disable or enable a Network Object filter:

1. Move the highlight to the **Display\Filters** menu.
The menu in Figure 4-53 appears.
2. Move to **Network object** and press Spacebar to change the ✓ to an x.
3. Press F3 (**Data display**) to display all frames in the capture buffer according to currently enabled filters.



Note: When you set a Network object filter, the filter is automatically enabled. If the Network object filter was disabled when you set it, a pop-up window will inform you that the filter has been enabled.

Symptom Frames Filter

In addition to the **Network object** display filter, the Expert analyzer also provides a **Symptom frames** display filter. The Symptom frames display filter allows you to filter from display those frames that do not exhibit symptoms. In this way you can filter a huge capture buffer down to just those frames that interest you.



To filter out frames that do not exhibit symptoms:

1. Move to **Display\Filters\Symptom frames**.




Figure 4-55. *Symptom frames filter. Notice the x preceding the filter.*

2. Press Spacebar to change the x in front of **Symptom frames** to a ✓, to enable the **Symptom frames** filter.
3. Press F3 (**Data display**) to display only those frames that exhibit symptoms. Figure 4-56 is an example of the Summary window after the **Symptom frames** filter was enabled.

SUMMARY	Delta T	DST	SRC	
8893	0.1894	MIS	NAHEED	Low throughput = 43 Kb/s
8915	0.2087	MIS	NAHEED	NCP C F=39C7 Read 512 at 76288
9024	0.7833	BIZ-ONE	SACHI	Low throughput = 43 Kb/s
9070	0.3789	BIZ-ONE	CCMAIL	NCP C F=A650 Read 512 at 7681177
9104	0.4899	MIS	NAHEED	File retransmission
9164	0.2805	BRUCE	BIZ-ONE	NCP C F=2C64 Read 4 at 73
9360	1.2573	MIS	NAHEED	Low throughput = 2 Kb/s
9399	0.8656	BIZ-ONE	SACHI	NCP C F=F719 Close file
9632	3.2719	BIZ-ONE	SACHI	Transport retransmission
10017	3.2706	BIZ-ONE	SACHI	NCP C F=A650 Read 512 at 7904153
				Request denied
				NCP R No queue job
				Transport retransmission
				NCP C F=39C7 Read 512 at 76800
				File retransmission
				NCP C F=2C64 Read 4 at 73
				File retransmission
				NCP C F=2C64 Read 4 at 73
				File retransmission
				NCP C F=2C64 Read 4 at 73

Frame 8893 of 16496

1 Help 2 Set mark 3 Expert window 5 Menus 6 Display options 7 Prev frame 8 Next frame 9 Select frame 10 New capture

Figure 4-56. Classic Summary display with *Symptom frames* filter enabled.

Advanced Navigation Techniques

This section describes several advanced techniques for navigating through the Expert window. As you grow more comfortable working with the Expert analyzer, these techniques will speed your work with the analyzer. They include:

- Higher layer/Lower layer function keys
- Next symptom/Previous symptom function keys

Using the Higher Layer/Lower Layer Function Keys

During post-capture display (or, while capture is paused), there are also several function keys available which allow you to trace the displays relating to a specific network object through the four Expert layers without having to return to the Expert Overview. For example, you could use the **Lower layer** key to trace the displays relating to a particular application from the Application layer down to the DLC Station layer. This eliminates the need to return to the Expert Overview before investigating related displays at another layer.



The **Higher layer/Lower layer** function keys are not available while the analyzer is actively capturing frames. They are available only while capture is paused or during post-capture display.



To use the Higher layer/Lower layer function keys:

1. In a Summary, Detail, or Statistics window at any of the four Expert layers, use the cursor keys to highlight the application, connection, network station, or DLC station of interest.
2. If the analyzer is capturing frames, pause capture by pressing F9.

Result: Additional key labels appear for F7 (**Lower layer**) and F8 (**Higher layer**) (Figure 4-57).

Note: The F7 (**Lower layer**) and F8 (**Higher layer**) keys will appear only during post-capture display, or if capture is paused.

Note: If the highlighted object is at the Application layer, the key label for F8 (**Higher layer**) will not appear, because there is no higher layer. Similarly, the key label for F7 (**Lower layer**) will not appear if the highlighted object is at the DLC Station layer because there is no lower layer.

F7 (**Lower layer**) label appears when capture is paused or during post-capture display.




Figure 4-57. Application Summary screen with F7 (**Lower layer**) visible.

3. Press F7 (**Lower layer**) or F8 (**Higher layer**).

Result: The object related to the highlighted object appears at the higher or lower layer, depending on which key was pressed. For example, if the highlight was on the application between the two stations **AlicesWS** and **SalesServer** (as in Figure 4-57) and F7 (**Lower layer**) was pressed, the display would now show the Connection Summary window with the corresponding connection highlighted (as in Figure 4-58).

Note: If F7 (**Lower layer**) is pressed from a Connection layer Summary or Detail window, the pop-up box in Figure 4-58 appears. Because there are two network stations associated with a connection, the analyzer prompts you to select which of the two related network stations you want to see highlighted in the Network Stations window.




Figure 4-58. Pop-up box for selecting related network station to display.

Using the Next Symptom/Previous Symptom Keys

You can also use the + (**Next symptom**) and - (**Previous symptom**) keys to speed your navigation of the Expert window. These keys allow you to skip automatically between network objects that have symptoms associated with them. These keys are available in any of the displays accessible from the Objects/Symptoms column of the Expert Overview. They are available during capture, while capture is paused, and post-capture.



The **Next symptom/Previous symptom** keys are particularly valuable in the Detail and Statistics windows. You can use them to scroll automatically to the Detail or Statistics window for the previous/next network object with associated symptoms. This eliminates the need to return to the Summary view to find a network object with associated symptoms.



To use the Next symptom/Previous symptom keys:

1. In any display accessible from the Objects/Symptoms column of the Expert Overview, press + (**Next symptom**) or - (**Previous symptom**).

Result: The display for the next or previous (depending on which key was pressed) object which has associated symptoms appears. The display corresponds to the display from which F2/F3 was pressed. Detail windows will appear from Detail windows, Statistics windows will appear from Statistics windows, and so on.

2. Note: If there are no previous symptoms and - (**Previous symptom**) is pressed, nothing will happen. Similarly, if there are no later symptoms and + (**Next symptom**) is pressed, nothing happens.

Function Keys in the Expert Window

This section describes the various function keys available in the Expert window. Different Expert displays have different associated function keys.

During Capture:

- | | |
|-------|--|
| +/- | The plus and minus keys allow you to move display to the next or previous symptom respectively. |
| F2 | From the Expert Overview, pressing the F2 key displays the Global Statistics window. |
| F4 | In the Summary displays, the F4 key allows you to change the format of the current Expert window. The available formats for the Summary window are described on page 4-40. |
| F7/F8 | <p>In the Diagnosis Summary and Diagnosis Detail windows, the F7 and F8 keys allow you to temporarily remove and restore diagnoses from the display. See page 4-12 for more information.</p> <p>In displays accessible from the Objects/Symptoms column of the Expert Overview, F7 moves display to the next higher layer associated with the highlighted object, while F8 moves to the next lower layer associated with the highlighted object.</p> |
| F9 | F9 pauses capture temporarily. While capture is paused, the following additional function keys become available: |
| F10 | F10 stops capture and returns you to the Main Menu of the analyzer. |

While Capture is Paused

- | | |
|-----|---|
| +/- | The plus and minus keys allow you to move display to the next or previous symptom respectively. |
| F1 | F1 provides a context-sensitive Explain message, displaying important information about the highlighted symptom or diagnosis. |
| F2 | <p>In the Expert Overview, pressing the F2 key displays the Global Statistics window.</p> <p>In a Summary or Detail display, the F2 keys acts as a toggle for setting and removing Network object filters. For more information on Network object display filters, see the sections beginning on page 4-68.</p> |
| F3 | F3 acts as toggle between the analyzer's Expert and Classic display windows. |
| F5 | F5 takes you to the analyzer's main menu. |

F6	F6 provides a menu of Capture-related options.
F7/F8	<p>In the Diagnosis Summary and Diagnosis Detail windows, the F7 and F8 keys allow you to temporarily remove and restore diagnoses from the display. See page 4–12 for more information.</p> <p>In displays accessible from the Objects/Symptoms column of the Expert Overview, F7 moves display to the next higher layer associated with the highlighted object, while F8 moves to the next lower layer associated with the highlighted object.</p>
F9	F9 resumes a paused capture.
F10	F10 starts a new capture.

APPENDIX A: SYMPTOM AND DIAGNOSIS MESSAGES

A

Appendix A. Symptom and Diagnosis Messages

Overview

This appendix lists all the symptom and diagnosis messages generated by the Expert analyzer, and provides a brief description. The messages are grouped by Expert layers; within each layer, they are arranged alphabetically.



This appendix is not intended to provide detailed descriptions of each symptom and diagnosis. When the analyzer generates a symptom or diagnosis you do not understand, you should pause capture and press F1 to invoke a context-sensitive Explain message. Explain messages provide detailed descriptions for all the symptoms and diagnoses generated by the Expert analyzer including related thresholds and possible solutions to network problems.

Symptoms

Application Layer

File retransmission

An entire file, or a subset of a file has been retransmitted. This differs from a transport layer retransmission because the application is purposely retransmitting the file. Each retransmission is counted as a separate symptom.

Loops on same request

The application process on one station sent out the same request even though it has already received the appropriate reply from the destination station. Only requests that are sent within the time specified by **Filter time** are considered "repeated."

Low throughput/Slow file transfer

The rate of throughput during a file transfer was less than the minimum rate specified by the **Local transfer** or **Remote transfer** threshold. Throughput is measured for consecutive bytes within the same file.

Read/write overlap

Read or write requests to a file overlapped each other. For example, if an application wrote bytes 50 through 700, and then wrote bytes 200 through 800, there would be a write overlap because bytes 200-700 were written twice.

Request denied

The number of denied application requests exceeded the **Denied count** threshold. An application request is only counted as denied if it occurs within the time specified by **Filter time**. For more information, see "Denied Count" and "Filter Time" on page 3-18.

Connection Layer

Ack missing

A REPLY-ACK frame was expected but none was received.

Ack number decreasing

An acknowledgment specifies the segment number of the next octet to be received. The segment number points to the octet's position in the data stream. The amount of data accumulated by the receiver determines what the next octet should be. For example, if octets 1 through 5000 have been received, the receiver specifies the next octet to be 5001. As the transmission progresses, the segment number should increase. A decreasing number causes the sender to send an octet that has already been received. If the analyzer detects this situation, it displays this symptom message.

Ack wrong frame

A REPLY-ACK frame was seen as a response to a REQUEST-DATA frame; REPLY-ACK should only be seen as a response to a REQUEST-DATA-LAST frame.

Bouncing frames

The same frame has appeared twice, but with a decreasing value in the "time-to-live" field. This usually occurs between two routers or gateways, when the same packet is sent between two network stations repeatedly.

Command retransmission

A LAT command frame has been retransmitted. The analyzer tracks the exact number of command frames retransmitted.

Data sent while flow control off

A DECnet data frame was sent while flow control was turned off at the receiving station.

Fast retransmission

A retransmission occurred within less than the time specified by the **Fast retrans** threshold.

Refer to “Fast Retransmission” on page 3–22 for more information on this threshold and the related symptoms and diagnoses.

Flow control off for x seconds

DECnet flow control was turned off for x seconds, which exceeded the threshold specified by **Zero window**.

Idle more than xx

No communications were detected between the two end-points of a connection at the transport layer for more than the time specified by the **Idle timer** threshold.

Refer to “Idle Timer” on page 3–21 for more information on this threshold and the related symptoms and diagnoses.

Long ack time

The time that it took the receiver to acknowledge an octet was excessive. The analyzer uses an internal algorithm to determine the threshold. If the threshold is exceeded, it prints the symptom message. The threshold is 3 times the average acknowledgment time plus the **Fast retrans** threshold.

Missing reply

In a request/reply-based protocol (such as Novell PEP), a request was detected, but a corresponding reply was not detected.

Multiple source routing

In a token ring environment, a source-routed packet can be sent from one station to another using multiple paths. This is probably due to incorrect configuration of the token ring bridges.

NFS retransmission

An NFS request has been retransmitted. This is detected by comparing the current RPC transaction identifier with the previous value for this connection.

Packets too close

Two LAT frames are closer than 20ms. The LAT standard is 80ms.

Receive/Continue missing

A RECEIVE-CONTINUE frame was expected as a response to a REQUEST-DATA frame but a different frame was received instead.

Reply retransmission

A LAT reply frame has been retransmitted. The LAT standard states that retransmissions should not occur until at least one second has elapsed from the prior transmission.

Synchronization frame missing

A SYNC frame was expected but none was received.

Transport retransmission

The sequence number is less than or equal to its previous value, indicating that this frame contains data that has already been transmitted.

Window frozen

The TCP window size of the highlighted station has been stuck for longer than the time specified by the **Zero window** threshold.

Window size exceeded

In a windowed protocol (such as TCP or DECnet), the sender sent a segment that contained more data than the receiver's advertised window size.

Wrong reply sequence

The reply sequence number did not match the request sequence number.

Zero window

The TCP window size of the highlighted station has been zero for longer than the duration specified by the threshold **Zero window**.

Network Station Layer

The symptoms and diagnoses at the network layer are concerned with addressing and how traffic is routed from the local network to remote networks.

Destination unreachable

The highlighted station has sent or received x number of ICMP "destination unreachable" messages.

Duplicate net address

The same network address was mapped to more than one DLC address.

Improper DECnet address

The first four bytes of a DECnet network layer address should always be AA000400. This symptom is generated if a non-conforming address was found in a Long Data or an endnode hello packet.

ICMP error

The highlighted station has received an ICMP message indicating a parameter problem.

Inconsistent server advertisement

Two routers advertise a Novell server with a hop count of one. This hop count value for a Novell SAP means that a router is the server.

Inconsistent subnet mask

The subnet mask specified in an ICMP "address mask reply" message did not match any of the expected subnet masks. The subnet mask could be legitimate, but it is not specified in the STARTUP.ENV file. Use the **Set subnet mask** utility in the **Expert settings** menu to edit subnet masks.

IP fragment missing

An IP layer fragment on an NFS connection has been lost. This will usually result in an NFS layer retransmission.

IP fragment out of order

An IP layer fragment on an NFS connection was not in sequential order.

Local router

When the analyzer detects that a router is routing traffic between two local stations, it displays a symptom message. Because the stations are located on the same network, no routing should be necessary.

Many routers to remote

A local station can connect to a remote station through more than one router on the local network.

Multiple routers to local station

The number of routers used to gain access to a local station has equalled or exceeded the **Multiple Routers** threshold.

Network unreachable

The highlighted station has received an ICMP "network unreachable" message.

Port unreachable

The highlighted station has sent an ICMP "port unreachable" message. The message indicates that the station has received a frame sent to the named port, but the port cannot be accessed by the receiving station.

Redirect network/host/frame

The highlighted station has sent an ICMP "redirect host" message. Routers send these messages to inform stations of better routes to desired destinations.

Small hello timer

The rate of DECnet endnode hellos is smaller than the **DEC Hello** threshold. A high rate of DECnet hellos contributes unnecessarily to network overhead.

Source address is broadcast

The source address in a packet is a broadcast address.

Source quench

The highlighted station has received an ICMP "source quench" message. Source quench messages inform stations to reduce their rate of frame transmission.

Time-to-live exceeded

The highlighted station has received an ICMP "Time Exceeded" message. The time-to-live field of the IP layer has reached zero, and therefore the frame has been discarded.

Time-to-live expiring

An IP frame has been detected with a "time-to-live" field equal to 1 or 0, indicating that the frame is about to expire.

Zeros broadcast address

Lists the number of IP frames sent from the highlighted station to an all-zero broadcast address.

DLC Station Layer

Broadcast storm

The rate of broadcast frames sent on the network has exceeded the **Broadcast sy** threshold.

Frame not analyzed

One or more frames were not analyzed by the Expert analyzer. This may happen during heavy network traffic. If the frames are still in the capture buffer, you can overcome this by reanalyzing the data in the capture buffer.

Frame too short

A frame fragment has been detected. The fragment is shorter than the DLC address fields.

LAN overload

The network data rate used a greater percentage of available bandwidth than that specified by the **LAN overload** threshold.

Physical level error

The analyzer has detected a physical level error. If the number of physical errors per second exceeds the **Physical error** threshold, the analyzer will generate a diagnosis. Physical errors include short frames, frames with bad CRCs, and lost frames.

Source DLC address is broadcast

The source DLC address field is a broadcast address.

MAC Layer (Token Ring)

The analyzer captures and reports all MAC level frames on the token ring. Since MAC level frames are essential for troubleshooting token rings, the analyzer reports most MAC frames as symptoms.

Abort error

An “abort delimiter transmitted” MAC condition has been detected.

AC error

The next active upstream neighbor is unable to set the Frame Copied/ Address Recognized bits in a frame it has copied.

Bad FC/AR flags

The analyzer has detected an invalid format in the Frame Copied/ Address Recognized bits of a frame from the highlighted station.

Burst error

There is a signaling error in the cable. The error is not caused by a station entering or leaving the ring. The Expert analyzer filters out those Burst error frames caused by ring entry and departure.

Duplicate test successful

The Duplicate Address Test MAC frame has been successful (another station on the ring has the same address). When the DLC address of a station trying to enter the ring is the same as the DLC address of a station already in the ring, the station attempting entry is automatically disconnected.

Excessive ring purge

The number of ring purge frames has exceeded the **Rng purge sy** threshold in the **Expert settings** menu.

Frame relay buffer depth exceeded

The buffer depth on the router has exceeded a preconfigured threshold. Frames may be lost as a result. If possible, the router should be reconfigured with more buffers.

Internal error

The highlighted station has a recoverable internal error. If the station is reporting multiple internal errors, the station is marginal.

Line error

A "line error" MAC condition has been detected. There was an invalid character in a frame or token, or there was a check error in a frame.

Local node with route designator

Source routing is being used but the source and destination stations are both on the same local ring.

Multiple local ring definitions

Source routing is being used. The routing information in two or more frames is contradictory-- that is, two frames have different definitions of the local ring number.

New active monitor

There is a new active monitor on the ring.

Receiver congestion error

The analyzer has detected a Receiver congestion MAC frame. Receiver congestion occurs when a station does not have enough room in its buffer to copy a frame for which it is the destination. If the number of Receiver congestion MAC frames per second exceeds the **RX Congestion** threshold, a diagnosis is generated.

Returned to ring

The highlighted station has reentered the ring, after having left the ring. A new symptom is generated each time the station reenters the ring.

Ring beaconing

The highlighted station has transmitted a Beacon MAC frame in an attempt to bring the ring back into normal operation. Also a diagnosis.

Station off ring

The highlighted station has left the ring, either purposely or due to a ring problem. A new symptom is generated each time the station leaves the ring.

Token error

The token has been lost. This error should only be generated by the active monitor when it recognizes the need to create a new token.

WAN/Synchronous**DISC frame**

One or more DISC (disconnect) frames have been received. The HDLC link has been disconnected and must be reestablished before any data transfer can proceed. All previous connections must be renewed.

DLCI bandwidth exceeded

Frame Relay symptom. The measured bandwidth exceeds the requested bandwidth reported in the most recent local management interface (LMI) PVC status frame. The requested bandwidth is the amount guaranteed by the Frame Relay service. It is legal to exceed this amount occasionally, but most Frame Relay services do not guarantee full frame delivery if the value is exceeded.

DLCI keepalive sequence error

Frame Relay symptom. The sequence number in a keepalive LMI frame has been reset to zero. Frames may have been lost immediately prior to this occurrence.

Excessive backward congestion

Frame Relay symptom. The percentage of frames with the Backward Explicit Congestion Notification (BECN) bit set exceeds the **Congestion %** threshold in the **Expert settings \ Thresholds** menu.

The BECN bit indicates backward congestion on a Frame Relay link. The BECN bit is set by a congested network to notify the user that congestion avoidance procedures should be initiated in the opposite direction of the transmitted frame.

Excessive forward congestion

Frame Relay symptom. The percentage of frames with the Forward Explicit Congestion Notification (FECN) bit set exceeds the **Congestion %** threshold in the **Expert settings \ Thresholds** menu.

The FECN bit indicates backward congestion on a Frame Relay link. The FECN bit is set by a congested network to notify the user that congestion avoidance procedures should be initiated in the opposite direction of the transmitted frame.

FRMR frame

One or more FRMR (frame reject) frames have been received. FRMR frames indicate an error condition not recoverable by retransmission. Investigate the FRMR frames for more details about the cause of each error.

HDLC retransmission

One or more HDLC numbered information frames have been retransmitted.

Inappropriate SABM

An HDLC SABM (set asynchronous balanced mode) frame has been received, but the Modulo 128 encoding option is currently selected in the **Options** menu of the Sniffer analyzer. This is an inconsistency. You should select the Modulo 8 encoding option instead. Encoding options are found in the **Options** menu of the Sniffer analyzer.

Inappropriate SABME

An HDLC SABME (set asynchronous balanced mode extended) frame has been received, but the Modulo 8 encoding option is currently selected in the **Options** menu of the Sniffer analyzer. This is an inconsistency. You should select the

Modulo 128 encoding option, instead. Encoding options are found in the **Options** menu of the Sniffer analyzer.

Inappropriate SNRM

An HDLC SNRM (set normal response mode) frame has been received, but the **Frame type** option in the Sniffer analyzer's **Options** menu is not currently set to **SDLC then SNA**. Because the HDLC SNRM frame is usually seen only on an SNA network, you should probably set the **Frame type** option to **SDLC then SNA**.

REJ frame

A REJ (reject) frame has been received. This usually indicates that one or more frames have been lost. If this happens often, check your modem and line for correct operation.

Router buffer overflow

Frame Relay symptom. The buffer depth on the router has exceeded a preconfigured router threshold, possibly causing frames to be lost. If possible, the router should be reconfigured with more buffers.

WAN underload

The Expert analyzer generates the WAN underload symptom when the data rate falls below the percentage of available bandwidth specified by the **WAN underload** threshold in the **Expert settings** menu.

WAN congested

The Expert analyzer generates the WAN overcongested symptom when the data rate exceeds the percentage of available bandwidth specified by the **WAN overload** threshold in the **Expert settings** menu.

Diagnoses

Application Layer

Excessive requests denied

This diagnosis indicates that a server has denied an excessive number of application requests relative to the number of successful requests. The related threshold is **Denied request %**.

Refer to “Excessive Requests Denied” on page 4–18 for more information on this diagnosis.

File overlap/retransmission

This diagnosis indicates that the same block of a file is retransmitted between two stations too many times.

When the analyzer counts the number of retransmissions, it also includes the number of file overlaps. Refer to “File Overlap / Retransmission” on page 4–19 for more information on this diagnosis.

Slow file transfer

The analyzer generates the **Slow file transfer** diagnosis when the ratio of slow versus normal file transfers is greater than the **Slow file %** threshold in the Expert settings menu. The analyzer uses different thresholds depending on whether frames were routed locally or remotely.

Refer to “Slow File Transfer” on page 4–33 for more information on this diagnosis and the related thresholds.

Slow server

This diagnosis indicates that the analyzer considers the highlighted server slow because of the time it takes for it to respond to application requests.

Refer to “Slow Server” on page 4–34 for more information on this diagnosis and its related thresholds.

Connection Layer

Non-responsive station

The analyzer generates this diagnosis when the number of consecutive identical retransmissions without response on a given connection exceeds the **No responses** threshold in the **Expert settings** menu.

Refer to “Non-Responsive Station” on page 4–29 for more information on this diagnosis and related thresholds.

Retransmissions

The analyzer generates this diagnosis when the number of retransmitted frames on a given connection (expressed as a percentage of good transmissions versus retransmissions on the connection) exceeds the **Retransmission percentage** threshold in the Expert settings menu.

Refer to “Retransmissions” on page 4–31 for more information on this diagnosis and related thresholds.

Network Station Layer

Duplicate network address

The analyzer generates this diagnosis (and symptom) when two or more DLC stations are associated with the same network address.

Refer to “Duplicate Network Address” on page 4–16 for more information on this diagnosis and related thresholds.

Local router

The analyzer generates this diagnosis when two DLC stations on the same network segment are communicating via two or more routers, rather than directly from one DLC station to the other.

Refer to “Local Router” on page 4–27 for more information on this diagnosis.

Multiple routers to station

The analyzer generates this diagnosis when there are more routers on the local network that can route frames to a remote station than specified by the **Multiple routers** threshold.

Refer to “Multiple Routers to Station” on page 4–28 for more information on this diagnosis and related thresholds.

DLC Station Layer

Broadcast/Multicast storm

The analyzer generates this diagnosis when the number of broadcast/multicast frames per second exceeds the rate specified by **Broadcast dg** in the **Expert settings** menu.

Refer to “Broadcast Storm” on page 4–15 for more information on this diagnosis and related thresholds.

LAN overload

The analyzer generates this diagnosis when the rate of network traffic in a given minute is too high. This depends on the settings of the thresholds **LAN overload** and **LAN overload percentage**.

Refer to "LAN Overloaded" on page 4-26 for more information on this diagnosis and the related thresholds.

High rate of physical errors

The analyzer generates this diagnosis when the rate of physical errors per second detected for a particular station exceeds the rate specified by the **Physical errors** threshold.

Refer to "High Rate of Physical Errors" on page 4-22 for more information on this diagnosis and its related threshold.

MAC Layer (Token Ring)

High rate of congestion

The analyzer generates this diagnosis when the rate of MAC receiver congestion errors per second exceeds the rate specified by the **RX Congestion** threshold.

Refer to "High Rate of Congestion" on page 4-20 for more information on this diagnosis and its related threshold.

High rate of line/burst errors

The analyzer generates this diagnosis when the rate of MAC level line plus burst errors for a given station exceeds the **Ring errors** threshold.

Refer to "High Rate of Line or Burst Errors" on page 4-21 for more information on this diagnosis and its related threshold.

High rate of remove from ring requests

The analyzer generates this diagnosis when the rate of MAC level remove from ring requests sent to a given station exceeds the **Stn removed** threshold.

Refer to "High Rate of Remove from Ring Requests" on page 4-23 for more information on this diagnosis and its related threshold.

High rate of ring entries

The analyzer generates this diagnosis when the rate of MAC level ring entries from a given station exceeds the **Ring entries** threshold.

Refer to "High Rate of Ring Entries" on page 4-24 for more information on this diagnosis and its related threshold.

High rate of ring purges

The analyzer generates this diagnosis when the rate of MAC level ring purge frames from a given station exceeds the **Rng purge dg** threshold.

Refer to “High Rate of Ring Purges” on page 4–25 for more information on this diagnosis and its related threshold.

Ring beaconing

The analyzer generates this diagnosis when it detects a MAC level ring beacon frame.

Refer to “Ring Beaconing” on page 4–32 for more information on this diagnosis and its related threshold.

WAN/Synchronous**WAN overloaded**

The data rate has exceeded the threshold specified by the **WAN overload** threshold for longer than the duration specified by the **Overload timer** threshold.

Underloaded network

The data rate has fallen below the threshold specified by the **WAN underload** threshold for longer than the duration specified by the **Underload timer** threshold.

Refer to “Underloaded Network” on page 4–35 for more information on this diagnosis and its related thresholds.

INDEX

Index

A

- Abort error
 - MAC symptom A-9
- absolute utilization
 - field in statistics windows 4-59, 4-61
- AC error
 - MAC symptom A-9
- Ack missing
 - symptom A-4
- Ack number decreasing
 - symptom A-4
- Ack wrong frame
 - symptom A-4
- active
 - token ring monitor 1-7
- active stations
 - field in Global Symptoms detail window 4-54
- active time
 - field in Global Symptoms detail window 4-54
- address
 - width of field 3-51
- alarm
 - defined 2-4
 - levels 3-38
 - offender field 2-5
 - overview of all associated options 3-33
 - priorities 3-33
 - priority 2-5
 - throttle 3-38
 - timestamp 2-5
 - type description 2-5
- analysis server
 - connect when already running 1-9
- Analyzer xiii
- Analyzer Operations Manual xiii
- analyzer present, token ring broadcast 1-7
- appl ID
 - counter 4-50

- application layer
 - alarm priorities 3-34
 - available Expert triggers 3-41
 - detail window 4-50
 - Expert thresholds 3-17
 - list of diagnoses A-14
 - list of symptoms A-3
 - OSI vs. Expert layer 3-5
 - Statistics window 4-56
- application requests
 - field in statistics window 4-56
- associated DLC addresses
 - field in statistics window 4-60
- associated network stations
 - field in statistics window 4-62
- asterisk
 - meaning in Expert displays 4-11
- average frame length
 - field in statistics window 4-58
- average load %
 - field in Global Symptoms detail window 4-54

B

- Bad FC/AR flags
 - MAC symptom A-10
- bandwidth
 - field in Global Stats window 4-66
 - percentage utilization 4-66
- baseline
 - network 3-13
- Beacon
 - alarm priority 3-37
- Bouncing frames
 - symptom A-4
- Broadcast dg
 - Expert threshold 3-25
- Broadcast Storm
 - alarm priority 3-36
- Broadcast storm
 - Diagnosis Detail display 4-15
 - symptom A-9
- Broadcast sy
 - Expert threshold 3-25
- broadcasts

field in Global Symptoms detail window 4-54

Broken Connection

alarm priority 3-35

broken connection

how analyzer calculates 4-29

Burst error

MAC symptom A-10

bytes

counter in summary windows 4-39

bytes transferred

field in statistics window 4-56

C

cable test

Ethernet 1-6

capture

customizing 3-43

selecting mode 2-7

vs. display 1-5

capture buffer

printing 3-47

capture filters

effects on Global Statistics 4-68

Classic capture

defined 1-4

Command retransmission

LAT symptom A-4

composition of traffic by protocol family

fields in Global Stats window 4-65

configuration

Expert analyzer 3-7

STARTUP.xxV 3-7

subnet masks 3-7

Congestion percentage

as calculated for Frame Relay 3-29

as calculated for HDLC 3-29

Expert threshold 3-29

conn

field in summary windows 4-39

connection layer

alarm priorities 3-35

available Expert triggers 3-41

detail window

DLC Station layer

detail window 4-50

Expert thresholds 3-21

list of diagnoses A-14

list of symptoms A-4

OSI vs. Expert layer 3-5

Statistics window 4-58

connections to net stations

field in statistics window 4-60

console

defined 1-4

relation to server 1-9

counters

appl ID 4-50

associated DLC addresses 4-60

connections to net stations 4-60

diagnosis 2-8

duration 4-11

first time 4-11

in Detail windows 4-49

in the Summary window 4-39

inter-frame time 4-57

transfers data for 4-62

D

data link layer

OSI vs. Expert layer 3-5

Data sent while flow control off

DECnet symptom A-4

DCE

as relates to Underload calculation 3-29

DEC hello

Expert threshold 3-22

to measure duplicate addresses 3-23

DEC keep alive

Expert threshold 3-22

DECnet

learning names

3-52

defaults

resetting for thresholds 3-13

subnet masks 3-7

Denied count

Expert threshold 3-18

Denied req%

Expert threshold 3-19

Destination unreachable

symptom A-6

Detail Diagnosis windows 4-13

Detail window

displaying 4-47

for subnet pairs 4-51

Global Symptoms 4-53

information in 2-13, 4-49

overview 4-5

- symptom and network object 4-47
 - diagnoses
 - column in Expert Overview 4-8
 - diagnosis
 - and the Expert analyzer 2-4
 - Broadcast storm 4-15
 - counter 2-8
 - defined 2-4
 - Detail windows 4-13
 - displays in the Expert window 4-10
 - Duplicate Network Address 4-16
 - Excessive Repeated Requests 4-17
 - Excessive Requests Denied 4-18
 - File Overlap/Retransmission 4-19
 - getting more information 2-9
 - High Rate of Congestion 4-20
 - High Rate of Line/Burst Errors 4-21
 - High Rate of Physical Errors 4-22
 - High Rate of Remove from Ring Requests 4-23
 - High Rate of Ring Entries 4-24
 - High Rate of Ring Purges 4-25
 - LAN Overloaded 4-26
 - listed at application layer A-14
 - listed at connection layer A-14
 - listed at DLC Station layer A-15
 - listed at MAC layer A-16
 - listed at network station layer A-15
 - listed for WAN/Synchronous A-17
 - Local router 4-27
 - Multiple Routers to Station 4-28
 - Non-responsive station 4-29
 - Overview display 2-9
 - restoring to display 4-12
 - Retransmissions 4-31
 - Ring Beaconsing 4-32
 - setting thresholds for 3-13
 - Slow File Transfer 4-33
 - Slow Server 4-34
 - Summary display 4-10
 - temporarily removing 4-12
 - Underloaded Network 4-35
 - using as a filter 4-68
 - using as trigger event 3-39
 - DISC frame
 - WAN/Synchronous symptom A-11
 - display
 - in the Expert window 4-6
 - server seen from console 1-9
 - types available in Expert window 2-8
 - vs. capture 1-5, 1-6
 - width of name field 3-51
 - display filters
 - for the Expert analyzer 4-68
 - symptom frames 4-76
 - Distributed Sniffer System 1-3
 - and Expert alarms 2-5
 - documentation xiii
 - Distributed Sniffer System: Server Installation and Operations Manual* xiii
 - Distributed Sniffer System: Token Ring Monitor Operations Manual* xiii
 - DLC addr
 - field in detail windows 4-50
 - DLC name
 - field in detail windows 4-50
 - DLC Station Address
 - field in summary window 4-39
 - DLC Station layer
 - alarm priorities 3-36
 - available Expert triggers 3-42
 - Expert thresholds 3-24
 - list of diagnoses A-15
 - list of symptoms A-9
 - OSI vs. Expert layer 3-5
 - Statistics window 4-60
 - DLCI bandwidth exceeded
 - WAN/Synchronous symptom A-11
 - DLCI keepalive sequence error
 - WAN/Synchronous symptom A-12
 - documentation
 - Distributed Sniffer System xiii
 - DTE
 - as relates to Underload calculation 3-29
 - Duplicate Network Address
 - alarm priority 3-35
 - Diagnosis Detail display 4-16
 - symptom A-6
 - Duplicate test successful
 - token ring symptom A-10
 - Duplicate%
 - thresholds 3-23
 - duration
 - counter in summary windows 4-11
 - difference from elapsed time counter 4-67
 - field in Global Stats window 4-66
- ## E
- Ethernet
 - cable test 1-6
 - Ethernet Monitor Operations Manual. xiii

- Excessive Backward Congestion
 - as calculated for Frame Relay nets 3-29
 - WAN/Synchronous symptom A-12
- Excessive Forward Congestion
 - as calculated for Frame Relay nets 3-29
 - WAN/Synchronous symptom A-12
- Excessive Repeated Requests
 - Diagnosis Detail display 4-17
- Excessive Requests Denied
 - Diagnosis Detail display 4-18
- Excessive ring purge
 - MAC symptom A-10
- Expert alarm
 - defined 2-4
 - offender field 2-5
 - priority 2-5
 - timestamp 2-5
 - type description 2-5
- Expert analyzer
 - alarms 2-4
 - and diagnoses 2-4
 - and learning names 3-52
 - and network objects 2-3
 - and symptoms 2-4
 - application layer 3-5
 - configuration 3-7
 - configuring subnet masks 3-9
 - configuring trustee names 3-11
 - connection layer 3-5
 - description of capture 2-3
 - Detail windows 2-13, 4-5
 - Diagnosis Summary display 4-10
 - display filters 4-68
 - DLC Station layer 3-5
 - effects of changing thresholds 3-30
 - excluding trustee names 3-11
 - Expert layers 3-4
 - Expert Overview window 4-5
 - Expert window 2-8
 - Freeze/Reuse allocation option 3-45
 - function keys 4-80
 - Global Statistics view 4-6
 - Highest layer option 3-44
 - layers 2-8
 - main menu 2-7
 - navigating displays 4-6
 - network object filter 4-68
 - network station layer 3-5
 - overview of displays 2-12, 4-4
 - protocols available for analysis 2-15
 - role in solving network problems 2-5

- setting subnet masks 3-7
- setting thresholds 3-13
- starting in Expert mode 2-3
- Statistics windows 2-14, 4-6, 4-54
- Summary windows 2-12, 4-5
- symptom and network object displays 4-36
- symptom detail windows 4-47
- terminology 2-3

- Expert Overview
 - and navigating through the analyzer 4-8
 - as home base for analysis 4-3
 - diagnoses column 4-8
 - explained 4-8
 - objects column 4-8
 - symptoms column 4-8

- Expert threshold 3-26

- Expert window
 - defined 2-8
 - displaying analysis results in 4-3
 - function keys 4-80
 - navigating displays 4-6
 - overview of displays 2-12

- Explain
 - defined 2-10
 - F1 2-10
 - sample screen 2-10
 - to display a message 2-10
 - using to investigate network problems 4-12
 - vs. help screens 2-10

F

- F1
 - Explain 2-10, 4-12, 4-80
 - help 4-80
- F10
 - stop capture 4-80
 - stop/new capture 4-81
- F2
 - displaying Global Statistics 4-64
 - filter&disply 4-69, 4-80
 - to view Global Statistics 4-80
- F3
 - display 4-80
 - toggle between Expert and Classic windows 4-80
- F4
 - changing formats of Summary window 4-40
 - view DLC Stn/Protocol/Symptom 4-80
- F5
 - menus 4-80

- F6
 - capture options 4-81
 - F7
 - higher layer 4-81
 - remove diag 4-12, 4-80, 4-81
 - F8
 - lower layer 4-81
 - restore diags 4-12, 4-80, 4-81
 - F9
 - pause 4-80
 - pause/resume capture 4-81
 - Fast retrans
 - Expert threshold 3-22
 - Fast retransmission
 - symptom A-4
 - features
 - new Expert features 1-13
 - field
 - printed report 3-47
 - width of name 3-51
 - file
 - printer output 3-49
 - STARTUP.xxV 3-7
 - File Overlap/Retransmission
 - Diagnosis Detail display 4-19
 - File retransmission
 - symptom A-3
 - Filter time
 - Expert threshold 3-18
 - filters
 - Expert display filters 4-68
 - first time
 - counter in summary windows 4-11
 - Flow control off for x seconds
 - DECnet symptom A-5
 - form feed, printed report 3-50
 - format
 - printed report 3-47
 - Frame not analyzed
 - symptom A-9
 - Frame Relay
 - about the global protocol family counter 4-65
 - and the calculation of Congestion percentage 3-29
 - Frame relay buffer depth exceeded
 - symptom A-10
 - frame size
 - effects on Global Statistics 4-68
 - Frame too short
 - symptom A-9
 - frames
 - field in subnet detail window 4-52
 - field in subnet summary windows 4-45
 - Freeze/Reuse allocation option 3-45
 - FRMR frame
 - WAN/Synchronous symptom A-12
 - From DCE
 - Global Statistics field 4-66
 - From DTE
 - Global Statistics field 4-66
 - function keys
 - in the Expert window 4-80
- ## G
- generate traffic 1-6
 - Global Statistics
 - display using F2 4-80
 - effects of capture filters on 4-68
 - effects of Frame Size option 4-68
 - fields composing 4-64
 - overview 4-6
 - overview of window 4-64
 - percent analyzed field 4-67
 - percentage bandwidth utilization fields 4-66
 - run information fields 4-66
 - start run field 4-67
 - to display the window 4-64
 - Global Symptoms
 - Detail window 4-53
 - summary window defined 4-46
- ## H
- HDLC
 - and the calculation of Congestion percentage 3-29
 - HDLC retransmission
 - WAN/Synchronous symptom A-12
 - heading, printed output 3-50
 - help
 - vs. Expert explain 2-10
 - High Rate of Congestion
 - Diagnosis Detail display 4-20
 - High Rate of Line/Burst Errors
 - Diagnosis Detail display 4-21
 - High Rate of Physical Errors
 - Diagnosis Detail display 4-22
 - High Rate of Remove from Ring Requests
 - Diagnosis Detail display 4-23

- High Rate of Ring Entries
 - Diagnosis Detail display 4-24
- High Rate of Ring Purges
 - Diagnosis Detail display 4-25
- Highest layer option 3-44
- highlight
 - menu selection 1-10, 1-11
- hop count
 - field in subnet detail window 4-52
- hops
 - field in statistics window 4-56
 - field in subnet summary window 4-45

I

- ICMP error
 - symptom A-7
- Idle more than xx
 - symptom A-5
- Idle timer
 - Expert threshold 3-21
- Improper DECnet address
 - symptom A-7
- Inappropriate SABM
 - WAN/Synchronous symptom A-12
- Inappropriate SABME
 - WAN/Synchronous symptom A-12
- Inappropriate SNRM
 - WAN/Synchronous symptom A-13
- Inconsistent server advertisement
 - symptom A-7
- Inconsistent subnet mask
 - symptom A-7
- inter-frame time
 - field in statistics window 4-57
 - how calculated 4-57
- Internal error
 - MAC symptom A-10
- Internetwork Analyzer
 - Expert thresholds 3-28
 - list of diagnoses A-17
 - list of symptoms A-11
- IP
 - setting IP addresses 3-7
- IP fragment missing
 - symptom A-7
- IP fragment out of order
 - symptom A-7

L

- LAN Manager
 - token ring functional address 1-7
- LAN overload
 - Expert threshold 3-24
 - symptom A-9
- LAN overload%
 - Expert threshold 3-24
- LAN Overloaded
 - diagnosis detail display 4-26
- last symptom
 - field in summary windows 4-39
- layers
 - on the Expert analyzer 2-8
 - on the Expert analyzerlayers 3-4
- Line error
 - MAC symptom A-10
- lines per page 3-50
- Local node with route designator
 - MAC symptom A-10
- Local router
 - alarm priority 3-36
 - Diagnosis Detail display 4-27
 - symptom A-7
- Local xfer
 - Exper threshold 3-19
- Long ack time
 - symptom A-5
- Loop%
 - Expert threshold 3-19
- Loops on same request
 - symptom A-3
- Low throughput/Slow file transfer
 - symptom A-3

M

- MAC layer
 - alarm priorities 3-36
 - available Expert triggers 3-42
 - Expert thresholds 3-26
 - list of diagnoses A-16
 - list of symptoms A-9
- main menu 1-10, 1-12
 - Expert analyzer 2-7
- main selection menu 2-6
- Many routers to remote
 - symptom A-7
- max load %

- field in Global Symptoms detail window 4-54
- memory
 - conserving with Highest layer option 3-44
 - Freeze/Reuse allocation option 3-45
- menu
 - main 1-12
 - panels 1-11
- Min appl req
 - threshold 3-17
- Missing reply
 - symptom A-5
- Mult routers
 - Expert threshold 3-22
- Multiple local ring definitions
 - MAC symptom A-10
- Multiple routers to local station
 - alarm priority 3-36
 - Diagnosis Detail display 4-28
 - symptom A-7
- Multiple source routing
 - token ring symptom A-5

N

- name
 - common Novell names to exclude 3-11
 - excluding Novell trustee names 3-11
 - Expert and remote stations 4-51
 - field width in display 3-51
 - tricks for learning w/Expert 3-52
 - using Expert to learn 3-52
- name table
 - using Expert to learn 3-52
- Name width display option 3-51
- net addr
 - field in detail windows 4-50
- net name
 - field in detail windows 4-50
- net station address
 - field in summary window 4-39
- network
 - baseline 3-13
- Network and Protocol Reference xiii
- network layer
 - OSI vs. Expert layers 3-5
- network object
 - and changed thresholds 3-30
 - and the Expert analyzer 2-3
 - and the Freeze/Reuse allocation option 3-45
 - defined 2-3
 - Detail windows 4-47
 - Freeze/Reuse allocation option 3-45
 - getting more information 2-12
 - how Expert reuses 3-46
 - overview of related displays 2-12
 - printing reports on 3-47
 - related displays in the Expert window 4-36
 - Statistics window 4-54
 - Summary displays 4-36
 - upper limit of Expert database 3-46
- Network object display filter 4-68
 - displaying 4-73
 - limitations 4-73
 - removing 4-75
 - setting 4-69
 - temporarily disabling 4-75
- Network Overload
 - alarm priority 3-36
- network station layer
 - available Expert triggers 3-41
 - detail window 4-50
 - Expert thresholds 3-22
 - list of diagnoses A-15
 - list of symptoms A-6
 - OSI vs. Expert layer 3-5
 - Statistics window 4-59
- network stations layer
 - alarm priorities 3-35
- Network Underload
 - symptom 3-28
- Network unreachable
 - ICMP symptom A-7
- New active monitor
 - MAC symptom A-11
- NFS retransmission
 - symptom A-5
- NI5210 Installation Manual xiv
- NI9210 Installation Manual xiv
- No responses
 - Expert threshold 3-21
- Non-responsive station
 - Diagnosis Detail display 4-29
- Novell
 - learning names 3-52
 - setting trustee names 3-11

O

- objects

- column in Expert Overview 4-8
- offender
 - field for Expert alarms 2-5
- options
 - Freeze/Reuse allocation 3-45
 - highest layer option 3-44
- organization
 - menus 1-12
- OSI model
 - vs. Expert layers 3-4
- output
 - printer page titles 3-50
 - to file 3-49
 - to printer 3-49
- Overcongested WAN
 - as calculated for HDLC 3-29
- Overload timer
 - Expert threshold 3-28

P

- packet data length
 - field in statistics window 4-56
- Packets too close
 - LAT symptom A-5
- page numbers 3-50
- page titles 3-50
- panel
 - menu 1-11
- parallel port 3-49
- pause
 - using F9 to pause 4-80
- percent analyzed
 - field in Global Stats window 4-67
- percentage bandwidth use
 - Global Stats fields 4-66
- Physical err
 - Expert threshold 3-25
- Physical Error
 - alarm priority 3-36
- physical error
 - received 3-25
 - sent 3-25
- physical layer
 - OSI vs. Expert layer 3-5
- Physical level error
 - symptom A-9
- Port unreachable
 - ICMP symptom A-8

- presentation layer
 - OSI vs. Expert layer 3-5
- printer port 3-49
- printing
 - capture buffer 3-48
 - destination 3-49
 - fields included 3-47
 - format 3-47
 - lines per page 3-50
 - overview 3-47
 - page size 3-50
 - page titles 3-50
 - print options 3-48
 - reports on network objects 3-47
 - to file 3-47
- PRN, file extension for printer output 3-49
- protocol
 - breakdown of traffic by family 4-65
 - field in summary window 4-39
- protocol interpreter
 - available on Expert analyzer 2-15

Q

- QS-1000 Installation Manual xiv
- QS-100D Installation Manual xiv

R

- Read/write overlap
 - symptom A-3
- README file xiv
- Receive Congestion Burst
 - alarm priority 3-37
- Receive/Continue missing
 - symptom A-5
- Receiver congestion error
 - MAC symptom A-11
- Redirect network/host/frame
 - ICMP symptom A-8
- REJ frame
 - WAN/Synchronous symptom A-13
- relative utilization
 - field in statistics windows 4-60, 4-62
- Remote xfer
 - Expert threshold 3-19
- remove diag.F7 4-12
- Reply retransmission
 - LAT symptom A-6
- Request denied

- symptom A-4
- requests
 - field in summary window 4-40
- Resp time
 - Expert threshold 3-17
- restore diags,F8 4-12
- Retrans%
 - Expert threshold 3-21
- Retransmission
 - alarm priority 3-35
- Retransmissions
 - Diagnosis Detail display 4-31
- Returned to ring
 - MAC symptom A-11
- Reuse/Freeze allocation option 3-45
- Ring Beaconing
 - Diagnosis Detail display 4-32
 - MAC symptom/diagnosis A-11
- Ring entries
 - Expert threshold 3-26
- Ring errors
 - Expert threshold 3-27
- Ring Purges
 - alarm priority 3-37
- Rng purge dg
 - Expert threshold 3-27
- Rng purge sy
 - Expert threshold 3-27
- RNR frames
 - relation to congestion percentage 3-29
- Router buffer overflow
 - WAN/Synchronous symptom A-13
- routers to subnet
 - field in subnet detail window 4-52
- RR frames
 - relation to congestion percentage 3-29
- run information
 - fields in Global Stats window 4-66
- RX congestion 3-26

S

- selection menu
 - main 2-6
 - server 1-9
- server
 - connect when already running 1-9
 - defined 1-4
 - relation to console 1-9
 - selection menu 1-9
- session layer
 - OSI vs. Expert layer 3-5
- setting
 - Name width display option 3-51
 - Network object display filter 4-69
 - Symptom frames filter 4-76
- size
 - printed page 3-50
- Slow File Process
 - alarm priority 3-34
- Slow File Transfer
 - Diagnosis Detail display 4-33
- Slow file%
 - Expert threshold 3-20
- Slow resp%
 - Expert threshold 3-17
- Slow Server
 - Diagnosis Detail display 4-34
- Small hello timer
 - DECnet symptom A-8
- Sniffer analyzer
 - starting in Expert mode 2-3
- Sniffer Network Analyzer
 - main selection menu 2-6
 - major components 1-5
- Sniffer server (see "server") 1-3
- SniffMaster console (see "console") 1-3
- SniffMaster console, relation to server 1-9
- Source address is broadcast
 - symptom A-8
- Source DLC address is broadcast
 - symptom A-9
- Source quench
 - ICMP symptom A-8
- standby monitor, token ring 1-7
- start run
 - field in Global Stats window 4-67
- STARTUP.xxV
 - configuring for Expert analyzer 3-7
- state
 - field in Global Symptoms detail window 4-54
- station address
 - width of display field 3-51
- Station off ring
 - MAC symptom A-11
- Station Removed
 - alarm priority 3-37

- station status
 - field in token ring statistics windows 4-63
 - Statistics window
 - application layer 4-56
 - connection layer 4-58
 - DLC Station layer 4-60
 - Expert analyzer 2-14
 - network station layer 4-59
 - overview 4-6
 - symptom and network object 4-54
 - to display 4-55
 - Stn removed
 - Expert threshold 3-27
 - subnet
 - detail window for subnet pairs 4-51
 - field in detail windows 4-50
 - field in summary windows 4-45
 - Summary window 4-44
 - subnet mask
 - default Expert masks 3-7
 - subnet masks
 - configuration 3-7
 - non-standard 3-7
 - Summary window
 - available formats 4-41
 - displaying 4-37
 - Global Symptom 4-46
 - information in 2-12, 4-38
 - meaning of asterisk 4-11
 - overview 4-5, 4-36
 - subnet counts 4-44
 - Sun Yellow Pages
 - learning names 3-52
 - symptom
 - and the Expert analyzer 2-4
 - defined 2-4
 - Detail windows 4-47
 - display filter 4-76
 - field in subnet detail window 4-52
 - field in subnet summary window 4-45
 - field in summary window 4-40
 - getting more information 2-12
 - listed at application layer A-3
 - listed at connection layer A-4
 - listed at DLC Station layer A-9
 - listed at MAC layer A-9
 - listed at network station layer A-6
 - listed for Internetwork analyzer A-11
 - overview of related displays 2-12
 - related Expert displays 4-36
 - setting thresholds for 3-13
 - Statistics windows 4-54
 - Summary displays 4-36
 - using as a filter 4-68
 - Symptom frames filter 4-76
 - symptoms
 - column in Expert Overview 4-8
 - Synchronization frame missing
 - symptom A-6
- ## T
- TCP keep alive
 - Expert threshold 3-22
 - TCP/IP
 - learning names 3-52
 - setting IP addresses 3-7
 - setting subnet masks 3-7
 - terminology
 - Expert analyzer 2-3
 - thresholds
 - at DLC Station layer 3-24
 - at MAC layer 3-26
 - at network station layer 3-22
 - Broadcast dg 3-25
 - Broadcast sy 3-25
 - Congestion percentage 3-29
 - DEC hello 3-22
 - DEC keep alive 3-22
 - Denied count 3-18
 - Denied req% 3-19
 - Duplicate% 3-23
 - effects of changing 3-14, 3-30
 - Expert application layer 3-17
 - Fast retrans 3-22
 - Filter time 3-18
 - for Internetwork Analyzer 3-28
 - for token ring 3-26
 - for WAN/Synchronous 3-28
 - Idle timer 3-21
 - interaction of thresholds 3-15
 - LAN overload 3-24
 - LAN overload% 3-24
 - Local xfer 3-19
 - Loop% 3-19
 - Min appl req 3-17
 - Mult routers 3-22
 - No responses 3-21
 - on token ring 3-26
 - Overload timer 3-28
 - Physical err 3-25

- Remote xfer 3-19
 - Resp time 3-17
 - Retransmission% 3-21
 - Ring entries 3-26
 - Ring errors 3-27
 - Rng purge dg 3-27
 - Rng purge sy 3-27
 - RX congestion 3-26
 - setting on Expert analyzer 3-13
 - Slow file% 3-20
 - Slow resp% 3-17
 - Stn removed 3-27
 - TCP keep alive 3-22
 - Underload timer 3-29
 - WAN Overload 3-28
 - WAN Underload 3-28
 - Zero window 3-21
 - throttle
 - as relates to Expert alarms 3-38
 - throughput
 - field in statistics window 4-56
 - timestamp
 - and Expert alarms 2-5
 - Time-to-live exceeded
 - symptom A-8
 - Time-to-live expiring
 - IP symptom A-8
 - title, printed report 3-50
 - Token error
 - MAC symptom A-11
 - token ring
 - alarm priorities 3-36
 - available Expert triggers 3-42
 - Expert thresholds 3-26
 - Expert thresholds for 3-26
 - LAN Manager functional address 1-7
 - list of diagnoses A-16
 - list of symptoms A-9
 - monitor 1-7
 - trace tool present 1-7
 - Token Ring 16/4 / A Network Guide to Operations xiv
 - Token Ring 16/4 Network Guide to Operations xiv
 - Token Ring Bursts
 - alarm priority 3-37
 - Token Ring Entries
 - alarm priority 3-37
 - Token Ring Monitor Operations Manual* xiii
 - total bytes
 - field in statistics window 4-58
 - total file transfers
 - field in statistics window 4-56
 - total symptoms
 - field in detail windows 4-51
 - trace tool present, token ring message 1-7
 - traffic generator 1-6
 - transport
 - OSI vs. Expert layer 3-5
 - Transport retransmission
 - symptom A-6
 - tree structure of menus 1-10
 - trigger
 - available MAC layer Expert triggers 3-42
 - effects of an Expert trigger 3-40
 - Expert token ring triggers 3-42
 - Expert triggers 3-39
 - Expert triggers at application layer 3-41
 - Expert triggers at connection layer 3-41
 - Expert triggers at DLC Station layer 3-42
 - Expert triggers at network station layer 3-41
 - Expert vs. Classic triggers 3-42
 - marking of trigger frame 3-42
 - processing order 3-42
 - using diagnoses as triggers 3-39
 - trustee names
 - setting on Expert analyzer 3-11
 - type description
 - and Expert alarms 2-5
- ## U
- Underload timer
 - Expert threshold 3-29
 - Underloaded Network
 - diagnosis 3-28
 - diagnosis detail display 4-35
 - WAN/Synchronous diagnosis A-17
 - upstream neighbor
 - field in token ring statistics windows 4-63
 - Use defaults command
 - resetting Expert thresholds 3-13
- ## W
- WAN congested
 - WAN/Synchronous symptom A-13
 - WAN Overload
 - Expert threshold 3-28
 - WAN overloaded
 - WAN/Synchronous diagnosis A-17

WAN Underload

Expert threshold 3-28

WAN/Synchronous symptom A-13

WAN/Synchronous

Expert thresholds 3-28

list of diagnoses A-17

list of symptoms A-11

Window frozen

TCP/IP symptom A-6

Window size exceeded

TCP/IP symptom A-6

Wrong reply sequence

symptom A-6

Z

Zero window

Expert threshold 3-21

TCP/IP symptom A-6

Zeros broadcast address

IP symptom A-8



*We simplify network complexity.*TM

Network General Corporation
4200 Bohannon Drive
Menlo Park, California 94025
+1 (415) 473-2000

Network General Europe
Belgicastraat 4
1930 Zaventem, Belgium
+32 (2) 725-6030

Network General Canada, Ltd.
9225 Leslie Street, Unit #7
Richmond Hill, Ontario L4B 3H6 Canada
+1 (416) 882-7905